

# **AIRSTAGE™ V-II**

Variable Refrigerant Flow System

## ***Multi Air Conditioning System for Buildings***

Large Capacity Multi VRF System  
DC Inverter Control Compressor  
Long Piping System Design  
High Efficiency Refrigerant R410A



**SERVICE MANUAL**  
**FUJITSU GENERAL LIMITED**





# CONTENTS

## 1. TEST RUN

<b>1-1 EXECUTION PROCEDURE AND EXECUTION PRECAUTIONS.....</b>	<b>01-01</b>
<b>1-2 TEST RUN METHOD.....</b>	<b>01-03</b>
1-2-1 Check Items Before Power ON.....	01-03
1-2-2 Check Items After Power ON.....	01-04
1-2-3 Test Run From Outdoor PC Board.....	01-06
1-2-4 Test Run From Remote Controller.....	01-07
<b>1-3 TEST RUN CONTROL.....</b>	<b>01-10</b>
<b>1-4 Field Setting And Monitor Mode List.....</b>	<b>01-11</b>

## 2. OUTDOOR UNIT OPERATION CONTROL

<b>2-1 INPUT / OUTPUT LIST.....</b>	<b>02-01</b>
<b>2-2 COMPRESSOR OPERATION.....</b>	<b>02-02</b>
2-2-1 Operation / Stop Condition.....	02-02
2-2-2 Capacity Control.....	02-02
2-2-3 Speed Range of Start,Stop,and Operation.....	02-03
2-2-4 Compressor Sequence Operation.....	02-05
<b>2-3 FAN CONTROL.....</b>	<b>02-06</b>
2-3-1 Cooling Operation.....	02-06
2-3-2 Heating Operation.....	02-07
2-3-3 Low noise mode.....	02-08
2-3-4 Snow Falling Protection Fan Mode.....	02-09
2-3-5 Other Control.....	02-09
<b>2-4 EXPANSION VALVE CONTROL.....</b>	<b>02-09</b>
<b>2-5 SPECIAL OPERATION.....</b>	<b>02-10</b>
2-5-1 Oil Recovery Operation.....	02-10
2-5-2 Pre-Heat Operation.....	02-11
2-5-3 Defrost Operation Control.....	02-11
<b>2-6 PROTECTIVE FUNCTION.....</b>	<b>02-13</b>
2-6-1 Protective Function List.....	02-13

# CONTENTS

## 3. INDOOR UNIT OPERATION

<b>3-1 FAN CONTROL</b>	03-01
3-1-1 Fan Speed Setting	03-01
3-1-2 "AUTO" Position	03-01
<b>3-2 MASTER CONTROL</b>	03-02
3-2-1 Operation Mode Control	03-02
3-2-2 Auto Changeover	03-04
3-2-3 "COOL" Position	03-05
3-2-4 "HEAT" Position	03-05
<b>3-3 LOUVER CONTROL</b>	03-06
<b>3-4 ELECTRONIC EXPANSION VALVE CONTROL</b>	03-09
<b>3-5 DRAIN PUMP OPERATION</b>	03-09
<b>3-6 FUNCTION</b>	03-10
3-6-1 Auto Restart	03-10
3-6-2 Icing Protection Control	03-10
3-6-3 Oil Recovery Operation	03-10
<b>3-7 TIMER CONTROL</b>	03-11
3-7-1 Wireless Remote Controller	03-11
3-7-2 Group Remote Controller	03-13
3-7-3 Wired Remote Controller	03-15

## 4. TROUBLE SHOOTING

<b>4-1 NORMAL OPERATION</b>	04-01
4-1-1 Indoor Unit Display	04-01
4-1-2 Outdoor Unit Display	04-02
<b>4-2 ABNORMAL OPERATION</b>	04-03
4-2-1 Indoor Unit Display	04-03
4-2-2 Outdoor Unit Display	04-04
4-2-3 Error Code List for Outdoor Unit	04-05
4-2-4 Remote Controller Display	04-06
4-2-5 Error Code List for Simple and Wired Remote Controller	04-07
4-2-6 Error Code List for Group Remote Controller	04-07
4-2-7 Trouble Level of System	04-08
4-2-8 Error History Mode	04-09-(02)
<b>4-3 TROUBLE SHOOTING</b>	04-10
4-3-1 Trouble Shooting With Error Code (INDOOR UNIT)	04-10
4-3-2 Trouble Shooting With Error Code (OUTDOOR UNIT)	04-21
4-3-3 Trouble Shooting for Optional Parts	04-75
<b>4-4 SERVICE INFORMATION</b>	04-95
4-4-1 Backup operation	04-95
4-4-2 Work procedure after the backup operation	04-97
<b>4-5 SERVICE PARTS INFORMATION</b>	04-98

# CONTENTS

## **5. APPENDING DATA**

<b>5-1 REFRIGERANT CIRCUIT</b> .....	05-01
<b>5-2 WIRING DIAGRAM</b> .....	05-05
5-2-1 Indoor Unit.....	05-05
5-2-2 Outdoor Unit.....	05-17
<b>5-3 CHARACTERISTICS OF SENSORS</b> .....	05-20
5-3-1 Pressure sensor.....	05-20
5-3-2 Thermistor resistance.....	05-21
5-3-3 Saturation temperature and saturation pressure tables (R410A).....	05-22
5-3-4 Temperature and pressure of refrigerant (Graph).....	05-23

## **6. DISASSEMBLY PROCESS**

# **AIRSTAGE™ V-II**

*Variable Refrigerant Flow System*

## **1. TEST RUN**





# 1. TEST RUN

## 1-1 EXECUTION PROCEDURE AND EXECUTION PRECAUTIONS

### Before execution

Execution zone decision	Execution procedure and precautions	Reason
Confirmation of refrigerant used	① Check the characteristics of the refrigerant used and grasp the special features of the refrigerant. If refrigerant must be charged, always charge the refrigerant specified for the product. R410A 4.20MPa	• Use of a refrigerant other than the specified refrigerant will invite equipment trouble.
Preparation of execution drawings	② Confirm the product design pressure.	
Confirmation of installation site	① Use new refrigerant piping of the thickness specified by the D&T manual.	• Secure the necessary pressure resistance.
Preparations before execution	② Since R410A dedicated tools are necessary, prepare them in advance. ③ Absolutely avoid use of existing piping. If use of existing piping is unavoidable, the piping must be cleaned.	

### Execution

Sleeve and insert work	Always use a level and keep the indoor unit level. If the equipment is tilted toward the drain port, install it so that the tilt is within 10mm. Excessive tilt will cause water leakage.	• Prevention of water leakage
Indoor unit installation	When performing piping work, observe the following items so that the inside of the piping is clean and air tight.	• Foreign matter, water, etc. in the piping will cause faulty cooling and compressor trouble.
Refrigerant piping work	① Use pipe that is not dirty inside. ② When the pipe is left standing, protect it. ③ Finish flaring exactly.	• Refrigerant leakage will cause low performance and abnormal stopping.
Drain piping work	④ Confirm the width across flats dimension and shape of flare nuts. ⑤ Always blow nitrogen while brazing. ⑥ Perform flushing before connecting the equipment.	
Duct work	① Always make the downward slope of the drain pipe 1/100 or greater and make the horizontal length within 20m.	• Prevention of water leakage
Heat insulation work	② Use hard polyvinylchloride pipe as the drain pipe. ③ Support the drain pipe between 1.5 to 2.0m. ④ Use pipe of 1 rank up (VP30 or greater) as central piping.	
Electrical work	Select the size of the heat insulating material according to the ambient temperature and relative humidity of the refrigerant. Use a heat insulating material having a heat conductivity of 0.043W/(m·k) or less.	• Prevention of water leakage
Outdoor unit foundation work		
Outdoor unit installation	When making flare connections always use a torque wrench and tighten the flare nut positively to the specified torque.	• Refrigerant leakage will cause low performance and abnormal stopping.
Refrigerant piping connection work	Pressurize the product with nitrogen gas up to the design pressure and conduct a 24Hr air tightness test.	• Refrigerant leakage will cause low performance and abnormal stopping.
Air tightness test	① Install a vacuum pump with reverse flow check mechanism or a reverse flow check adaptor to a conventional vacuum pump and use. ② Pump down sufficiently. Approximately 1 hour or longer after -0.10MPa reached. Allow to stand for approximately 1 hour after stopping the vacuum pump and confirm that the needle does not return.	• Mixing in of vacuum pump oil by reverse flow will cause equipment trouble. • Prevents degradation of the oil by completely removing water and air.
Vacuum drying	③ Air purging using refrigerant is strictly prohibited.	*recommend the vacuuming mode


#### \* Vacuuming mode

This function is used for vacuuming the indoor unit and the connection piping.

When the [vacuuming mode] is set, <Push switch setting, F3:21> EEV of connected all indoor units opens.  
So, the vacuuming indoor unit and piping becomes easier.

When the vacuuming ends, please turn off the power supply of the indoor and outdoor unit, [vacuuming mode] is released.

## Execution



## 1-2 TEST RUN METHOD

### 1-2-1 Check Items Before Power ON

Procedure	Check contents	Judgment standard	Check
Power source	Circuit breaker capacity	Outdoor unit: 50A (AJ*144/126/108), 30A (AJ*90/72)	
		Indoor unit: 20A	
	Type of power source wiring	Circuit breaker: 30A=4mm <sup>2</sup> , 50A=10mm <sup>2</sup> , 60A=16mm <sup>2</sup> , 80A=22mm <sup>2</sup> , 100A=38mm <sup>2</sup>	
		Outdoor unit: 10mm <sup>2</sup> (AJ*144/126/108), 4.0mm <sup>2</sup> (AJ*90/72)	
		Indoor unit: 2.5mm <sup>2</sup>	
	Supply power source	Using a phase tester, etc., check the phase of the power source.	
		Outdoor unit side: Between R-S AC 400V (380-415V)	
		Between S-T AC 400V (380-415V)	
		Between T-R AC 400V (380-415V)	
		Indoor unit side: AC 230V (220-240V)	

Outdoor unit	Appearance	Shall be no scratches, deformation, etc. (Be careful of deformation of the front panel)	
	Serial No.	Shall be checked and entered in the check sheet.	
	Outside air temperature	Shall be checked and entered in the check sheet.	
	Power source wiring connection	Connection points check & loose terminal panel screws check	
	Type of communication line	0.33mm <sup>2</sup> , shielded wire used (22AWG)	
	Communication line connection	Connection points check & loose terminal panel screws check	
	Connection piping	Check whether or not the heat insulation material is installed without a gap.	
	DIP-SW setting	Outdoor unit address setting (SET : 3-1, 2)	
		Setting for number of slave units (SET : 3-3, 4)	
		Number of outdoor units installed (SET : 5-1, 2)	
		Terminal resistor setting (SET : 5-4)	
	Rotary SW setting	Refrigerant circuit address setting (SET : REF AD×10 & ×1)	
	Additional refrigerant amount	Comparison of calculated value and value written on electrics box. Entered in check sheet.	
	3-way valve	MASTER: Gas pipe shall be full-open.	
		MASTER: Liquid pipe shall be full-open.	
		SLAVE1: Gas pipe shall be full-open.	
		SLAVE1: Liquid pipe shall be full-open.	
		SLAVE2: Gas pipe shall be full-open.	
		SLAVE2: Liquid pipe shall be full-open.	

[Note] If operated with the 3-way valve closed, the oil discharged from the compressor will not be returned and will lead to trouble.

Indoor unit	Appearance	There shall be no scratches, deformation, tilting, etc.	
	Serial No.	Shall be checked and entered in the check sheet.	
	Drain cap installation	Shall be installed positively.	
	Power source wiring connection	Connection points check & loose terminal panel screws check	
	Type of communication line	0.33mm <sup>2</sup> , shielded wire used (22AWG)	
	Communication line connection	Connection points check & loose terminal panel screws check	
	Type of remote controller wiring	0.33mm <sup>2</sup>	
	Remote controller wiring connection	Connection points check & loose terminal panel screws check	
	Connection piping	Check whether or not the heat insulation material is installed without a gap.	
	Rotary SW setting	Refrigerant circuit address (REF AD)	
		Indoor unit address (IU AD)	
		At automatic address setting, IU AD/REF AD shall be [0].	
		Remote controller address (RC AD)	
	DIP-SW setting	Function setting (Remote controller custom code/ external input switching/ auxiliary heater ON-OFF)	

## 1-2-2 Check Items After Power ON

[Note]

Cooling test run for each refrigerant circuit.

If multiple refrigerant circuits are test run at the same time, refrigerant circuit address setting errors cannot be detected.

Procedure	Check contents	Judgment standard	Check
Power ON	Outdoor unit circuit breaker ON	Check lighting of PC board LED101 and 7-segment display.	
	Indoor unit circuit breaker ON	Check whether or not indoor unit OPERATION and TIMER lamps flash alternately.	
Outdoor unit PC board push button SW setting/check	Function setting	Are the necessary functions set?	
Address setting/ check	Automatic address setting	Addresses shall be assigned to all indoor units. Check for unset or duplicated addresses.	
	Address read	All the indoor units and outdoor units of the same refrigerant circuit can be checked on the service tool.	
	Address record	Enter the set addresses in the check sheet.	
	Address hold check	Check whether or not the address setting is held by the service tool after indoor/outdoor circuit breakers were turned OFF ⇒ ON.	
Cooling test run	Outdoor unit (master) push button SW operation	All the indoor units in the same refrigerant circuit shall enter the cooling test run state. The outdoor units corresponding to the operation capacity of the indoor units shall operate. *See P01-05 described later.	
All of the indoor units operation (after 30 mins)	<On service tool>		
	High pressure	HPS : 2.7 MPa *	
	Low pressure	LPS : 0.8 MPa *	
	Discharge pipe temperature (outdoor unit)	TH1 (TH2) : 87°C *	
	Suction pipe temperature (outdoor unit)	TH4 : 17°C *	
	Subcool (difference between inlet and outlet of SCHEX)	TH6 - TH7 : 10°C or greater *	
	Inlet air temperature (indoor unit)	TH21 : 27°C *	
	Heat exchange inlet temperature (indoor unit)	TH22 : 11°C *	
	Heat exchange outlet temperature (indoor unit)	TH24 : 13°C *	
	Compressor operation	Shall operate corresponding to the operation capacity of the indoor units.	
	Data output	Service tool used, output (CSV ⇒ Excel)	
	<Outdoor unit>		
	Outdoor PC board/7-segment display	The 7-segment display of all outdoor units of the same refrigerant circuit shall display	
	Operation voltage	Between R-S AC400V (380-415V)	
		Between S-T AC400V (380-415V)	
		Between T-R AC400V (380-415V)	
	Abnormal sound/ abnormal vibration	These shall be no abnormal sound or abnormal vibration.	
		The outdoor fan shall not make a moaning sound.	
		There shall be no discharge air leaking from the outdoor duct.	
		There shall be no pipe chattering sound or flute sound generated.	
	<Indoor unit service tool + actual measurement>		
	Outlet air temperature	Inlet air temperature and outlet air temperature difference shall be 10°C or greater.	
	Abnormal sound/abnormal vibration	There shall be no abnormal sound or abnormal vibration.	
	Water leakage check	There shall be no water leakage. There shall be no condensation on the drain, cabinet, piping, and discharge port.	
	Remote controller operation	Shall operate according to the settings. (ON-OFF, set temperature change)	

Procedure	Check contents	Judgment standard	Check
Indoor unit individual operation	<Indoor unit service tool + actual measurement>		
	Fan operation	Shall be switched to all fan speeds in the cooling mode.	
	Louver operation (except duct)	Louver shall be switched to all positions. Shall also swing.	
	Outlet air temperature	Inlet air temperature and outlet air temperature difference shall be 10°C or greater	
	Abnormal sound/abnormal vibration	There shall be no abnormal sound or abnormal vibration.	
	Water leakage check	There shall be no water leakage. There shall be no condensation on the drain, cabinet, piping, and discharge port.	
	Remote controller operation	Shall operate according to the settings. (ON-OFF, set temperature change)	

\*

These are representative figures of AJYA90LALH at the standard condition. ( Indoor : 27°C, Outdoor : 35°C )

If conditions are different from those above mentioned, the figures will be changed slightly.

It depends on following conditions.


- Outdoor unit capacity
- Indoor and outdoor temperature
- Indoor unit capacity
- Pipe length
- etc



## 1-2-3 Test Run From Outdoor PC Board

All the indoor units connected to the outdoor unit can be test-operated by push button setting. (Only for master unit)


### ● SWITCH POSITION



### ● TEST RUN SETTING


For a detailed description of push button operation, refer to the [D&T manual Chapter 6. SYSTEM DESIGN]

#### < Monitoring condition >




↓ (1) Press the MODE / EXIT button ( SW107 ) once.


#### < Mode select condition >



#### < Fuction select condition >




#### < Pursuance completion >



↓ (6) Press the ENTER button ( SW109 ) or Time out ( 5 seconds)


#### < Return to mode select condition >



(7) Press the MODE / EXIT button





#### < Return to monitoring condition >





example,  
Normal indicate : [ Cooling mode ]


## 1-2-4 Test Run From Remote Controller

### 1. Standard wired remote controller

Stop the indoor unit. Push the  button and  button simultaneously for more than two seconds. The air conditioner will start to conduct a test run and "i" will display on the remote controller display.

However, the ,  setting button does not have function, but all other buttons, displays, and protection functions will operate.


- Perform the test operation for 60 minutes.
- To stop test run, push the START / STOP button of the standard wired remote controller.
- For the operation method, refer to the operating manual and perform operation check.
- Check that there are no abnormal sounds or vibration sounds during test run operation.





### 2. Standard wireless remote controller



- Press the TEST RUN button on the remote controller, while the air conditioner is running.
- To end test run operation, press the remote controller START / STOP button.


When the air conditioner is being test run, the OPERATION and TIMER lamps of indoor unit flash slowly at the same time.




### 3. Simple remote controller

Stop the indoor and outdoor units. Push the remote controller  button and  button simultaneously for more than three seconds. The air conditioner will start to conduct a test run and "i" will display on the temperature display.

However the ,  setting button does not have function but all other buttons, displays and protection functions will operate.

- To stop test running press the  button of the simple remote controller.
- For the operation method refer to the operating manual and perform operation check.
- Check that there are no abnormal sounds or vibration sounds during test run operation.



#### 4. Touch panel controller

##### Test run operating procedure

<Monitor screen (icon)>

Monitor Mode 10/11.2008.Mar. 02:20 PM Status: On

All Lange Group

Top Up Down List


Office A On Cool 21.5°C  
Office B On Heat 21.0°C  
PC Room On Cool 26.0°C  
Room 101 Off  
Restrant On Auto 24.0°C  
Entrance On Auto 24.0°C  
Meeting 1 On Heat 21.5°C  
Meeting 2 Off  
Meeting 3 On Heat 21.0°C  
Conference A On Heat 21.5°C  
Conference B On Auto 22.0°C  
Parking lot Off

Setting  
Schedule

Select All (1)  
Clear All  
Operation (2)  
On  
Off (\*)

Group Schedule Op.Controlled Mode  
Error Filter Sign Op.Restricted Set Temp.

UTY - DTG \*



<Monitor screen (list)>

Monitor Mode 10/11.2008.Mar. 02:20 PM Status: On

All Lange Group

Top Up Down List

Name	Expand	Status	Mode	Set Temp	Fan	R/C Prohibit
Office A		On	Heat	21.5°C	High	
Office B		Mixed	Mixed	Mixed	Mixed	Mixed
PC Room		On	Auto	24.0°C	Low	
Room 101		Off				
Restrant		On	Cool	26.0°C	Auto	
Entrance		Off				
Meeting 1		Off				


Setting  
Schedule

Select All (1)  
Clear All  
Operation (2)  
On  
Off (\*)

Group Schedule RC Prohibition  
Error Filter Sign All Mode Filter  
Op. Controlled On/Off Temp.  
Op. Restricted On Timer


- (1) Select the objective you want to test run.  
Select the objective icon or list at the monitor screen. (Multiple selections is possible)  
Select all the devices registered as objectives by pressing "Select All" on the monitor screen.
- (2) After objective selection at (1), switch to the <Setting screen> by pressing "Operation".

<Setting screen>




(3) Switch to the <Details setting screen> by pressing "Optional Setting" on the setting screen.

<Details setting screen>



(4) Send (start) test run by pressing "Start" and then pressing "OK" on the details setting screen. Test run continues for 60 minutes. During sending, the slave screen shown below is displayed. When sending is completed, the sending slave screen and details setting screen are closed.



To interrupt test run, select the device being test run and execute an operation stop command.

- (\*) At the monitor screen, test run is reset by stopping operation of the objective devices by pressing "OFF".
- (\*) Or test operation is reset by stopping operation of the objective devices by pressing "Off" of Operation and then pressing "OK" on the setting screen.

## 1-3 TEST RUN CONTROL

### 1. When the test run signal is transmitted from standard wired, wireless remote controller, simple remote controller, transmitted network, and outdoor unit.


- (1) The test run operation starts and the electric expansion valve is controlled to a maximum flow, regardless of the temperature condition.
- (2) Frost prevention operation has priority over item(1).
- (3) Whether state of the indoor unit operates or stops, All units in the same refrigerant circuit will start to conduct a test run in accordance with the operation mode set by push switch of outdoor unit ( see 1 - 2 - 3 ).
- (4) After 60 minutes passes, the test run stops.
- (5) Test running initialization is shown below.

Operating Mode	EXCEPT FOR THE DUCT MODEL		DUCT TYPE	
	Cooling	Heating	Cooling	Heating
Fan speed	Hi	Hi	Hi	Hi
Room Temperature Indication	18	30	18	30
Vertical Air Direction Panel	Position ①	Position ④	_____	_____
Swing	OFF	OFF	_____	_____


**\*EXAMPLE**



■ COMPACT CASSETTE TYPE



■ CEILING TYPE



■ COMPACT WALL MOUNTED TYPE



## 1-4 Field Setting And Monitor Mode List

	Classification	ITEM CODE No.	Setting Mode	ITEM CODE No.	Information contents
Push switch on outdoor unit PCB  Monitor mode [ F1 ]	Device and system	00	Connected number of indoor unit		The number of the communicating unit is displayed
		01	Software version of outdoor unit		
		02	Software version of INV PCB		Software version : E●●●VOO☆■□L△△-◎
		03	Software version of communication PCB		[E●●●●][VOO][☆■□][L△△][-◎] displays by five items It skips when there is no suffix「-◎」
	Operation of each part	10	Rotational speed of outdoor unit fan motor		The rotational speed of the outdoor unit fan motor is displayed [ rpm ]
		11	Rotational speed of INV compressor		The rotational speed of the compressor is displayed [ rps ]
		12	Current value of INV compressor		Current value of INV compressor is displayed [ A ]
		13	Current value of CONST speed compressor		Current value of CONST speed compressor is displayed [ A ]
		14	Pulse of EEV1		Pulse of EEV1 is displayed [ pls ]
		15	Pulse of EEV2		Pulse of EEV2 is displayed [ pls ]
	Time guard	20	Accumulated current time		Accumulated current time is displayed [ ×10 hour ]
		21	INV compressor accumulated time [ Cooling ]		Accumulated time is displayed in the cooling operation of the INV compressor [ ×10 hour ]
		22	INV compressor accumulated time [ Heating ]		Accumulated time is displayed in the heating operation of the INV compressor [ ×10 hour ]
		23	CONST speed compressor accumulated time		Accumulated time is displayed of the CONST speed compressor [ ×10 hour ]
	Refrigerant cycle data 1	30	Information on Thermistor 1		The value of the Thermistor 1 is displayed [°C] or [°F]
		31	Information on Thermistor 2		The value of the Thermistor 2 is displayed [°C] or [°F]
		32	Information on Thermistor 3		The value of the Thermistor 3 is displayed [°C] or [°F]
		33	Information on Thermistor 4		The value of the Thermistor 4 is displayed [°C] or [°F]
		34	Information on Thermistor 5		The value of the Thermistor 5 is displayed [°C] or [°F]
		35	Information on Thermistor 6		The value of the Thermistor 6 is displayed [°C] or [°F]
		36	Information on Thermistor 7		The value of the Thermistor 7 is displayed [°C] or [°F]
		37	Information on Thermistor 8		The value of the Thermistor 8 is displayed [°C] or [°F]
		38	Information on Thermistor 9		The value of the Thermistor 9 is displayed [°C] or [°F]
		39	Information on Thermistor 10		The value of the Thermistor 10 is displayed [°C] or [°F]
	Refrigerant cycle data 2	40	Information on Thermistor 11		The value of the Thermistor 11 is displayed [°C] or [°F]
	Refrigerant cycle data 3	50	Information on pressure sensor 1		The value of the pressure sensor 1 is displayed [ MPa ] or [ psi ]
		51	Information on pressure sensor 2		The value of the pressure sensor 2 is displayed [ MPa ] or [ psi ]

	Classification	ITEM CODE No.	Setting Mode	ITEM CODE No.	Setting Function	Default
Indoor unit field setting setting by remote controller	Address	01	Indoor unit address	00~63	00~63	00
		02	Refrigerant circuit address	00~99	00~99	00
	Filter	11	Filter indicator Interval	00	Default	○
				01	Longer	
				02	Shorter	
		13	Filter sign display	00	Enable	○
				01	Disable	
				02	Display only on central remote control	
	Airflow	20	Ceiling airflow (Cassette type only)	00	Default	○
				01	High ceiling	
		23	Vertical airflow direction	00	Default	○
				01	Raise	
		24	Horizontal swing airflow direction	00	Default	○
				01	Left half	
Push switch on outdoor unit PCB  Setting mode [ F2 ]	Correction	10	Sequential start shift	00	Normal	○
				01	21sec. Delay	
				02	42sec. Delay	
				03	63sec. Delay	
				04	120-150m	
	Change of function 1	11	Cooling capacity shift	00	Normal mode	○
				01	Save energy mode 1 (+2°C)	
				02	High power mode 1 (-2°C)	
				03	High power mode 2 (-4°C)	
		12	Heating capacity shift	00	Normal mode	○
				01	Save energy mode (-2°C)	
	Change of function 2	13	Defrost setting shift	00	End temperature:Normal	○
				01	End temperature:Higher	
		20	Switching between forced stop or emergency stop	00	Forced stop	○
				01	Emergency stop	
		21	Operation mode selecting method	00	Priority given to the first command	○
				01	Priority given to the external input of outdoor unit	
				02	Priority given to the master indoor unit	
		22	Snow falling protection fan mode	00	Normal operation	○
				01	Snow falling protection fan mode	
		23	Interval setting for snow falling protection fan mode	00	Standard (30min)	○
				01	Short 1 (5min)	
				02	Short 2 (10min)	
				03	Short 3 (20min)	
	Low noise setting 1	24	High static pressure mode	00	Standard	○
				01	High static pressure 1 (equivalent to 30Pa)	
		28	Change of unit (Temperature)	00	Celsius(°C)	○
				01	Fahrenheit (°F)	
		29	Change of unit (Pressure)	00	MPa	○
				01	psi	
	Change of function 1	30	Energy saving level setting	00	Level 1 (stop)	○
				01	Level 2 (operated at 40% capacity)	
				02	Level 3 (operated at 60% capacity)	
				03	Level 4 (operated at 80% capacity)	
	Low noise setting 1	40	Capacity priority setting (in low noise mode)	00	Off (quiet priority)	○
				01	On (capacity priority)	
		41	Low noise mode setting	00	Off (Normal)	○
				01	On (Low noise mode operation is always done)	
	Low noise setting 1	42	Low noise mode operation level setting	00	Level 1 (55dB)	○
				01	Level 2 (50dB)	

		ITEM CODE No.	Setting Mode	Setting Function	Default
Push switch on outdoor unit PCB  Function mode [ F3 ]	Forced operation	00	Cooling test run	Forced thermostat-ON in Cooling	
		01	Heating test run	Forced thermostat-ON in Heating	
		02	Test run stop	Test run is stopped	
	Install and maintenance 1	10	Signal amplifier automatic address	Automatic address setting operates for signal amplifier	
		11	Indoor unit automatic address	Automatic address setting operates for indoor unit of same refrigerant circuit	
	Install and maintenance 2	21	Vacuumping mode	Vacuumping mode operatesRefer to page 01-01 for the function	
	Clear	30	Error history clear	All the abnormal code histories are cleared	
		32	Current time clear	Accumulated current time becomes [ 0 ]	
		33	INV compressor accumulated timeclear	Accumulated time of the INV compressor becomes [ 0 ]	
		34	CONST speed compressor accumulated time clear	Accumulated time of the CONST compressor becomes [ 0 ]	
		35	Field setting all clear	Return to default the all set items	
	Abnormal	40	*Abnormal reset	It was displayed when abnormality occurs, and abnormal code is reset  This is a function that uses to clear abnormal display after the repair is completed Please operate the switch after power off or power on the outdoor unit	
	Specialtyfunction	91	Central control forced release	When the centralized control device failure, and the centralized control setting cannot be released, this function is used  All the limitations set with the centralized control device are released	
		ITEM CODE No.	Meaning of Error History Number	Information contents	
Push switch on outdoor unit PCB  Error History Mode [ F9 ]	Error history	00	1 time ago (Newest)	Refer to Chapter 4.TROUBLE SHOOTING 4-2-3 Error Code List for Outdoor Unit  and 4-2-8 Error History Mode	
		01	2 times ago		
		02	3 times ago		
		03	4 times ago		
		04	5 times ago		
		05	6 times ago		
		06	7 times ago		
		07	8 times ago		
		08	9 times ago		
		09	10 times ago (Oldest)		

\*< Reset Error Item List By Abnormal Reset Setting >

- Compressor 2 Error
- Compressor 2 Overcurrent Error
- Compressor Motor Loss of Synchronization
- Compressor 1 or 2 Temperature Abnormal
- Inverter Compressor Start Up Error
- Discharge Temperature 1 or 2 Abnormal
- Low Pressure Abnormal
- Current Sensor 1 Error
- Trip Detection
- Outdoor Unit Fan Motor Lock Error
- Rush Current Limiting Resistor Temp Rise Protection
- Magnetic Relay Error

# **AIRSTAGE™ V-II**

*Variable Refrigerant Flow System*

## **2. OUTDOOR UNIT OPERATION CONTROL**





## 2. OUTDOOR UNIT

### 2-1 INPUT / OUTPUT LIST

		Input / output or kind of detail	Control range
INPUT	Discharge pressure sensor Suction pressure sensor Discharge temperature sensor 1 Discharge temperature sensor 2 Outdoor temperature sensor Suction temperature sensor Heat exchanger temperature sensor Liquid temperature sensor 1 Liquid temperature sensor 2 Sub-cool heat exchanger (inlet) sensor Sub-cool heat exchanger (outlet) sensor Compressor temperature sensor 1 Compressor temperature sensor 2 Operation current sensor Pressure switch 1 (Inverter comp) Pressure switch 2 (constant speed comp)	Pressure sensor Pressure sensor Themistor Themistor Themistor Themistor Themistor Themistor Themistor Themistor Themistor Themistor Themistor Current transformer Pressure switch Pressure switch	Measure range 0.0 to 5.0MPa Measure range 0.0 to 1.7MPa Measure range 10 to 130°C Measure range 10 to 130°C Measure range -25 to 58°C Measure range -35 to 70°C Measure range -35 to 70°C Measure range -35 to 70°C Measure range -35 to 70°C Measure range -35 to 70°C Measure range -35 to 70°C Measure range 10 to 130°C Measure range 10 to 130°C Open 4.2MPa Short 3.2MPa Open 4.2MPa Short 3.2MPa
	Rotary SW & DIP-SW & Push SW	Address and function setting	
OUTPUT	Compressor 1 (Inverter) Compressor 2 Electronic expansion valve 1 (Main) Electronic expansion valve 2 (SC-Hex) Fan motor 4-way valve 1 Solenoid valve 1 Solenoid valve 2 Solenoid valve 3 Solenoid valve 5 Solenoid valve 6 Crank case heater 1 Crank case heater 2 Base heater	Magnetic relay Magnetic relay EEV coil EEV coil DC Brushless motor 4-way valve coil Hot gas bypass INV Comp pressure equalizing valve ACM oil return valve1. EEV1 bypass valve INV comp oil release valve For Inverter Compressor For Constant speed Compressor Field supply	Operation coil AC220-240V, 50Hz Operation coil AC220-240V, 50Hz Operating voltage DC12V Operating voltage DC12V AC220-240V, 50/60Hz 6/5 W AC220-240V, 50Hz, 8W AC220-240V, 50Hz, 6W AC220-240V, 50Hz, 6W AC220-240V, 50Hz, 8W AC220-240V, 50Hz, 6W AC240V, 25W AC240V, 35W AC220-240V, 35W
Communication Input / Output	LON WORKS Inverter communication Outdoor unit communication	Indoor unit ↔ Outdoor unit Outdoor unit ↔ Outdoor unit	
External Input / Output	External input 1 (CN131) (Low noise mode operation) External input 2 (CN132) (Cooling / Heating priority) External input 3 (CN133) (Outdoor unit operation peak control) External input 4 (CN134) (Emergency stop operation)	Non-voltage contact input	
	External output 1 (CN136) (Error display) External output 2 (CN137) (Operation display)	ON (Error) / OFF (Normal) ON (Operation) / OFF (Stop)	Control output: DC 0/12-24V, Max.30mA Control output: DC 0/12-24V, Max.30mA
LED display	Single LED 101 Single LED 102 7 Segment LED	Display the information on operation, error and setting with single LED and 7 segment LED.	

## 2-2 COMPRESSOR OPERATION

### 2-2-1 Operation / Stop Condition

When cooling requirement capacity or heating requirement capacity from either of the indoor units in the same refrigerant circuit is input, the compressor operates.

When all the indoor units in no "cooling requirement capacity" or "heating requirement capacity", the compressor is stopped.

But in the following case, the compressor operates in accordance with operation of each mode.


- During 3 minute restart prevention operation
- Icing protection
- Failure (Refer to chapter 4, TROUBLE SHOOTING )
- Oil recovery
- Under expansion valve initialization
- At protective operation
- Emergency stop
- Defrost operation
- Peak cut stop operation

### 2-2-2 Capacity Control

#### (1) Capacity of compressor operation

By combining the operation of DC inverter rotary compressor and the constant speed scroll compressor, the amount of required refrigerant circulation according to cooling and heating load can be supplied from compressor efficiently.

DC inverter rotary compressor is able to control the amount of required refrigerant circulation in details.



## (2) Target low-pressure and high-pressure control

### <Cooling>

In order to make the evaporation pressure of the indoor unit at the proper pressure on a variety of operations, capacity of the compressor will be controlled by low-pressure sensor of the outdoor unit (Master unit).

### <Heating>

In order to make the condensation pressure of the indoor unit at the proper pressure on a variety of operations, capacity of the compressor will be controlled by high-pressure sensor of the outdoor unit (Master unit).

Target low-pressure and high pressure temperature depends on system capacity, capacity of compressor operation, pipe length, and capacity shift switch settings.


## 2-2-3 Speed Range of Start, Stop, And Operation (For DC Inverter Rotary Compressor)

- On stop mode : 0 rps
- On operating mode : 30 - 100 rps
- Master and slave inverter compressors rotational speed are controlled the same  
( In the case of multi outdoor unit )

### (1) Cooling starting process

- For cooling operation only, the upper limit speed at starting is made 50rps and is raised in +10rps increments every 60 seconds.


- The compressor operates at the upper limit speed if the target speed is higher than the upper limit speed.
- The compressor operates at the target speed if the target speed is lower than the upper limit speed.



## (2) Heating starting process

At the start of heating, the compressor is started by the following process. All compressors start-up to change the 4 way valve. Capacity control returns to normal control after the end of the starting process.  
(target high-pressure control)

### < Starting process >



	End conditions
Starting process ①	7 minutes elapsed from start of process ① or 1 minute elapsed from start of process ① and high-pressure of all outdoor units $\geq 2.50\text{MPa}$ Compression ratio of any outdoor unit $> 8$
Starting process ②	30 minutes elapsed from start of process ② or high-pressure of all outdoor units $\geq 2.63\text{MPa}$ or discharge SH of all operating compressors $> 12^\circ\text{C}$

\*However, when the following condition (A) or (B) are satisfied, starting process is not performed.


### < Conditions under which starting process is not performed >

- (A) When outside air temperature  $> 20^\circ\text{C}$
- (B) When the starting process at heating before stopped at the start of heating (including thermostat OFF stop) within 30 minutes after heating stopped.

### < Operation >

Inverter compressor of all outdoor unit is started at 40rps and normal control immediately begins.  
(target high-pressure control)

## (3) Limits the upper limit speed of the INV compressor according to the present high-pressure value.



## 2-2-4 Compressor Sequence Operation


Make a starting sequence and start and stop the compressors in accordance with that sequence.

Starting sequence ①: Compressors are started at nth and stopped nth from the end


Example) Starting sequence ①: Compressor started first, compressor stopped last

Starting sequence ②: Compressor started 2nd, compressor stopped 2nd from the end

- Make a sequence such that the INV compressors are always started before constant speed compressors.
- Operate so that the speed of the operating INV compressors is the same.  
(May also vary with the upper limit & lower limit speed restriction)
- Rotate the starting sequence under the following conditions:
  - Defrosting
  - Oil recovery
  - When cooling discharge temperature is high



CONST. : Constant speed compressor  
INV : Inverter compressor



## 2-3 FAN CONTROL

### 2-3-1 Cooling Operation


Fan step	Fan speed (rpm)				
	AJ *A72LALH	AJ *A90LALH	AJ *A108LALH	AJ *A126LALH	AJ *A144LALH
16	880	880	880	920	920
15	860	860	860	870	870
14	810	810	810	820	820
13	720	720	720	720	720
12	600	600	600	600	600
11	500	500	500	500	500
10	420	420	420	420	420
9	360	360	360	360	360
8	320	320	320	320	320
7	300	300	300	300	300
6	intermittent 1	intermittent 1	intermittent 1	intermittent 1	intermittent 1
5	intermittent 2	intermittent 2	intermittent 2	intermittent 2	intermittent 2
4	intermittent 3	intermittent 3	intermittent 3	intermittent 3	intermittent 3
3	intermittent 4	intermittent 4	intermittent 4	intermittent 4	intermittent 4
2	intermittent 5	intermittent 5	intermittent 5	intermittent 5	intermittent 5
1	intermittent 6	intermittent 6	intermittent 6	intermittent 6	intermittent 6
0	0	0	0	0	0

#### ● Switching conditions of step

The initial speed of the outdoor unit is detected by out door temperature sensor.

Outside air temperature sensor detected value	Fan step
$TAOUT > 30^{\circ}\text{C}$	16
$30^{\circ}\text{C} \geq TAOUT > 20^{\circ}\text{C}$	10
$20^{\circ}\text{C} \geq TAOUT > 10^{\circ}\text{C}$	7
$10^{\circ}\text{C} \geq TAOUT$	0

The fan is controlled to keep high puressure saturation temperature within the target range as follows




Thereafter, the high-pressure is monitoring at a set time interval and the fan speed is changed by the following conditions.

(Conditions which lower the fan speed)  
 High-pressure saturation < low limit of target high-pressure saturation range and heat sink temperature  $\leq 75^{\circ}\text{C}$

(Conditions which raise the fan speed)  
 High-pressure saturation > upper limit of target high-pressure saturation or heat sink temperature  $\geq 80^{\circ}\text{C}$

## ● Intermittent fan mode

Fan step	Fan speed 0 rpm duration time T ( sec )	Fan speed 300 rpm duration time ( sec )
intermittent 1	6	7
intermittent 2	12	
intermittent 3	19	
intermittent 4	26	
intermittent 5	33	
intermittent 6	40	



When switched from normal fan step to intermittent fan step, always start from 300rpm/7sec.

When there was a change during intermittent step 1-6, switching is performed at the time the current speed duration time reaches time-up.

## 2-3-2 Heating Operation

Fan step	Fan speed (rpm)				
	AJ * A72LALH	AJ * A90LALH	AJ * A108LALH	AJ * A126LALH	AJ * A144LALH
16	880	880	880	920	920
15	860	860	860	870	870
14	830	830	830	820	820
13	700	700	700	700	700
12	600	600	600	600	600
11	500	500	500	500	500
10	420	420	420	420	420
9	360	360	360	360	360
8	320	320	320	320	320
7	300	300	300	300	300

## ● Switching conditions of step

The initial speed of the first boot outdoor unit is detected by outdoor air temperature sensor value (TAOUT).

Outside air temperature sensor detected value	Fan step
TAOUT < 10°C	16
10°C ≤ TAOUT < 15°C	12
15°C ≤ TAOUT < 20°C	7
20°C ≤ TAOUT	7

Thereafter, the high-pressure is monitoring at a set time interval and the fan speed is changed by the following conditions. Other outdoor units are normally operated at fan step 16.

(Condition which lowers the fan speed)

High-pressure ≥ 3.30MPa and heat sink temperature ≤ 75°C

(Condition which raises the fan speed)

High-pressure saturation ≤ 3.20MPa or heat sink temperature ≥ 80°C

## 2-3-3 Low noise mode

When the low noise mode setting ON from PUSH SW or EXTERNAL INPUT, the outdoor unit operates in the low noise mode as follows.

### «Settings and corresponding operations»

Capacity priority setting ( PUSH SW )	Low noise level setting ( PUSH SW )	Operation mode
OFF	LEVEL 1	LOW NOISE MODE ①
	LEVEL 2	LOW NOISE MODE ②
ON	LEVEL 1	* Automatic switching ①
	LEVEL 2	* Automatic switching ②

### «Low noise mode and operation contents»

			8HP	10HP	12HP	14HP	16HP
LOW NOISE MODE ①	COOL	Fan upper limit speed	600rpm	600rpm	600rpm	600rpm	600rpm
		Upper limit compressor capacity	INV 45rps	INV 53rps	INV 60rps	INV 72rps	INV 72rps
	HEAT	Fan upper limit speed	600rpm	600rpm	600rpm	600rpm	600rpm
		Upper limit compressor capacity	INV 46rps	INV 47rps	INV 61rps	INV 100rps	INV 100rps
LOW NOISE MODE ②	COOL	Fan upper limit speed	500rpm	500rpm	500rpm	500rpm	500rpm
		Upper limit compressor capacity	INV 45rps	INV 50rps	INV 60rps	INV 62rps	INV 62rps
	HEAT	Fan upper limit speed	500rpm	500rpm	500rpm	500rpm	500rpm
		Upper limit compressor capacity	INV 45rps	INV 45rps	INV 55rps	INV 62rps	INV 62rps


The constant speed compressor is stopped in the LOW NOISE MODE ① and ②

The operating noise is reduced by limiting the rotational speed of the inverter compressor and fan motor


LOW NOISE MODE ① ・ ・ ・ The operating sound lowers from about 3 to 5 dB more than the rated value

LOW NOISE MODE ② ・ ・ ・ The operating sound lowers from about 3 to 5 dB more than the LOW NOISE MODE ①

#### \* Automatic switching ①



#### \* Automatic switching ②





## 2-3-4 Snow Falling Protection Fan Mode


The fan rotates compulsorily at the maximum speed when the outdoor temperature becomes 5°C or less when snow falling protection fan mode is set on.

The fan is rotated for 1 minute at the fan step upper limit at the interval set by PUSH SW.

This mode ends when the outdoor temperature becomes 7°C or more or operation starts.

(Operation contents)

Interval setting	PUSH SW setting ( F2 - 23 )	Interval time Int (min)
setting ④ (standard)	00	30
setting ①	01	5
setting ②	02	10
setting ③	03	20



## 2-3-5 Other Control

To accurately detect the outside air temperature, the fan is operated while the outdoor unit is stopped.

## 2-4 EXPANSION VALVE CONTROL

	Initialization conditions	Operation mode	Control range	
			operation	stop
EEV 1	① When power turned on	Cooling	0 pulses	0 pulses
		Heating	55 - 500 pulses	
EEV 2	② When operation stopped	Cooling	55 - 500 pulses	0 pulses
		Heating		

< Cooling mode >  
0 pulses basically.

< Heating mode >

EEV is controlled so that the system reaches closer to the target discharge temperature that is calculated from high and low pressure.

## 2-5 SPECIAL OPERATION

### 2-5-1 Oil Recovery Operation

#### (1) Purpose of the operation

The amount of refrigerant lubricant oil which has been transported to the indoor units and the connection pipe with the refrigerant will become large as the operation time of compressor increases. It is necessary to recover the oil back into the outdoor unit for a certain time interval in order to prevent compressors from damaging due to lack of lubrication oil.

#### ① Simple oil recovery operation < Oil recovery from the gas main pipe > (Only cooling mode)

##### < Start condition >

Suction temperature — low pressure saturation temperature  $\geq 10^{\circ}\text{C}$  continues for 30 minutes

##### < End condition >

Suction temperature — low pressure saturation temperature  $\leq 7^{\circ}\text{C}$

##### < Operation >

Indoor unit : Expansion valve of operating indoor unit gradually opened

Outdoor unit : Normal cooling operation

#### ② Cooling oil recovery operation

##### < Start condition >

Compressor accumulated operation time since last cooling oil recovery operation exceeds 3 hours (first time : 1 hour)

##### < End condition >

30 seconds have elapsed since the start and "suction temperature - low pressure saturation temperature  $\leq 5^{\circ}\text{C}$ " at all outdoor units or 6 minutes have elapsed since the start.

##### < Operation >

COMPRESSOR: Performed by all INV compressors and the constant speed compressors operating up until now  
INV speed varies depending on the operation state.

EEV Opening (Indoor/Outdoor unit): Controlled pulse (as normal operation mode).

FAN speed (Indoor/Outdoor unit) : Controlled fan speed (as normal operation mode).

#### ③ Heating oil recovery operation

##### < Start condition >

Compressor accumulated operation time since the last heating oil recovery exceeds 8 hours (first time : 1 hour)

##### < End condition >

After 4 minutes have elapsed



##### < Operation >

COMPRESSOR: Performed by all INV compressors and the constant speed compressors operating up until now  
INV speed varies depending on the operation state.

EEV Opening (Indoor/Outdoor unit) : Controlled pulse (as normal operation mode)

FAN speed (Indoor/Outdoor unit) : Controlled fan speed (as normal operation mode)

#### Others

During the oil recovery operation,  appears on the display of wired and central remote controller, and  appears on the simple remote controller.

The operation indicators (LED) of the indoor units flash slowly.

## 2-5-2 Pre-heat Operation

This pre-heat operation protects the start up failure by preventing the refrigerant from soaking into the oil in compressor.

Crankcase heater ON: 30 minutes elapsed since installed compressors stopped (However, ON when power turned on)

OFF: Installed compressors operation

\*It doesn't control according to the temperature.

Inverter use: Decided by INV compressor ON-OFF

Constant speed use: Decided by constant speed compressor ON-OFF

## 2-5-3 Defrost Operation Control

### < Defrosting start condition >

Accumulated heating operation time is 40 minutes or longer

[Accumulated heating operation time is reset at the end of cooling operation or defrosting operation.]

and

an outdoor unit satisfies condition ① or ② below

Condition①: "Heat exchange temperature  $\leq -2^{\circ}\text{C}$ " accumulated operating time is 180 minutes or longer  
(75 minutes for indoor unit connection capacity  $\leq 90\%$  at 1 outdoor unit connection)

Condition②: After the following all condition satisfied, "heat exchange temperature  $\leq$  defrosting start judgment temperature and during heat exchange liquid temperature drop" accumulated time:10minutes

(a) accumulated heating operation time  $\geq 30$  minutes

(b) 10 minutes have elapsed after outdoor unit starting

(c) 5 minutes have elapsed since oil recovery

\* Defrosting start and end judgment temperature are determined by the outdoor temperature.

⇒ **Defrosting start judgment temperature =  $0.8 \times \text{outdoor temperature} - 11.6$  (However,  $-27.6^{\circ}\text{C}$  to  $-6^{\circ}\text{C}$ )**

If the calculated result is lower than  $-27.6^{\circ}\text{C}$ , the judgment temperature is defined as  $-27.6^{\circ}\text{C}$

If the calculated result is higher than  $-6^{\circ}\text{C}$ , the judgment temperature is defined as  $-6^{\circ}\text{C}$

### < Defrosting end condition >

① At all outdoor units, heat exchange liquid temperature  $\geq$  end judgment temperature  
or

② when 10 minutes have elapsed from the start  
(When the indoor unit connection capacity is 90% or less, after 15 minutes have elapsed.)

⇒ **Defrosting end judgment temperature =  $0.39 \times \text{outdoor temperature} + 12.7$  (However, 5 to  $12^{\circ}\text{C}$  range)**

If the calculated result is lower than  $5^{\circ}\text{C}$ , the judgment temperature is defined as  $5^{\circ}\text{C}$

If the calculated result is higher than  $12^{\circ}\text{C}$ , the judgment temperature is defined as  $12^{\circ}\text{C}$


## < Operating state of each part during defrosting operation >

Indoor unit EEV : Open FAN : Stop

Outdoor unit FAN : Stop Compressor : In operation


### [ STEP 1 ]

All compressors operates and it defrosting.




### [ STEP 2 ]

Outdoor units which satisfied the defrosting end judgment temperature are stopped for constant speed compressor and are operated at the lowest speed (30rps) for inverter compressor.



### [ STEP 3 ]

When the defrosting of all outdoor units ends, all outdoor unit stop. The start rotation execution is done, and restarts.



## 2-6 PROTECTIVE FUNCTION

### 2-6-1 Protective Function List

Protective Function	Detect Parts	COOL	HEAT	DISPLAY	Operating Condition	Operation
Discharge Temp Protection 1	Discharge Temp Thermistor	○		—	<p>&lt;Starting conditions&gt; 3 minutes have elapsed since the start of operation and (discharge temperature <math>\geq 100^{\circ}\text{C}</math> or suction SH <math>\geq 10^{\circ}\text{C}</math> accumulated time 30 minutes)</p> <p>&lt;Reset conditions&gt; Discharge temperature <math>\leq 95^{\circ}\text{C}</math> and suction <math>\leq 7^{\circ}\text{C}</math></p>	EEV of operating indoor unit gradually opened
Discharge Temp Protection 2	Discharge Temp Thermistor	○	○	—	<p>&lt;Starting conditions&gt; Cooling: Discharge temperature <math>\geq 95^{\circ}\text{C}</math> Heating: Discharge temperature <math>\geq 102^{\circ}\text{C}</math></p> <p>&lt;Reset conditions&gt; Discharge temperature <math>&lt; 90^{\circ}\text{C}</math> Discharge temperature <math>&lt; 97^{\circ}\text{C}</math></p>	EEV2 + 30pls/30 secs
Discharge Temp Protection 3	Discharge Temp Thermistor	○		—	<p>&lt;Starting conditions&gt; Discharge temperature <math>\geq 107^{\circ}\text{C}</math></p> <p>&lt;Reset conditions&gt; Discharge temperature <math>\leq 105^{\circ}\text{C}</math></p>	Outdoor unit rotation execution * After rotation has been executed once; it is executed every 15 minutes.
Discharge Temp Protection 4	Discharge Temp Thermistor	○	○	—	<p>&lt; starting condition&gt; Discharge temperature <math>\geq 105^{\circ}\text{C}</math></p> <p>&lt;Pattern reset condition&gt; Discharge temperature <math>\leq 100^{\circ}\text{C}</math></p>	INV compressor speed -6rps every 30 secs Speed rise prohibited, when discharge temperature becomes lower than $105^{\circ}\text{C}$ , prohibit the rotational speed rise of the compressor.
Discharge Temp Protection 5	Discharge Temp Thermistor		○	—	<p>&lt;Starting conditions&gt; Discharge temperature <math>\geq 95^{\circ}\text{C}</math> and EEV1=500pls</p> <p>&lt;Reset conditions&gt; 2 minutes have elapsed and (discharge temperature <math>\leq 90^{\circ}\text{C}</math> or EEV1 <math>\leq 400</math>pls)</p>	Expansion valve of stopped indoor unit gradually opened (upper limit 200pls)
Discharge Temp Protection 6	Discharge Temp Thermistor		○	—	<p>&lt;Starting conditions&gt; Discharge temperature <math>\geq 90^{\circ}\text{C}</math></p> <p>&lt;Reset conditions&gt; Discharge temperature <math>&lt; 90^{\circ}\text{C}</math></p>	EEV1: Forcefully OPEN
Discharge Temp Protection Stop	Discharge Temp Thermistor	○	○	P1	<p>&lt;Pattern ① starting condition&gt; Discharge temperature <math>\geq</math> fixed value (INV: <math>110^{\circ}\text{C}</math>, constant speed: <math>115^{\circ}\text{C}</math>)</p> <p>&lt;Pattern ① reset condition&gt; 3 minutes have elapsed and discharge temperature <math>\leq 80^{\circ}\text{C}</math></p>	Corresponding compressor stopped
				EA11 (INV)	<p>&lt;Pattern ② starting condition&gt; Pattern ① generated 2 times within 40 minutes</p>	Corresponding compressor stopped (permanent stop) Error display
				EA21 (CONST)	<p>&lt;Pattern ② reset condition&gt; Error reset (push button SW) executed after power turned on again</p>	
High Pressure Protection 1	High Pressure Sensor	○		—	<p>&lt;Starting conditions&gt; High-pressure <math>\geq 3.94\text{MPa}</math></p> <p>&lt;Reset conditions&gt; Fixed time has elapsed and high-pressure <math>\leq 3.70\text{MPa}</math> * Fixed time when SV1: ON 180 secs, when SV2: ON 30 secs</p>	At INV independent operation: SV2 ON At constant speed independent operation: SV1 ON
High Pressure Protection 2	High Pressure Sensor		○	—	<p>&lt;Starting conditions&gt; High-pressure <math>\geq 3.60\text{MPa}</math></p> <p>&lt;Reset conditions&gt; 3 minutes have elapsed and high-pressure <math>\leq 2.80\text{MPa}</math></p>	At INV independent operation: SV2 ON When still insufficient: SV1 ON + SV2 ON  At INV + constant speed operation, constant speed independent operation: SV1 ON
High Pressure Protection 3	High Pressure Sensor	○		—	<p>&lt;Starting conditions&gt; Fixed time has elapsed and high-pressure <math>\geq 3.50\text{MPa}</math> (* Fixed time at start of operation: 10 secs, after operation execution: 20 secs)</p> <p>&lt;Reset conditions&gt; Operation (fan speed 1 step increase) complete</p>	Fan speed 1 step increase
High Pressure Protection 4	High Pressure Sensor		○	—	<p>&lt;Pattern ① starting condition&gt; High-pressure <math>\geq 3.30\text{MPa}</math></p> <p>&lt;Pattern ① reset condition&gt; High-pressure <math>&lt; 3.3\text{MPa}</math></p>	Fan speed lowered/every 30 secs
				—	<p>&lt;Pattern ② starting condition&gt; High-pressure <math>\geq 3.50\text{MPa}</math></p> <p>&lt;Pattern ② reset condition&gt; High-pressure <math>&lt; 3.5\text{MPa}</math></p>	Fan lowest speed (300rpm) fixed
High Pressure Protection 5	High Pressure Sensor		○	—	<p>&lt;Starting conditions&gt; High-pressure <math>\geq 3.20\text{MPa}</math></p> <p>&lt;Reset conditions&gt; High-pressure <math>&lt; 3.20\text{MPa}</math></p>	Compressor capacity lowered/every 15 secs
Abnormal High Pressure Protection Control	High Pressure Sensor	○		—	<p>&lt;Pattern ① starting condition&gt; High-pressure <math>\geq 3.78\text{MPa}</math></p> <p>&lt;Pattern ① reset condition&gt; After 25 seconds have elapsed and high-pressure <math>&lt; 3.70\text{MPa}</math></p>	Compressor capacity rise prohibited
				—	<p>&lt;Pattern ② starting condition&gt; High-pressure <math>\geq 3.90\text{MPa}</math></p> <p>&lt;Pattern ② reset condition&gt; After 25 seconds have elapsed and high-pressure <math>&lt; 3.78\text{MPa}</math></p>	Compressor capacity lowered every 30 secs

Protective Function	Detect Parts	COOL	HEAT	DISPLAY	Operating Condition	Operation
High Pressure Protection Stop 1	High Pressure Sensor	○	○	P2	<Pattern ① starting condition> High-pressure $\geq 4.00\text{MPa}$  <Pattern ① reset condition> 5 minutes have elapsed and high-pressure $\leq 3.50\text{MPa}$	All compressors in outdoor unit stopped
				EA41	<Pattern ② starting condition> Pattern ① generated 3 times within 60 minutes.  <Pattern ② reset condition> 10 minutes have elapsed and high-pressure $\leq 3.50\text{MPa}$	All compressors in outdoor unit stopped Error display
High Pressure Protection Stop 2	Pressure Switch	○	○	P2	<Pattern ① starting condition> Pressure SW operated (Operated by high-pressure $\geq 4.20\text{MPa}$ )  <Pattern ① reset condition> 5 minutes have elapsed and pressure SW operation reset (Reset by high-pressure $\leq 3.2\text{MPa}$ )	Corresponding compressor stopped
				EA42 (INV) EA43 (CONST)	<Pattern ② starting condition> Pattern ① generated 3 times within 60 minutes.  <Pattern ② reset condition> 10 minutes have elapsed and pressure SW operation reset (Reset by high-pressure $\leq 3.2\text{MPa}$ )	Corresponding compressor stopped Error display
Low Pressure Protection 1	Low Pressure Sensor	○		—	<Starting conditions> Low-pressure $\leq 0.20\text{MPa}$  <Reset conditions> 5 minutes have elapsed and low-pressure $\geq 0.30\text{MPa}$	SV1 ON
Low Pressure Protection 2	Low Pressure Sensor		○	—	<Starting conditions> Low-pressure $\leq 0.10\text{MPa}$  <Reset conditions> 3 minutes have elapsed and low-pressure $\geq 0.17\text{MPa}$	SV1 ON
Low Pressure Protection 3	Low Pressure Sensor	○		—	<Starting conditions> One operating outdoor unit and INV compressor operating at 30rps and low-pressure $\leq 0.65\text{MPa}$  <Reset conditions> 5 minutes have elapsed and INV compressor operating at 40rps or faster	SV1 ON
Low Pressure Protection 4	Low Pressure Sensor		○	—	<Starting conditions> 3 minutes have elapsed and low-pressure $\leq 0.18\text{MPa}$  <Reset conditions> 3 minutes have elapsed and low-pressure $\geq 0.22\text{MPa}$	EEV of stopped indoor unit opened quickly (450pls)
Abnormal Low Pressure Protection Control	Low Pressure Sensor		○	—	<starting condition> Low-pressure $\leq 0.16\text{MPa}$ <reset condition> 3 minutes have elapsed and low-pressure $\geq 0.18\text{MPa}$	Compressor capacity lowered every 180 secs, when the Low-pressure becomes more than 0.17MPa, prohibit compressor capacity rise.
Low Pressure Protection Stop	Low Pressure Sensor	○	○	P3	<Pattern ① starting condition> Low-pressure $\leq 0.05\text{MPa}$ or low-pressure $\leq 0.10\text{MPa}$ continues for 10 mins  <Pattern ① reset condition> 3 minutes have elapsed and low-pressure $\geq 0.17\text{MPa}$	All compressors in outdoor unit stopped
				EA51	<Pattern ② starting condition> Pattern ① generated 5 times within 180 minutes.  <Pattern ② reset condition> Error reset (push button SW) executed after power turned on again.	All compressors in outdoor unit stopped (permanent stop) Error display
Compressor Temp Protection Stop	Compressor Temp Thermistor	○	○	P4	<Pattern ① starting condition> Compressor temperature $\geq$ fixed value (INV: $112^{\circ}\text{C}$ , Constant speed: $120^{\circ}\text{C}$ )  <Pattern ① reset condition> 3 minutes have elapsed and discharge temperature $\leq 80^{\circ}\text{C}$	Corresponding compressor stopped
				EA31 (INV) EA32 (CONST)	<Pattern ② starting condition> Pattern ① generated 2 times within 40 minutes  <Pattern ② reset condition> Error reset (push button SW) executed after power turned on again	Corresponding compressor stopped (permanent stop) Error display

Protective Function	Detect Parts	COOL	HEAT	DISPLAY	Operating Condition	Operation
Overcurrent Break Stop (INV compressor)	Overcurrent Protection Circuit	○	○	E941 (permanent stop)	Inverter compressor is stopped when the over current protection circuit in the inverter PC Board detects an abnormal current during the operation. If it repeated 5 times, the inverter compressor becomes permanent stop.	INV compressor stopped
				E931 (permanent stop)	Inverter compressor is stopped when the over current protection circuit in the inverter PC Board detects an abnormal current at the time of start up. Inverter compressor becomes permanent stop if it repeated over the number of set time.	
				—	<Reset condition> Error reset (push button SW) executed after power turned on again.	
Overcurrent Break Stop (Constant speed compressor)	Current Detector Circuit	○	○	—	<Pattern ① starting condition> Constant speed compressor current value $\geq 19.5\text{A}$ continues for 2 secs  <Pattern ① reset condition> 10 minutes have elapsed since compressor was stopped.	Constant speed compressor stopped
				E922	<Pattern ② starting condition> Pattern ① generated 2 times within 60 minutes.  <Pattern ② reset condition> Error reset (push button SW) executed after power turned on again.	Constant speed compressor stopped (permanent stop) Error display
Heatsink Temp Protection Stop	Heatsink Temp Thermistor	○	○	—	<Pattern ① starting condition> Heat sink temperature $\geq 88^{\circ}\text{C}$  <Pattern ① reset condition> 3 minutes have elapsed and heat sink temperature $\leq 75^{\circ}\text{C}$	INV compressor stopped
				EAC4	<Pattern ② starting condition> Pattern ① generated 3 times within 60 minutes.  <Pattern ② reset condition> 10 minutes have elapsed and heat sink temperature $\leq 75^{\circ}\text{C}$	INV compressor stopped Error display
Frequency Maximum Setting Protection (INV compressor)	Current Detector Circuit	○	○	—	<Pattern ① starting condition> Current value $\geq 18.2\text{A}$  <Pattern ① reset condition> Current value $< 18.2\text{A}$	INV compressor speed rise prohibited
				—	<Pattern ② starting condition> Current value $\geq 19.2\text{A}$  <Pattern ② reset condition> Current value $< 19.2\text{A}$  <div>           • Pattern ① and ② start current value changed by outside temperature         </div>	INV compressor speed lowered

# **AIRSTAGE™ V-II**

*Variable Refrigerant Flow System*

## **3. INDOOR UNIT OPERATION**





# 3. INDOOR UNIT OPERATION

## 3-1 FAN CONTROL

### 3-1-1 Fan Speed Setting

Fan speed setting



Press the FAN CONTROL button to set the fan speed.




### 3-1-2 "AUTO" Position

#### 1. COOLING OPERATION


The fan speed is determined automatically in accordance with the condition " $(T_R(\text{corrected room temperature}) - T_s(\text{corrected set temperature}))$ " as shown on the right. However, the fan speed zone is determined in the manner as the room temperature increases for the following cases.

- (1) When the  $T_s$  is changed.
- (2) When the operation mode is changed from other mode to "COOL".
- (3) When the fan control is changed from other position to "AUTO".



#### 2. HEAT OPERATION

Same as Cooling operation, fan speed is decided by the difference between the room temperature and the set temperature.



#### 3. DRY OPERATION

The indoor fan always rotates at "Lo" speed.



- (1) The indoor fan starts operation 5 seconds after the electric expansion valve opens. However, when the indoor unit just starts its operation or the operation mode is changed from other to "DRY" and the refrigerant circulation is not stopped, the fan will rotate immediately without a delay time of 5 seconds.
- (2) The indoor fan will stop in 30 seconds when the refrigerant circulation stops.
- (3) The indoor fan will stop immediately when the indoor unit is stopped by pushing the stop button or by a setting of ON timer.
- (4) When the refrigerant circulation is stopped due to a lower room temperature for more than 3 minutes, the fan will rotate 2 minutes at intervals of 3 minutes.
- (5) When the indoor unit just starts its operation or the operation mode is changed from other to "DRY" and the refrigerant circulation is stopped, the fan will rotate for 1 minute and then it will operate according to the statement (4).

## 3-2 MASTER CONTROL

### 3-2-1 Operation Mode Control

Each operation mode is controlled as below.

(1) Stop mode

Indoor fan motor : OFF  
Electric expansion valve : Stop pulse  
Drain pump : Turns ON-OFF by the drain pump control function

(2) Cool, Dry and Heat Mode

	Cool	Dry	Heat
Indoor fan motor	Operates according to the AIR FLOW-MODE setting.	See the fan control page.	Operates according to the AIR FLOW-MODE setting, and besides cold air prevention operation
Drain pump	Turns ON-OFF by the drain pump control function		
Electrical expansion valve	Pulse controlled by the temperature difference calculation and frost prevent fuction	Pulse controlled by the temperature difference calculation and frost prevent function	Pulse controlled by the temperature difference.

(3) Priority mode


The purpose of the priority mode is to restrict operation commands (heating, cooling, dry) from the connected indoor units. There are 3 priority modes of Neutral, Cooling Priority, and Heating Priority. The operation modes restricted by each of these modes are as follows:

Priority mode	Restricted operation mode
Neutral	No restrictions
Cooling priority	Heating
Heating priority	Cooling, dry

1. Priority mode decision methods

Method 1. (Default value)


The initial priority mode is made Neutral and is shifted to Cooling Priority when cooling and to Heating Priority when heating depending on which operation mode (cooling, heating) was input first. After shifting to Cooling Priority or Heating Priority, the priority mode shifts to Neutral only when there was a Stop input from all the indoor units.



Method 2. (Management by outdoor unit)

Operation mode management is made "Management by outdoor unit" by outdoor unit PUSH-SW (field setting).

The priority mode shifts to Cooling Priority or Heating Priority in accordance with input from the outdoor unit regardless of the current mode.



### Method 3. (Management by indoor unit)


Operation mode management is made "Management by indoor unit" by outdoor unit PUSH-SW (field setting).

Then the master indoor unit is set by wired remote controller.

Thereupon the priority mode shifts to Cooling Priority or Heating Priority in accordance with input from the master indoor unit regardless of the current priority mode.

The priority mode is fixed at either cooling or heating even if the master indoor unit stops

Cooling/heating switching can be performed by the master indoor unit only.



### (4) Opposite operation mode

When the operation mode commanded from an indoor unit (remote controller) and the operation mode allowed by the system (cooling and dry operation for cooling only type and operation mode allowed by priority mode for heat pump type) do not match, it is indicated by blinking of an LED.

Timer lamp: 3 secs ON/1 sec OFF repeated


## 3-2-2 Auto Changeover

[Method]

1. Switch operation mode management to "Management by indoor unit" by outdoor unit DIP-SW.
2. Set the master indoor unit by wired remote controller.
3. Judge cooling/heating by the difference between the master indoor unit's setting temperature and the room temperature.

### ■ AUTO CHANGEOVER operation


Operation flow chart



### 3-2-3 "COOL" Position

When using the cooling mode, set the temperature to a value lower than the current room temperature, otherwise the indoor unit will not start the cooling operation and only the fan will rotate.


An example for COOLING TEMPERATURE CONTROL time chart (Manual setting)



### 3-2-4 "HEAT" Position

- (1) When using the heating mode, set the temperature to a value higher than the current room temperature, otherwise the indoor unit will not start the heating operation.
- (2) After the start of heating operation, the fan of indoor unit will not rotate until the heater exchange is warmed up to blow out warm air.
- (3) During defrosting, the OPERATION indicator lamp flashes 6 sec. ON and 2 sec. OFF, and repeat. The heating operation will be temporarily interrupted.

An example for HEATING TEMPERATURE CONTROL time chart (Manual setting)



### 3-3 LOUVER CONTROL


### (1) ADJUSTING THE DIRECTION OF AIR CIRCULATION

**Instructions relating to heating (\*) are applicable only to heat pump type outdoor unit.**

Begin air conditioner operation before performing this procedure.

## Vertical Air Direction Adjustment

This instructions are applicable to "LARGE CEILING TYPE",  
"UNIVERSAL FLOOR/CEILING TYPE", "CASSETTE TYPE",  
"WALL MOUNTED TYPE" and "COMPACT WALL MOUNTED TYPE".



**Example :** When set to vertical air direction.


**Press the VERTICAL AIR FLOW DIRECTION SET button.**

- Press the VERTICAL AIRFLOW DIRECTION button.  
The temperature display will change to the vertical airflow direction setting display.
- Press the VERTICAL AIRFLOW DIRECTION button to change the vertical louvre position.  
The position number will appear on the display.


Cooling & Dry : ①, ②, ③, ④

Heating : ①, ②, ③, ④


## ■ LARGE CEILING TYPE




### ■ UNIVERSAL FLOOR/CEILING TYPE




■ CASSETTE TYPE



### ■ WALL MOUNTED TYPE



### ■ COMPACT WALL MOUNTED TYPE



**⚠ DANGER!**

Never place fingers or foreign objects inside the outlet ports, since the internal fan operates at high speed and could cause personal injury.

- Always use the remote control unit's AIR FLOW DIRECTION button to adjust the UP/DOWN air direction flaps or RIGHT/LEFT air direction louvers. Attempting to move them manually could result in improper operation; in this case, stop operation and restart. The louvers should begin to operate properly again.
- When used in a room with infants, children, elderly or sick persons, the air direction and room temperature should be considered carefully when making settings.

- Use the air direction adjustments within the ranges shown above.
- The vertical airflow direction is set automatically as shown, in accordance with the type of operation selected.
  - During Cooling mode : Horizontal flow ①
  - \* During Heating mode : Downward flow ④
- During AUTO mode operation, for the first minute after beginning operation, airflow will be horizontal ①, the air direction cannot be adjusted during this period.

## Horizontal Air Direction Adjustment


This instructions are applicable to "LARGE CEILING TYPE", "UNIVERSAL FLOOR/CEILING TYPE" and "WALL MOUNTED TYPE".

**Press the HORIZONTAL AIR FLOW DIRECTION SET button.**

- Press the HORIZONTAL AIRFLOW DIRECTION button. The temperature display will change to the horizontal airflow direction setting display.
- Press the HORIZONTAL AIRFLOW DIRECTION button to change the horizontal louvre position. The position number will appear on the display.


Cooling & Dry : ①, ②, ③, ④, ⑤

Heating : ①, ②, ③, ④, ⑤




**Example :** When set to horizontal air direction.


### ■ LARGE CEILING TYPE



### ■ WALL MOUNTED TYPE



### ■ UNIVERSAL FLOOR/CEILING TYPE



## (2) SWING OPERATION

Instructions are applicable to "LARGE CEILING TYPE", "UNIVERSAL FLOOR / CEILING TYPE", "CASSETTE TYPE", "WALL MOUNTED TYPE" and "COMPACT WALL MOUNTED TYPE".


Begin air conditioner operation before performing this procedure.

### To select Vertical airflow SWING Operation

This instructions are applicable to "LARGE CEILING TYPE", "UNIVERSAL FLOOR/CEILING TYPE", "CASSETTE TYPE", "WALL MOUNTED TYPE" and "COMPACT WALL MOUNTED TYPE".

**Press the VERTICAL SWING button for more than two seconds.**

The remote controller's Vertical Swing Display will light up.  
In this mode, the UP/DOWN air direction flaps will swing automatically to direct the air flow both up and down.



**Example :** When set to vertical swing.

### To Stop Vertical airflow SWING Operation

**Press the VERTICAL SWING button for more than two seconds once and again.**

The remote controller's Vertical Swing Display will go out.  
Airflow direction will return to the setting before swing was begun.



Instructions are applicable to "LARGE CEILING TYPE",  
 "UNIVERSAL FLOOR / CEILING TYPE", "CASSETTE TYPE",  
 "WALL MOUNTED TYPE", and "COMPACT WALL MOUNTED TYPE".

### About Vertical Airflow SWING Operation

- The SWING operation may stop temporarily when the air conditioner's fan is not operating, or when operating at very low speeds.
- The swing operation is not available depending on the model. Please refer to the operating manual for the indoor unit.

Air swing range


Air flow direction set	Range of swing
①	① to ④ (All range)
②	
③	
④	

### To select Horizontal Airflow SWING Operation

This instructions are applicable to "LARGE CEILING TYPE",  
 "UNIVERSAL FLOOR / CEILING TYPE", "WALL MOUNTED TYPE".

**Press the HORIZONTAL SWING button for more than two seconds.**

The remote controller's Horizontal Swing Display will light up.  
 In this mode, the RIGHT/LEFT air direction louvers will swing automatically to direct the airflow both right and left.



**Example :** When set to horizontal swing.

### To stop Horizontal airflow SWING Operation

**Press the HORIZONTAL SWING button for more than two seconds once and again.**

The remote controller's Horizontal Swing Display will go out.  
 Airflow direction will return to the setting before swing was begun.

### About Horizontal Airflow Swing Operation

- Left and right swing range can be changed in 3 steps by field setting.
- The SWING operation may stop temporarily when the air conditioner's fan is not operating, or when operating at very low speeds.
- The swing operation is not available depending on the model. Please refer to the operating manual for the indoor unit.

Left and right swing range (◆ ... Factory setting)

Range of swing	Function Number	Setting Value
◆ ① to ⑤ (All range)	24	00
① to ③		01
③ to ⑤		02

## 3-4 ELECTRONIC EXPANSION VALVE CONTROL

### 1. Initialization

- When the power is turned ON.
- When it has passed the limited time since the last initialization.

### 2. Operation Control

- When indoor unit stopping

Outdoor unit Condition	EEV Condition
OFF	Fully closed
Cooling	Fully closed
Heating	Slightly open

- When starting up  
(Cooling) Move to the cooling control base pulse in steps.  
(Heating) Move to the heating control base pulse in steps.
- Automatic operatic control  
Automatic PI control is performed based on the indoor unit heat exchanger outlet temp and inlet temp.
- Room temperature control  
The room temperature is controlled so that it reaches to the set-up temperature based on the difference between the room temperature and the set-up temperature, and the change of indoor unit temperature. if the room temperature becomes 0.5°C lower than the set-up temperature, EEV is fully closed.

### 3. Special Control

- Oil recovery operation : Controlled pulse.
- Test run operation : Controlled pulse.
- Icing protection control : Fully closed.
- Pump down operation : Fully open.
- Defrost operation : Controlled pulse

## 3-5 DRAIN PUMP OPERATION

- (1) When cooling and refrigerant circulation starts, the drain pump starts simultaneously.
- (2) The drain pump operates continuously for 3 minutes after the refrigerant circulation stopped.
- (3) When the refrigent circulation is stopped by a start of indoor heat exchanger frost prevention operation, the drain pump will turn off in 1 hour after the end of indoor heat exchanger frost prevention operation.
- (4) When the water level in the drain pan rises up and then the float switch functions:
  - ① Microcomputer stops the refrigerant circulation and indoor fan motor operation.
  - ② Drain pump operates continuously for 3 minutes after the float switch is turned off.  
(Almost condensing water may be drained)
- (5) When the float switch turns ON continuously for 3 minutes, 'FAILURE INDICATION' operates.
- (6) When the float switch turns OFF within 3 minutes, the unit starts cooling operation.

## 3-6 FUNCTION

### 3-6-1 Auto Restart

The air conditioner restarts with the previous setting operation.

### 3-6-2 Icing Protection Control

The icing of the indoor heat exchanger is prevented during the cooling and dry mode operation.

(1) Starting Condition

- Compressor is operation more than 3 minutes.  
When "Heat exchanger inlet temperature  $\leq T_A$ " continues \*4 minutes or more.
- Compressor is operation more than 3 minutes.  
When "Heat exchanger outlet temperature  $\leq T_A$ " continues 4 minutes or more.

(2) Operation

EEV is closed.  
Fan is at the setting amount.

(3) Completing Condition

Heat exchanger inlet and middle temperature  $\geq T_B$   
After more than 5 minutes


\* Drain pump turns off at 60 minutes past the completion of the icing protection operation.

$T_A$	$T_B$
1°C	7°C

### 3-6-3 Oil Recovery Operation

[Oil recovery operation] : It periodically returns the residual refrigerant ion oil in the indoor unit and the connection piping back to the outdoor unit , and prevents the compressor oil level from decreasing.

Indoor unit LED : Operation LED



Indoor fan : Same operation before oil recovery operation.

Indoor EEV : Control pulse

\* During the above operation, a refrigerant noise may be from the indoor unit.

## 3-7 TIMER CONTROL

### 3-7-1 Wireless Remote Controller

UTY - LNH\*

There are following 4 kinds of timer modes are available.




- ON Timer
- OFF Timer
- PROGRAM Timer
- SLEEP Timer

#### 1. ON / OFF TIMER

The timer functions cannot be used when this controller is used together with the remote controller (Wired type).  
A beeping sound is made when a signal is received.

##### To set the ON / OFF timer







Press the START/ STOP button to start the air conditioner, and then proceed as follows.

<p><b>1</b>  Press the <b>TIMER MODE</b> button to select "OFF TIMER" or "ON TIMER"</p> <p>→ CANCEL → OFF TIMER → ON TIMER → PROGRAM TIMER (OFF ← ON, OFF → ON) →</p>	<p><b>2</b>   Adjust the OFF or ON time. (About 5 seconds later, the entire display will reappear.)</p>
--	---

#### 2. PROGRAM TIMER

##### To set the PROGRAM timer

Press the START/ STOP button to start the air conditioner, and then proceed as follows.

<p><b>1</b>  Select "OFF TIMER"</p>	<p><b>2</b>  Adjust the OFF time.</p>	<p><b>3</b>  Select "ON TIMER"</p>
<p><b>4</b> Adjust the ON time. (About 5 seconds later, the entire display will reappear.)</p> <p></p>	<p><b>5</b>   Select "PROGRAM TIMER" (Either OFF → ON or OFF ← ON will display.) (If the ON timer has been selected to operate first, the unit will stop operating at this point.)</p>	

##### To cancel the TIMER

 Select "CANCEL".  
The air conditioner will return to normal operation.

##### \*To change operating conditions

If you wish to change the operating conditions (ON/OFF, Mode, Fan Speed, Temperature Setting), after making the time setting, wait until the entire display reappears, then press the appropriate buttons to change to the desired operating condition.

\* Even ON/OFF and Sleep timer are valid.

#### 3. SLEEP TIMER

##### To set the SLEEP timer


Unlike other timer functions, the SLEEP timer is designed to set the duration of time in which the unit does not operate. The SLEEP timer can be set regardless of whether the indoor unit is operating or stopped.

<p><b>1</b>  (Both the indoor unit's OPERATION indicator lamp (green) and the TIMER indicator lamp (orange) will light.)</p>	<p><b>2</b>   Adjust the OFF time. (About 5 seconds later, the entire display will reappear.)</p>
---	---

##### To change the timer settings

<p><b>1</b>  Press the SLEEP button once again.</p>	<p><b>2</b>  Set the time using the TIMER SET buttons.</p>
--	---

##### \*To cancel the TIMER

 Select "CANCEL".  
The air conditioner will return to normal operation.

##### \*To stop air conditioner operation during timer operating




\* Even ON/OFF and Program timer are valid.

- Sleep timer

The sleep timer function automatically corrects the temperature thermostat setting according to the time setting to prevent excessive cooling and heating while sleeping.


#### Cooling operation / dry operation

When the sleep timer is set, the set temperature automatically rises  $1^{\circ}\text{C}$  every hour. The set temperature can rise up to a maximum of  $2^{\circ}\text{C}$



#### Heating operation

When the sleep timer is set, the set temperature automatically drops  $1^{\circ}\text{C}$  every 30 minutes. The set temperature can drop to a maximum of  $4^{\circ}\text{C}$



## 3-7-2 Group Remote Controller

UTY - CGG \*

Different schedules can be set for each day of the week.

• WEEKLY TIMER

Four timers can be set for each day

### 1. WEEKLY TIMER

The timer function is not available depending on the initial setting.




- Different schedules can be set for each day of the week.
- Four timers can be set for each day.
- Operation on/off time, operation mode, and temperature can be specified for each timer.

#### To start / cancel the WEEKLY timer operation


The timer does not start if the time is not set.

ALL


Press the ALL TIMER button to start or cancel the WEEKLY timers for all indoor units.





- If any of the indoor units are in the timer mode, pressing this button cancels the timers for all indoor units.
- If none of the indoor units are in the timer mode, pressing this button starts the timers for all indoor units.



Press the Select button to select the indoor unit.




Press the Timer Mode (DELETE) button to start or cancel the WEEKLY timers.




Note: When a time is not set, the weekly timer cannot be started.

#### To set the WEEKLY timer




Press the PROGRAM (CLOCK ADJUST) button.

\* Do not press this button for two seconds or more, otherwise you will enter the time setting mode.




Press the Select button to select the indoor unit.

\* If all indoor units are selected, the times for all of the registered indoor unit timers are set at once.





3

#### Day of the week setting



Press the DAY button to select the day of the week.


\* For ALL, all of the days can be set together when a appears around each day.



4

#### Timer setting

Decrement Increment






Press the Set Time buttons to set the time in 10-minute increments.

\* Hold down a Set Time button to adjust the time quickly.

\* The time already set at another timer is skipped at the relevant indoor unit.

# 5


## ● Operating setting



Press the Start/Stop button or the Mode button or the Set Temperature button to set the operation.

\* For the operations that can be set, refer to "Operation mode setting", "Room temperature setting", and "To start /stop operation", in "OPERATION".


\* Only the current operation settings are displayed.



ex. TIMER-1 will start operation at 8:00 on COOL.

# 6

## ● Setting the next timer for the same day:



Then press the ENTER button to proceed to the time setting, and repeat steps from **4** to **5**.

● Repeat steps **3** to **5** to set the timer for another day of the week.

※ Be careful for pressing the ENTER button without any operation setting because the time that is set will be cancelled.

# 7

## ● Setting the timer for the other indoor units:




Before setting the timer for other indoor units, press the ENTER button to confirm the settings.

\* The display switches to the next timer.

● Repeat steps **2** to **6** to set the timer for other indoor units.


# 8



1. Press the ENTER button to confirm the set timer.
2. Press again the PROGRAM (CLOCK ADJUST) button to complete the weekly timer setting.



\* flashes for two seconds.

When the operating time is set, the mark appears.



ex. TIMER-1 will start operation at 8:00 on COOL with a setting of 20°C

## ● To delete the operating time



1. If the Timer Mode (DELETE) button is pressed during steps **3** to **7**, the operating time for the selected day will be deleted.

\* If all the days are selected, the operating times for all of the days of the selected timer will be deleted.

2. Press the ENTER button to confirm the deletion.

## 1 NOTES

- (1) The WEEKLY timer does not operate when the HEAT timer is set if a HEAT PUMP MODEL in the air conditioning system is operating in the cooling mode. In addition, the WEEKLY timer does not operate when the COOL or DRY timer is set if a HEAT PUMP MODEL in the air conditioning system is operating in the heating mode.
- (2) Even if the timer operation is set, the timer lamp of the indoor unit does not light up. (The timer lamp is used for wireless remote controller only.)
- (3) If the same time is set in Timer-1 to Timer-4 of an indoor unit, the timer setting of the smallest number will be effective.

### 3-7-3 Wired Remote Controller


UTY - RNK \*





- ON / OFF TIMER
- WEEKLY TIMER
- TEMPERATURE SET BACK TIMER


#### 1. ON / OFF TIMER


The timer function is not available depending on the model.

**To set the ON/OFF timer**

**1**  
  
CLOCK ADJUS  
Press the timer mode button to select the ON timer or OFF timer. It is switched every time as shown in the below diagram when the button is pressed.

  
No display →  →  →   
NON STOP    OFF TIMER    ON TIMER    WEEKLY TIMER

**2**  
  
From 1 to 24 hours  
Press the set time buttons to set the time. After the time is set, the timer will start automatically. The amount of time until the OFF timer operates that is displayed on the timer display decreases as time passes.

  
ex. OFF timer set for 6 hours

● To cancel

  
TIMER DELETE


- Press the DELETE button to cancel the timer mode.
- The timer mode can also be canceled by changing the timer mode using the timer mode button.





## 2. WEEKLY TIMER

The timer function is not available depending on the model.

### Weekly timer setting




Press the timer mode button to select the weekly timer.






Press the SET button for 2 seconds or more.

### **3** • Day of the week setting






Press the DAY button to select the day of the week, and then press the TIMER SET button to confirm the setting.


\* For ALL, all of the days can be set together when a  appears around each day.



### **4** • Time setting (ON / OFF timer)



When the operating time is set, the  mark appears.




ex. The timer is set for 7:00-18:00.

Press the SET TIME buttons to set the ON time in 30-minute increments, then press the TIMER SET button to proceed to the OFF time setting. Set the OFF time in the same way.




If necessary, set the second weekly timer settings in the same way.

### • Time setting (Independent OFF timer)

Switching from ON/OFF timer to independent OFF timer



The independent timer will flash on the display.



Press the TIMER MODE button to change to the independent OFF timer setting.


\* The time setting process is the same as the ON/OFF timer.

Press the TIMER MODE button to return to the ON/OFF timer setting.

**5**

Repeat steps **3** and **4** to set the weekly timer for another day of the week.

**6**



Press the TIMER SET button for 2 seconds or more to complete the weekly timer settings.


### • To delete the operating time



If the TIMER DELETE button is pressed during steps **3** or **4**, the operating time for the selected day will be deleted. If all the days are selected, the operating times for all of the days will be deleted.


## To start /cancel the WEEKLY timer operation

### ● To start



The independent timer will flash on the display.

When the weekly timer is selected, the timer starts automatically.




ex. Operating time 7:00-18:00  
Indpnd. OFF time 21:00

The operating time for the current day is displayed.

### ● To cancel

TIMER DELETE



- Press the TIMER DELETE button to cancel the timer mode.
- The timer mode can also be canceled by changing the timer mode using the TIMER MODE button.

## NOTES

### (1) PRECAUTIONS DURING WEEKLY TIMER SETUP

Setup is not possible in the following cases, so amend the time.

- Be sure to set the ON time first, then the OFF time. If either the ON time or the OFF time is not set correctly, the timer will not operate properly.
- The WEEKLY 2 settings cannot be set earlier than the WEEKLY 1 settings.
- The WEEKLY 1 and WEEKLY 2 time spans cannot overlap.

(2) The earliest OFF time you can set is 30 minutes after the ON time.

(3) The OFF time can be carried over to the next day.

(4) The earliest independent OFF time you can set is 30 minutes after the last OFF time.


(5) An independent OFF time can be set up to 0:00 hours of the next day.

(6) Even if the timer operation is set, the timer indicator lamp of the indoor unit does not light up. (The timer indicator lamp is used for wireless remote controllers only.)

## To set the DAY OFF (for a holiday)

1

TIMER SET



During the weekly timer, press the TIMER SET button for 2 seconds or more to set the day.

2

DAY



Select the day to set the DAY OFF.

3


DAY





Press the DAY (DAY OFF) button for 2 seconds or more to set the DAY OFF.

4

TIMER SET



Press the TIMER SET button for 2 seconds or more to complete the DAY OFF setting.



Flashing mark:  
indicates the DAY OFF.

ex. The DAY OFF is set for Monday.


### ● To cancel

Follow the same procedures as those for setup.


## NOTES

- The DAY OFF setting is only available for days for which weekly settings already exist.
- If the operating time carries over to the next day (during a next day setting), the effective DAY OFF range will be set as shown below.

### ● Normal



### ● Next day setting




- The DAY OFF setting can only be set one time.  
The DAY OFF setting is cancelled automatically after the set day has passed.

### 3. TEMPERATURE SET BACK TIMER


The timer function is not available depending on the model.

#### Temperature SET BACK timer setting

**1**  SET BACK



If there is no existing SET BACK temperature setting, " - - " will be displayed for the temperature.

**2**  TIMER SET

Press the SET button for 2 seconds or more.




Press the SET BACK button to change to the SET BACK confirmation display.

The SET BACK operating time and the set temperature will be displayed.


**3** • Day setting

DAY  
DAY OFF

TIMER SET

TIMER SET





ex. When setting all days together


Follow step **3** and **4** in "To set the WEEKLY timer". The DELETE button is also used as described in the procedures for the weekly timer.


**4** • Temperature setting

Press the set temperature buttons to set the temperature. (The temperature setting range is the same as the range for the operation mode.)



ex. Operating time 15:00 - 22:00





**5**  TIMER SET

Repeat steps **3** and **4**. Press the SET button for 2 seconds or more to complete the temperature SET BACK timer settings.

#### To start /cancel the temperature SET BACK timer operation

##### • To start

 SET BACK




ex. Display during SET BACK timer operation  
(The operating time will not be displayed.)

Press the SET BACK button. The SET BACK confirmation display appears for 5 seconds, and then the timer starts automatically.

##### • To cancel

 SET BACK

TIMER DELETE



Press the SET BACK button, and then press the DELETE button while the SET BACK confirmation display is displayed. Even if the SET BACK button is pressed again, the SET BACK timer will be cancelled.

#### **i** NOTES

- The SET BACK timer only changes the set temperature, it cannot be used to start or stop air conditioner operation.
- The SET BACK timer can be set to operate up to two times per day but only one temperature setting can be used.
- The SET BACK timer can be used together with the ON, OFF, and weekly timer functions.
- The SET BACK operating time is displayed only in the SET BACK confirmation display.  
(Refer to step 1 for the SET BACK confirmation display.)
- During the COOL/DRY mode, the air conditioner will operate at a minimum of 18°C even if the SET BACK temperature is set to 17°C or lower.
- Room temperatures as low as 10, 12, and 14°C cannot be set depending on the model.

# **AIRSTAGE™ V-II**

*Variable Refrigerant Flow System*








## **4. TROUBLE SHOOTING**





















## 4. TROUBLESHOOTING



### 4-1 NORMAL OPERATION

#### 4-1-1 Indoor Unit Display

Indication type	Indication Lamp	Flashing Pattern
Operation	Operation LED	Continuous lighting
Anti Freeze		Continuous lighting(lowered light)
Timer	Timer LED	Continuous lighting(lowered light)
Filter	Filter LED	Continuous lighting
Power Failure	Operation LED	ON  OFF
	Timer LED	ON  OFF
Test Operation	Operation LED	ON  OFF
	Timer LED	ON  OFF
Defrosting	Operation LED	ON  OFF
Oil Recovery		
Opposite Operation Mode	Timer LED	ON  OFF
Maintenance Mode	Operation LED	ON  OFF
	Timer LED	
	Filter LED	

## 4-1-2 OUTDOOR UNIT DISPLAY

Indication type	7 Segment LED Pattern	Description
Idling(stop)	 Blank	
Cooling Mode	 "C" OO "L"	
Heating Mode	 "H" EA "T"	
Oil Recovery Operation	 "O" IL "R" ECOVERY	Refer to 02-10 page for operation.
Defrost Operation	 "D" E "F" ROST	Refer to 02-11 page for operation.
Discharge Temp. Protection is stopped	 "P" ROTECT "1"	<Starting condition> Discharge temp $\geq$ fixed value (INV:110°C, constant speed:115°C) <Release condition> 3 minutes have elapsed and discharge temperature $\leq$ 80°C
High Pressure Protection is stopped	 "P" ROTECT "2"	<Starting condition> High pressure $\geq$ 4.00MPa <Release condition> 5 minutes have elapsed and high pressure $\leq$ 3.50MPa
Low Pressure Protection is stopped	 "P" ROTECT "3"	<Starting condition> Low pressure $\leq$ 0.05MPa or low pressure $\leq$ 0.10MPa continues for 10 mins <Release condition> 3 minutes have elapsed and low pressure $\geq$ 0.17MPa
Compressor Temperature Protection is stopped	 "P" ROTECT "4"	<Starting condition> Compressor temp $\geq$ fixed value (INV:112°C, Constant speed:120°C) <Release condition> 3 minutes have elapsed and discharge temperature $\leq$ 80°C
Peak Cut Mode	 "P" eak "C" ut	
Low Noise Mode	 "L" OW "N" OISE	Refer to 02-08 page for operation.
Snow Falling Protection Fan mode	 "SN" OW	Refer to 02-09 page for operation.
Inverter Compressor Operation Indication	 Blinking	ON  OFF
Constant Speed Compressor Operation Indication	 Blinking	ON  OFF
Inverter Compressor and Constant Speed Compressor Operation Indication	 Blinking	ON  OFF



## 4-2 ABNORMAL OPERATION

### 4-2-1 Indoor Unit Display


Please refer the flashing pattern as follows.

Error Contents	Operation LED	Timer LED	Filter LED	Trouble shooting
Remote Controller Communication Error	1 times flash	2 times flash	Continuous flash	9,10
Network Communication Error	1 times flash	4 times flash	Continuous flash	12
Indoor Unit Parallel Communication Error	1 times flash	6 times flash	Continuous flash	11
Indoor Unit Power Frequency Abnormal	3 times flash	1 times flash	Continuous flash	2
Indoor Unit Main PCB Error	3 times flash	2 times flash	Continuous flash	1,3
Room Temperature Sensor Error	4 times flash	1 times flash	Continuous flash	4
Indoor Unit Heat Ex. Sensor Error	4 times flash	2 times flash	Continuous flash	5,6
Indoor Unit Fan Motor Error	5 times flash	1 times flash	Continuous flash	8
Water Drain Abnormal	5 times flash	3 times flash	Continuous flash	7
Outdoor Unit Error	9 times flash	15 times flash	Continuous flash	13 ~ 62

Depending on contents of Outdoor unit, it may not indicate. (Refer to "TROUBLE LEVEL OF SYSTEM")

#### Error Indication Flashing Pattern


Example : Indoor Unit Main PCB Error (Operation LED : 3 times, Timer LED : 2 times)






## 4-2-2 Outdoor Unit Display


### LED display



**POWER MODE LED : on**  
**ERROR LED : blink**




### Operation button



### ERROR transition

Short press : less than 3 seconds

Long press : more than 3 seconds



If some error is newly occurred or resolved during transition, it is reflected after going back to "Annunciation".

\* Only in the case of "indoor unit abnormal (E.5U.1)", indoor unit address is shown by ENTER long press.

## 4-2-3 Error Code List for Outdoor Unit

Error Code	Error Contents	Trouble shooting
- - - -	Initial Setting Error	13
1 3 . 1	Communication Error Between Outdoor Unit	14
1 4 . 1	Outdoor Unit Network communication 1 Error	15
1 4 . 2	Outdoor Unit Network communication 2 Error	16
2 8 . 1	Auto Address Setting Error	61
2 8 . 4	Signal Amplifier Auto Address Setting Error	62
5 U . 1	Indoor Unit Error	1 ~ 12
6 1 . 5	Outdoor Unit Reverse Phase, Missing Phase Wire Error	17
6 2 . 3	Outdoor Unit EEPROM Access Error	18
6 2 . 6	Inverter Communication Error	19
6 2 . 8	Outdoor Unit EEPROM Data Error	20
6 3 . 1	Inverter Error	21
6 7 . 2	Inverter PCB Momentary Power Failure Detection	22
6 8 . 1	Magnetic Relay Error	23
6 8 . 2	Rush Current Limiting Resistor Temp Rise Protection	24
6 9 . 1	Outdoor Unit Communication PCB Parallel Communication Error	25
7 1 . 1	Discharge Temp Sensor 1 Error	26
7 1 . 2	Discharge Temp Sensor 2 Error	27
7 2 . 1	Compressor Temp Sensor 1 Error	28
7 2 . 2	Compressor Temp Sensor 2 Error	29
7 3 . 3	Outdoor Unit Heat Ex. Liquid Temp. Sensor Error	30
7 4 . 1	Outdoor Temp Sensor Error	31
7 5 . 1	Suction Gas Temp Sensor Error	32
7 7 . 1	Heat Sink Temp Sensor Error	33
8 2 . 1	Sub-cool Heat Ex. Gas Inlet Temp. Sensor Error	34
8 2 . 2	Sub-cool Heat Ex. Gas Outlet Temp. Sensor Error	35
8 3 . 1	Liquid Pipe Temp. Sensor 1 Error	36
8 3 . 2	Liquid Pipe Temp. Sensor 2 Error	37
8 4 . 1	Current Sensor 1 Error	38
8 6 . 1	Discharge Pressure Sensor Error	39


Error Code	Error Contents	Trouble shooting
8 6 . 3	Suction Pressure Sensor Error	40
8 6 . 4	High Pressure Switch 1 Error	41
8 6 . 5	High Pressure Switch 2 Error	42
9 2 . 1	Compressor 2 Error	43
9 2 . 2	Compressor 2 Current Value Error	44
9 3 . 1	Inverter Compressor Start Up Error	45
9 4 . 1	Trip Detection	46
9 5 . 5	Compressor Motor Loss of Synchronization	47
9 7 . 1	Outdoor Unit Fan Motor Lock Error	48
9 7 . 4	Outdoor Unit Fan Motor Undervoltage	49
9 7 . 5	Outdoor Unit Fan Motor Temperature Abnormal	50
9 U . 2	Slave Unit Error	51
A 1 . 1	Discharge Temperature 1 Abnormal	52
A 2 . 1	Discharge Temperature 2 Abnormal	53
A 3 . 1	Compressor 1 Temperature Abnormal	54
A 3 . 2	Compressor 2 Temperature Abnormal	55
A 4 . 1	High Pressure Abnormal	56
A 4 . 2	High Pressure Protection 1	57
A 4 . 3	High Pressure Protection 2	58
A 5 . 1	Low Pressure Abnormal	59
A C . 4	Heat Sink Temperature Abnormal	60

## 4-2-4 Remote Controller Display

### << SIMPLE REMOTE CONTROLLER >>

#### ERROR CODE DISPLAY


If an error occurs, the following display will be shown.  
 ("Er" will appear in the set room temperature display.)  
 If "Er" is displayed, immediately contact authorized service personnel.



### << WIRED REMOTE CONTROLLER >>

#### ERROR CODE DISPLAY

If an error occurs, the following display will be shown.  
 ("Er" will appear in the set room temperature display.)  
 If "Er" is displayed, immediately contact authorized service personnel.




### << GROUP REMOTE CONTROLLER >>

#### ERROR CODE DISPLAY

The air conditioning system must be inspected if "E" : " (error code) appears on the timer and Clock Display, or the operation lamp is flashing.

\*1 ; Model code  
 □ : Outdoor unit  
 I : Indoor unit  
 E : Group remote controller  
 R : Convertor



## 4-2-5 Error Code List for Simple and Wired Remote Controller

Error Code	Error Contents	Trouble shooting
1 2	Remote Controller Communication Error	9, 10, 97
1 4	Network Communication Error	12
1 5	Scan Error	98
1 6	Indoor Unit Parallel Communication Error	11
3 1	Indoor Unit Power Frequency Abnormal	2
3 2	Indoor Unit Main PCB Error	1, 3

Error Code	Error Contents	Trouble shooting
4 1	Room Temperature Sensor Error	4
4 2	Indoor Unit Heat Ex. Sensor Error	5, 6
5 1	Indoor Unit Fan Motor Error	8
5 3	Water Drain Abnormal	7
9 U	Outdoor Unit Error	14 ~ 62

## 4-2-6 Error Code List for Group Remote Controller

Error Code	Error Contents	Trouble shooting
- -	Initial Setting Error	13
1 2	Remote Controller Communication Error	7,9,10,86,92
1 3	Communication Error Between Outdoor Unit	14
1 4	Network Communication Error	12,15,16,95
1 5	Scan Error	92
1 6	Indoor Unit Parallel Communication Error	11,89
2 6	Address Setting Error	90
2 8	Other Setting Error	61, 62, 91
3 1	Indoor Unit Power Frequency Abnormal	2
3 2	Indoor Unit Main PCB Error	1, 3
4 1	Room Temperature Sensor Error	4
4 2	Indoor Unit Heat Ex. Sensor Error	5, 6
5 1	Indoor Unit Fan Motor Error	8
5 3	Water Drain Abnormal	7
6 1	Outdoor Unit Reverse Phase, Missing Phase Wire Error	17
6 2	Outdoor Unit Main PCB Error	18 ~ 20
6 3	Inverter Error	21
6 7	Inverter PCB Momentary Power Failure Detection	22
6 8	Magnetic Relay Error	23, 24
6 9	Outdoor Unit Communication PCB Error	25
7 1	Discharge Temperature Sensor Error	26, 27
7 2	Compressor Temperature Sensor Error	28, 29
7 3	Outdoor Unit Heat Ex. Temperature Sensor Error	30
7 4	Outdoor Temperature Sensor Error	31
7 5	Suction Gas Temperature Sensor Error	32
7 7	Heat Sink Temperature Sensor Error	33

Error Code	Error Contents	Trouble shooting
8 2	Sub-cool Heat Ex. Gas Temperature Sensor Error	34, 35
8 3	Liquid Pipe Temperature Sensor Error	36, 37
8 4	Current Sensor Error	38
8 6	Pressure Sensor Error	39 ~ 42
9 2	Compressor 2 Error	43, 44
9 3	Compressor Start Up Error	45
9 4	Trip Detection	46
9 5	Compressor Motor Control Error	47
9 7	Outdoor Unit Fan Motor Error	48 ~ 50
A 1	Discharge Temperature 1 Abnormal	52
A 2	Discharge Temperature 2 Abnormal	53
A 3	Compressor Temperature Abnormal	54, 55
A 4	High Pressure Abnormal	56 ~ 58
A 5	Low Pressure Abnormal	59
A C	Heat Sink Temperature Abnormal	60
C 4	PCB Error	91
C A	Software Error	82, 89
C 1	PCB Error 1	80, 85

## 4-2-7 TROUBLE LEVEL OF SYSTEM

### << System Condition when Outdoor Unit Error is occurred >>

System Condition	Outdoor unit Condition		Trouble Level	
			1	2
			(1) Not indicated on Indoor Unit. Not indicated on Peripheral Unit. Indicated on Service Tool.	(2) ● Indicated on Indoor Unit. Indicated on Peripheral. Indicated on Service Tool.
System is not stopped compulsorily.	>Abnormal >LED indication >Outdoor unit does not stop	Operation continues. (Only the subject unit stops)	>Temporary blackout detection protection (Inverter compressor stop) >Outdoor network communication abnormal 1	<ul style="list-style-type: none"> <li>○ Compressor 2 current value error (Constant speed compressor stops)</li> <li>○ Compressor 2 error (Constant speed compressor stops)</li> <li>○ Discharge temperature 1 abnormal (Inverter compressor stops)</li> <li>○ Discharge temperature 2 abnormal (Constant speed compressor stops)</li> <li>○ Compressor 1 temperature abnormal (Inverter compressor stops)</li> <li>○ Compressor 2 temperature abnormal (Constant speed compressor stops)</li> <li>○ High pressure switch 1 error (Inverter compressor stops)</li> <li>○ High pressure switch 2 error (Constant speed compressor stops)</li> <li>○ Discharge Temp sensor 1 error (Inverter compressor stops)</li> <li>○ Discharge Temp sensor 2 error (Constant speed compressor stops)</li> <li>○ liquid pipe Temp sensor 1 Error</li> <li>○ liquid pipe Temp sensor 2 Error</li> <li>○ Suction gas Temp sensor error</li> <li>○ Outdoor Temp sensor error</li> <li>○ Sub-cool heat Ex. gas inlet Temp sensor error</li> <li>○ Sub-cool heat Ex. gas outlet Temp sensor error</li> <li>○ Compressor Temp sensor 1 error (Inverter compressor stop)</li> <li>○ Compressor Temp sensor 2 error (Constant speed compressor stop)</li> <li>○ Heat sink Temp sensor error (Inverter compressor stop)</li> <li>○ Current sensor error (Inverter compressor stop)</li> <li>○ High pressure switch 1 error (Inverter compressor stop)</li> <li>○ High pressure switch 2 error (Constant speed compressor stop)</li> <li>○ Inverter error (Inverter compressor stop)</li> <li>○ Heat sink temperature abnormal (Inverter compressor stop)</li> <li>○ Inverter compressor start up error (Inverter compressor stop)</li> <li>○ Trip detection (Inverter compressor stops)</li> <li>○ Rush current limiting resistor Temp rise protection (Inverter compressor stop)</li> <li>○ Comp. motor loss of synchronization (Inverter compressor stop)</li> <li>○ Inverter communication error (Inverter compressor stop)</li> </ul> <p>Outdoor unit EEPROM access error Outdoor unit EEPROM data corrupted</p>
	>Abnormal >LED indication >Outdoor unit stops >Recoverable >Operation continuable	Only the subject unit stops	(Not available)	(Not available)

● This will not be displayed on indoor unit which Error Report Target(function setting 47 of indoor unit) is set "for administrator".

○ System will shut down when all compressors are in abnormal stop due to some sort of defect.

System Condition	Outdoor unit Condition		Trouble Level	
			1	2
			(1) Not indicated on Indoor Unit. Not indicated on Peripheral Unit. Indicated on Service Tool.	(2) Indicated on Indoor Unit. Indicated on Peripheral. Indicated on Service Tool.
System is compulsorily stopped.	>Abnormal >LED indication >Outdoor unit stops >Recoverable >Operation continuable	Subject refrigerant circuit stops	(Not available)	(Not available)
	>Abnormal >LED indication >Outdoor unit stops >Not recoverable >Need to repair >secondary accident is possible.	Subject refrigerant circuit stops	(Not available)	>High pressure abnormal >Low pressure abnormal >Magnetic relay error >Fan motor lock error >Fan motor temperature abnormal >Heat Ex. liquid Temp sensor error >Discharge pressure sensor error >Suction pressure sensor error >Outdoor unit communication PCB parallel communication error >Outdoor unit network communication 2 error >Outdoor unit reverse phase, Missing phase wire error >Outdoor unit fan motor undervoltage >Communication error between outdoor unit

<Important>

Even if power is reset, the following Error cannot release.

- Compressor 2 overcurrent error
- Compressor 2 error
- Discharge temperature 1 abnormal
- Discharge temperature 2 abnormal
- Compressor 1 temperature abnormal
- Compressor 2 temperature abnormal
- Current sensor error
- Inverter compressor start up error
- Trip detection
- Rush current limiting resistor Temp rise protection
- Comp. motor loss of synchronization
- Low pressure abnormal
- Magnetic relay error
- Fan motor lock error

These errors can not be judged without operating the system, and the serviceman would not be able to check it if the system power is turned off before visiting the site for repair.  
In Error release, you need to operate push switch and apply "Error reset" (F3-40) after power restart.


## 4-2-8 ERROR HISTORY MODE

When the abnormality occurred, the V2 system memorizes the history of error codes up to 10 and it can be displayed on 7 segments LED.


It is an effective means to examine abnormality that occurred in the past.

\*The error history can be cleared by setting to F3-30.


Refer to the following for the procedure.




### ① Change to the Error History Mode from the Mode Selection Display




### ② Select the Error History Number



### ③ Check the detail of the Error History




### ④ End of the Error History mode



## 4-3 TROUBLE SHOOTING

### 4-3-1 Trouble shooting with error code (INDOOR UNIT)

<b>Trouble shooting 1</b> <b>INDOOR UNIT Error Method:</b> <b>Model Information Error</b> <b>(Indoor Unit Main PCB Error)</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E.5 U.1</b> <b>Indoor Unit : Operation LED 3 times Flash, Timer LED 2 Times Flash,</b> <b>Filter LED Continuous Flash.</b> <b>Error Code : 3 2</b>
<b>Detective Actuators:</b>  Indoor Unit Controller PCB Circuit	<b>Detective details:</b> 3 continuous failure of lead test of EEPROM at Power ON, or Apparent Model information error from EEPROM. Also, Error on Model information upon model information test of EEPROM, or Model information of EEPROM not possible to recover.
<b>Forecast of Cause :</b> 1. Outside cause 2. Connection failure of electric components 3. Controller PCB defective	



#### **Note : EEPROM**


EEPROM(Electronically Erasable and Programmable Read Only Memory) is a non-volatile memory which keeps memorized information even if power is turned off. It can change the contents electronically. To change the contents, it uses higher voltage than normal, and it can not change a partial contents. (Rewriting shall be done upon erasing the all contents.) There is a limit in a number of rewriting.




<b>Trouble shooting 2</b> <b>INDOOR UNIT Error Method:</b> <b>Power Frequency Abnormal</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E.5 U.1</b> <b>Indoor Unit : Operation LED 3 times Flash, Timer LED 1 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 3 1</b>
--	--

<b>Detective Actuators:</b> Indoor Unit Controller PCB Circuit	<b>Detective details:</b> When 5 continuous failures occurred at Power frequency test.
---	---

<b>Forecast of Cause :</b> 1. Outside cause 2. Installation failure 3. Defective connection of electric components 4. Controller PCB defective
---



<b>Trouble shooting 3</b> <b>INDOOR UNIT Error Method:</b> <b>EEPROM Access Abnormal</b> <b>(Indoor Unit Main PCB Error)</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E.5 U.1</b> <b>Indoor Unit : Operation LED 3 times Flash, Timer LED 2 Times Flash,</b> <b>Filter LED Continuous Flash.</b> <b>Error Code : 3 2</b>
<b>Detective Actuators:</b> Indoor Unit Controller PCB Circuit	<b>Detective details:</b> When 3 continuous failure occurred on lead test of EEPROM.
<b>Forecast of Cause :</b> 1. Outside cause 2. Defective connection of electric component 3. Controller PCB defective	





**Trouble shooting 5**  
**INDOOR UNIT Error Method:**  
**Heat Exchanger Inlet Sensor Error**

**Indicate or Display:**  
Outdoor Unit : E.5 U.1  
Indoor Unit : Operation LED 4 times Flash, Timer LED 2 Times Flash,  
Filter LED Continuous Flash.  
Error Code : 4 2

**Detective Actuators:**

Indoor Unit Controller PCB Circuit  
Heat Exchanger Inlet Thermistor

**Detective details:**

When open or shorted Heat Exchanger Inlet Thermistor is detected  
at Power ON.

**Forecast of Cause :** 1. Connector defective connection 2. Thermistor defective 3. Controller PCB defective

**Check Point 1 : Check connection of Connector**

- ☐ Check if connector is loose or removed
- ☐ Check erroneous connection
- ☐ Check if thermistor cable is open

**>>Reset Power when reinstalling due to removed connector or incorrect wiring.**

OK

**Check Point 2 : Remove connector and check Thermistor resistance value**

Thermistor Characteristics (Rough value)

Temperature (°C)	0	5	10	15	20	25	30	35
Resistance Value (kΩ)	168.6	129.8	100.9	79.1	62.5	49.8	40.0	32.4

Temperature (°C)	40	45	50
Resistance Value (kΩ)	26.3	21.2	17.8


► **If Thermistor is either open or shorted, replace it and reset the power.**

OK

**Check Point 3 : Check voltage of Controller PCB (DC5.0V)**

Make sure circuit diagram of each indoor unit and check terminal voltage at Thermistor (DC5.0V)

• Duct Schematic Diagram (Connector connection)




H/E Inlet Thermistor  
(CN20 Wire:Black)

H/E Outlet Thermistor  
(CN20 Wire:Gray)

Room Temp. Thermistor  
(CN19 Wire:Black)

• Small size Wall mount Schematic Diagram(Direct soldering to PCB)



H/E Inlet Thermistor  
(CN12 Wire:Black)

H/E Outlet Thermistor  
(CN11 Wire:Gray)


Room Temp. Thermistor  
(CN10 Wire:Black)

• Cassette Schematic Diagram (Connector connection)

H/E Inlet Thermistor  
(CN9 Wire:Black)

H/E Outlet Thermistor  
(CN9 Wire:Gray)

Room Temp. Thermistor  
(CN8 Wire:Black)




• Wall mount Schematic Diagram (Connector connection)

H/E Inlet Thermistor  
(CN17 Wire:Black)

H/E Outlet Thermistor  
(CN17 Wire:Gray)

Room Temp. Thermistor  
(CN16 Wire:Black)



► **If the voltage does not appear, replace Controller PCB and set up the original address.**  
**(Refer to 06-03 page Main PCB removal.)**

**Trouble shooting 6**  
**INDOOR UNIT Error Method:**  
**Heat Exchanger Outlet Sensor Error**

**Indicate or Display:**  
**Outdoor Unit : E.5 U.1**  
**Indoor Unit : Operation LED 4 times Flash, Timer LED 2 Times Flash, Filter LED Continuous Flash.**  
**Error Code : 4 2**

**Detective Actuators:**

Indoor Unit Controller PCB Circuit  
 Heat Exchanger Outlet Thermistor

**Detective details:**

When open or shorted Heat Exchanger outlet Thermistor is detected at Power ON.


**Forecast of Cause :** 1. Connector defective connection 2.Thermistor defective 3.Controller PCB defective

**Check Point 1 : Check connection of Connector**

- ☐ Check if connector is loose or removed
  - ☐ Check erroneous connection
  - ☐ Check if thermistor cable is open
- >>Reset Power when reinstalling due to removed connector or incorrect wiring.**



**Check Point 2 : Remove connector and check Thermistor resistance value**



Thermistor Characteristics (Rough value)


Temperature (°C)	0	5	10	15	20	25	30	35
Resistance Value (kΩ)	168.6	129.8	100.9	79.1	62.5	49.8	40.0	32.4

Temperature (°C)	40	45	50
Resistance Value (kΩ)	26.3	21.2	17.8

► **If Thermistor is either open or shorted, replace it and reset the power.**




**Check Point 3 : Check voltage of Controller PCB (DC5.0V)**



Make sure circuit diagram of each indoor unit and check terminal voltage at Thermistor (DC5.0V)


- Duct Schematic Diagram (Connector connection)
- Small size Wall mount Schematic Diagram(Direct soldering to PCB)



H/E Inlet Thermistor  
(CN20 Wire:Black)

H/E Outlet Thermistor  
(CN20 Wire:Gray)

Room Temp. Thermistor  
(CN19 Wire:Black)



H/E Inlet Thermistor  
(CN12 Wire:Black)

H/E Outlet Thermistor  
(CN11 Wire:Gray)


Room Temp. Thermistor  
(CN10 Wire:Black)

- Cassette Schematic Diagram (Connector connection)

H/E Inlet Thermistor  
(CN9 Wire:Black)

H/E Outlet Thermistor  
(CN9 Wire:Gray)

Room Temp. Thermistor  
(CN8 Wire:Black)




- Wall mount Schematic Diagram (Connector connection)

H/E Inlet Thermistor  
(CN17 Wire:Black)

H/E Outlet Thermistor  
(CN17 Wire:Gray)

Room Temp. Thermistor  
(CN16 Wire:Black)




► **If the voltage does not appear, replace Controller PCB and set up the original address.**  
**(Refer to 06-03 page Main PCB removal.)**

<b>Trouble shooting 7</b> <b><u>INDOOR UNIT Error Method:</u></b> <b>Water Drain Abnormal</b>	<b><u>Indicate or Display:</u></b> <b>Outdoor Unit : E.5 U.1</b> <b>Indoor Unit : Operation LED 5 times Flash, Timer LED 3 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 5 3</b>
---	---

<b><u>Detective Actuators:</u></b> Indoor Unit Controller PCB Circuit Float Switch	<b><u>Detective details:</u></b> When Float switch is ON for more than 3 minutes.
--	--

<b><u>Forecast of Cause :</u></b> 1. Float switch defective 2. Shorted connector/wire 3. Controller PCB defective 4. Drain pump defective
---

<b>Check Point 1 : Check Float Switch</b>	
<ul style="list-style-type: none"> <li>❑ Check operation of float switch. (any blocking by dust, etc.)</li> <li>❑ Remove Float switch and check ON/OFF switching operation by using a meter.</li> </ul> <p><b>&gt;&gt;If Float switch is defective, replace it.</b></p>	

↓  
**OK**

<b>Check Point 2 : Check Connector (CN 1) / Wire</b>
<ul style="list-style-type: none"> <li>❑ Check loose contact of CN1 /shorted wire (pinched wire).</li> </ul> <p><b>&gt;&gt;Replace Float switch if the wire is abnormal</b></p>

↓  
**OK**

<b>Check Point 3 : Check Controller PCB</b>
<p>► <b><u>If Check Point 1 &amp; 2 do not improve the symptom, change Controller PCB and set up the original address. (Refer to 06-03 page Main PCB removal.)</u></b></p>

**Attention!!**

Small size wall mount type does not have a float switch. In this case, replace Controller PCB and set up the original address. Please refer to.

<b>Trouble shooting 8</b> <b>INDOOR UNIT Error Method:</b> <b>Indoor Unit Fan Motor Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E.5 U.1</b> <b>Indoor Unit : Operation LED 5 times Flash, Timer LED 1 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 5 1</b>
---	--

<b>Detective Actuators:</b> Indoor Unit Controller PCB Circuit Indoor Fan Motor	<b>Detective details:</b> When Indoor fan control is either phase control or DC control and rotation feed back control is ON, the feed back rotation value becomes 0 and lasts for more than 1 minute at motor operation condition. Or, the feed back rotation value continues at 1/3 of target value for more than 1 minute.
---	--

<b>Forecast of Cause :</b> 1. Fan rotation failure 2. Fan motor winding open 3. Motor protection by surrounding temp. increase 4. Capacitor failure 5. Control PCB failure
---

<b>Check Point 1 : Check rotation of Fan</b>
<input type="checkbox"/> Rotate the fan by hand when operation is off. (Check if fan is caught, dropped off or locked motor) <u>&gt;&gt;If Fan or Bearing is abnormal, replace it.</u>



<b>Check Point 2 : Check Motor winding</b>
<input type="checkbox"/> Check Indoor Fan motor (PARTS INFORMATION19) <u>&gt;&gt;If Fan motor is abnormal, replace it.</u>



<b>Check Point 3 : Check ambient temp. around motor</b>
<input type="checkbox"/> Check excessively high temperature around the motor. (If there is any surrounding equipment that causes heat) <u>&gt;&gt;Upon the temperature coming down, restart operation.</u>



<b>Check Point 4 : Check Motor Capacitor</b>
<input type="checkbox"/> Check continuity of motor capacitor <u>&gt;&gt;If it is shorted, replace the capacitor.</u>



<b>Check Point 5 : Replace Controller PCB</b>
<input type="checkbox"/> Change Controller PCB and set up the original address. (Refer to 06-03 page Main PCB removal.)

**Attention!!**  
 In case of Duct type, replace Controller PCB and set up the original address, since it is a tapping control.






<b>Trouble shooting 11</b> <b>INDOOR UNIT Error Method:</b> Indoor Unit Parallel Communication Error	<b>Indicate or Display:</b> Outdoor Unit : E.5 U.1 Indoor Unit : Operation LED 1 times Flash, Timer LED 6 Times Flash, Filter LED Continuous Flash. Error Code : 1 6
--	---

<b>Detective Actuators:</b> Indoor unit Controller PCB circuit Indoor unit Communication PCB	<b>Detective details:</b> When Parallel communication error (Communication reset occurs continuously more than specified times) is detected.
--	---

<b>Forecast of Cause :</b> 1. Connection failure 2. Outside cause 3. Communication PCB failure 4. Controller PCB failure
--



<b>Trouble shooting 12</b> <b>INDOOR UNIT Error Method:</b> <b>Network Communication Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E.5 U.1</b> <b>Indoor Unit : Operation LED 1 times Flash, Timer LED 6 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 1 4</b>
--	--

<b>Detective Actuators:</b> Indoor unit Controller PCB circuit Indoor unit Communication PCB	<b>Detective details:</b> When the cut-off of network communication is detected (more than 90 seconds passed since the last receipt of Outdoor unit signal).
--	---

<b>Forecast of Cause :</b> 1. Connection failure 2. Outside cause 3. Communication PCB failure 4. Controller PCB failure
--

<b>Check Point 1 : Check the connection</b>
<u>After turning off the power, check and correct followings.</u> <input type="checkbox"/> Is Indoor Communication PCB loose? <input type="checkbox"/> Check loose or removed connection of communication line between Indoor and Outdoor unit. <input type="checkbox"/> When the signal amplifier is connected, is it failure of signal amplifier? (Refer to "TROUBLE SHOOTING FOR OPTIONAL PARTS")



<b>Check Point 2 : Check if any outside cause such as voltage drop or noise</b>
<ul style="list-style-type: none"> <li>● Instant voltage drop ----- Check if there is any electric equipment with a large load within the same circuit.</li> <li>● Momentary power failure ----- Check contact failure or leak current in power supply circuit  <u>&gt;&gt;Check Outdoor Unit as well.</u></li> <li>● Check if there is any equipment that causes harmonic wave near the power cable (Neon light bulb or any electronic equipment which causes harmonic wave). And check the complete insulation of grounding.  <u>&gt;&gt;If the same symptom does not reappear after resetting the power, possibility of noise is high.</u></li> </ul>




<b>Check Point 3 : Check Communication PCB and Controller PCB</b>
<input type="checkbox"/> If some of Indoor units have errors, replace Communication PCB of the Indoor units that have the error. <u>&gt;&gt;If the symptom does not change, replace Indoor unit Controller PCB. (Refer to 06-03 page Main PCB removal.)</u> <input type="checkbox"/> If all the Indoor units have error, check if the Outdoor Unit Communication PCB has a loose connection (Refer to Trouble Shooting 15). <u>&gt;&gt;If the symptom does not change, replace Outdoor unit Communication PCB (Replace Controller PCB if it does not change).</u>



<b>Trouble shooting 14</b> <b>OUTDOOR UNIT Error Method:</b> <b>Communication Error Between Outdoor Unit</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 13. 1</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 13</b>
--	---

<b>Detective Actuators:</b>  Outdoor unit main PCB	<b>Detective details:</b> <b>Master unit:</b> State in which "number of connected slave units" by Dip-SW and the number of slave units which can be recognized by communication did not match continued for 10 seconds or more after the start of control. <b>Slave unit:</b> State in which communication from the master unit was not received continued for 10 seconds or more after the start of control.
--	---


<b>Forecast of Cause :</b> 1. Noise, momentary open, voltage drop 2. Power supply defective 3. The number setting mistake of outdoor unit 4. Connection of communication lines between outdoor units defective 5. Main PCB defective
--



<b>Trouble shooting 15</b> <b><u>OUTDOOR UNIT Error Method:</u></b> <b>Outdoor Unit Network</b> <b>Communication 1 Error</b>	<b><u>Indicate or Display:</u></b> <b>Outdoor Unit : E. 14. 1</b> <b>Indoor Unit : No display</b> <b>Error Code : 14</b>
---	---

<b><u>Detective Actuators:</u></b> Outdoor unit Main PCB	<b><u>Detective details:</u></b> • No communication for 180 seconds or more from an indoor unit which received communication once and no outdoor network communication error 2.
---	--


<b><u>Forecast of Cause :</u></b> 1. Noise, momentary open, voltage drop 2. Indoor unit power off 3. Communication line connection defective 4. Terminal resistor setting mistake 5. Communication PCB mounting defective, Communication PCB defective 6. Controller PCB defective
--



<b>Trouble shooting 16</b> <b><u>OUTDOOR UNIT Error Method :</u></b> <b>Outdoor Unit Network</b> <b>Communication 2 Error</b>	<b><u>Indicate or Display:</u></b> <b>Outdoor Unit : E. 14. 2</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash,</b> <b>Filter LED Continuous Flash.</b> <b>Error Code : 14</b>
--	--

<b><u>Detective Actuators:</u></b> Outdoor unit Main PCB	<b><u>Detective details:</u></b> •No communication for 180 seconds or more from all indoor units that once received communication
---	--


<b><u>Forecast of Cause :</u></b>	1. Noise, momentary open, voltage drop 2. Indoor unit power off 3. Communication line connection defective 4. Terminal resistor setting mistake 5. Communication PCB mounting defective, Communication PCB defective 6. Control PCB defective
-----------------------------------	---



<b>Trouble shooting 17</b> <b>OUTDOOR UNIT Error Method:</b> <b>Outdoor Unit Reverse Phase,</b> <b>Missing Phase Wire Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 61. 5</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash,</b> <b>Filter LED Continuous Flash.</b> <b>Error Code : 61</b>
--	---

<b>Detective Actuators:</b> Outdoor unit Main PCB	<b>Detective details:</b> •Reverse phase prevention circuit detected reversed phase input or input was not normal.
--	---


<b>Forecast of Cause :</b> 1. Noise, momentary open, voltage drop 2. Power supply defective 3. Filter PCB (Main) defective 4. Main PCB defective
---



<b>Trouble shooting 18</b> <b>OUTDOOR UNIT Error Method:</b> <b>Outdoor Unit EEPROM Access Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 62. 3</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 62</b>
--	---

<b>Detective Actuators:</b> Outdoor unit Main PCB	<b>Detective details:</b> •Access to EEPROM failed due to some cause after outdoor unit started.
--	---

<b>Forecast of Cause :</b> 1. Noise, momentary open, voltage drop 2. Main PCB defective
---






<b>Trouble shooting 19</b> <b>OUTDOOR UNIT Error Method:</b> <b>Inverter Communication Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 62. 6</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 62</b>
--	---

<b>Detective Actuators:</b> Outdoor unit Main PCB	<b>Detective details:</b> •Communication not received from Inverter PCB for 10 seconds or more
--	---


<b>Forecast of Cause :</b> 1. Noise 2. Main to Inverter PCBs wiring connection defective 3. Main PCB defective 4. Inverter PCB defective
---



<b>Trouble shooting 20</b> <b>OUTDOOR UNIT Error Method:</b> <b>Outdoor Unit EEPROM Data Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 62. 8</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 62</b>
--	---

<b>Detective Actuators:</b>  Outdoor unit Main PCB	<b>Detective details:</b> <ul style="list-style-type: none"> <li>▪ Set contents sum value memorized in EEPROM and sum value calculated based on the set contents read from EEPROM do not match</li> <li>* Regarding the sum value, only the contents set in the push button SW setting mode (F2) shall be the objective.</li> </ul>
--	---


<b>Forecast of Cause :</b> 1. Noise, momentary open, voltage drop 2. Main PCB defective
---



<b>Trouble shooting 21</b> <b>OUTDOOR UNIT Error Method:</b> <b>Inverter Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 63. 1</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 63</b>
--	---

<b>Detective Actuators:</b> Inverter PCB	<b>Detective details:</b> •Error information received from Inverter PCB
---	--


<b>Forecast of Cause :</b>	1. Noise, momentary open, voltage drop. 2. Power supply to Filter PCB (INV) to Inverter PCB wiring disconnection, open 3. Filter PCB ( INV) defective 4. Inverter PCB defective
----------------------------	---



<b>Trouble shooting 22</b> <b>OUTDOOR UNIT Error Method:</b> <b>Inverter PCB Momentary Power Failure Detection</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 67. 2</b> <b>Indoor Unit : No Display</b> <b>Error Code : 67</b>
--	--

<b>Detective Actuators:</b> Inverter PCB	<b>Detective details:</b> <ul style="list-style-type: none"> <li>• "Momentary power failure" received from Inverter PCB</li> </ul>
---	---


<b>Forecast of Cause :</b> 1. Noise, momentary power failure, voltage drop 2. Magnetic Relay (for Inverter) coil side wiring disconnection, open 3. Power supply to Filter PCB (INV) to Inverter PCB wiring disconnection, open 4. Main PCB defective 5. Inverter PCB defective
---



<b>Trouble shooting 23</b> <b>OUTDOOR UNIT Error Method:</b> <b>Magnetic Relay Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 68. 1</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 68</b>
--	---

<b>Detective Actuators:</b> Current sensor 2 (current sensor for constant speed compressor)	<b>Detective details:</b> <ul style="list-style-type: none"> <li>"Current value (constant speed) <math>\geq 3.0A</math>" continues for 5 seconds during constant speed compressor stop command</li> </ul>
--	---

<b>Forecast of Cause :</b> <ol style="list-style-type: none"> <li>1. Magnetic Relay (for constant speed compressor) defective</li> <li>2. Current sensor 2 (current sensor for constant speed compressor) defective</li> <li>3. Main PCB defective</li> </ol>
---




\* When the magnetic Relay (for constant speed compressor) was turned ON manually, a Magnetic Relay Error may be generated.

<b>Trouble shooting 24</b> <b>OUTDOOR UNIT Error Method:</b> <b>Rush Current Limiting Resistor</b> <b>Temp Rise Protection</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 68. 2</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash,</b> <b>Filter LED Continuous Flash.</b> <b>Error Code : 68</b>
---	---

<b><u>Detective Actuators:</u></b>  Inverter PCB	<b><u>Detective details:</u></b>  ▪ "Protection stop by "Rush current limiting resistor temperature rise detection" of inverter PCB" was generated 2 times.
--	---


<b><u>Forecast of Cause :</u></b>	1. Magnetic relay (for inverter) coil side wiring disconnection, open 2. Power supply to Filter PCB (INV) to Inverter PCB wiring disconnection, open 3. Main PCB defective (Magnetic relay (for inverter) ON/OFF relay) 4. Inverter PCB defective (DC voltage detection circuit, magnetic relay (for inverter) drive output)
-----------------------------------	--



<b>Trouble shooting 25</b> <b>OUTDOOR UNIT Error Method:</b> <b>Outdoor Unit Communication PCB</b> <b>Parallel Communication Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 69. 1</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 69</b>
---	---

<b>Detective Actuators:</b>  Outdoor unit Main PCB	<b>Detective details:</b> •Parallel communication (communication between master PC and Neuron Chip) failed 5 times.
--	--

<b>Forecast of Cause :</b>	1. Noise      2. Communication PCB connection defective 3. Communication PCB defective      4. Main PCB defective
----------------------------	--



<b>Trouble shooting 26</b> <b>OUTDOOR UNIT Error Method:</b> <b>Discharge Temp Sensor 1 Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 71. 1</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 71</b>
---	---

<b>Detective Actuators:</b>  Discharge temperature thermistor 1	<b>Detective details:</b> <ul style="list-style-type: none"> <li>Discharge temperature thermistor 1 short detected</li> <li>Discharge thermistor 1 open detected after compressor 1 operated continuously for 5 minutes or more</li> </ul>
---	--



<b>Forecast of Cause :</b> <ol style="list-style-type: none"> <li>Connector connection defective, open</li> <li>Thermistor defective</li> <li>Main PCB defective</li> </ol>
---

Check Point 1 : Check the connector connection and cable open <input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check
---



Check Point 2 : Check the thermistor <input type="checkbox"/> Thermistor characteristics check (Disconnect the thermistor from the PCB and check.) * For the thermistor characteristics, refer to the "Service Parts Information 22".
---



Check Point 3 : Check voltage of Main PCB (DC5.0V) <input type="checkbox"/> Main PCB (CN141:1-2) voltage value = 5V <u>Remove the thermistor from Main PCB, check the voltage.</u>	<div style="border: 1px solid black; padding: 5px; text-align: center;"> <b>DC</b>   </div>
<div style="border: 1px solid black; padding: 10px; text-align: center;">  <p>Discharge temperature sensor 1 (CN141:1-2)</p> <p>► <b>If the voltage does not appear, replace Main PCB and set up original address.</b>  <b>(Refer to 06-03 page Main PCB removal.)</b></p> </div>	



<b>Trouble shooting 27</b> <b>OUTDOOR UNIT Error Method:</b> <b>Discharge Temp Sensor 2 Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 71. 2</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 71</b>
---	---

<b>Detective Actuators:</b>  Discharge temperature thermistor 2	<b>Detective details:</b> <ul style="list-style-type: none"> <li>• Discharge temperature thermistor 2 short detected</li> <li>• Discharge thermistor 2 open detected after compressor 2 operated continuously for 5 minutes or more</li> </ul>
---	--



<b>Forecast of Cause :</b> <ol style="list-style-type: none"> <li>1. Connector connection defective, open</li> <li>2. Thermistor defective</li> <li>3. Main PCB defective</li> </ol>
--

<b>Check Point 1 : Check the connector connection and cable open</b>
<input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check



<b>Check Point 2 : Check the thermistor</b>
<input type="checkbox"/> Thermistor characteristics check (Disconnect the thermistor from the PCB and check.) * For the thermistor characteristics, refer to the "Service Parts Information 22".



<b>Check Point 3 : Check voltage of Main PCB (DC5.0V)</b>	<div style="border: 1px solid black; padding: 5px; text-align: center;"> <b>DC</b>   </div>
<input type="checkbox"/> Main PCB (CN141:3-4) voltage value = 5V <u>Remove the thermistor from Main PCB, check the voltage.</u>	
<div style="border: 1px solid black; padding: 10px; text-align: center;">  <p>CN141</p> </div>	
Discharge temperature sensor 2 (CN141:3-4)	
<b>► If the voltage does not appear, replace Main PCB and set up original address.</b> <u>(Refer to 06-03 page Main PCB removal.)</u>	

<b>Trouble shooting 28</b> <b>OUTDOOR UNIT Error Method:</b> <b>Compressor Temp Sensor 1 Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 72. 1</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 72</b>
--	---

<b>Detective Actuators:</b>  Compressor temperature thermistor 1	<b>Detective details:</b> <ul style="list-style-type: none"> <li>Compressor temperature thermistor 1 short detected</li> <li>Compressor thermistor 1 open detected after compressor 1 operated continuously for 5 minutes or more</li> </ul>
--	--

<b>Forecast of Cause :</b> <ul style="list-style-type: none"> <li>1. Connector connection defective, open</li> <li>2. Thermistor defective</li> <li>3. Main PCB defective</li> </ul>
--

Check Point 1 : Check the connector connection and cable open
<input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check



Check Point 2 : Check the thermistor
<input type="checkbox"/> Thermistor characteristics check (Disconnect the thermistor from the PCB and check.) * For the thermistor characteristics, refer to the "Service Parts Information 22".



Check Point 3 : Check voltage of Main PCB (DC5.0V)	<div>DC</div>
<input type="checkbox"/> Main PCB (CN141:5-6) voltage value = 5V <u>Remove the thermistor from Main PCB, check the voltage.</u>	
<div> <p>Diagram of CN141 connector showing three thermistor locations. The first two are labeled 'THERMISTOR (DIS. TEMP. 1)' and 'THERMISTOR (DIS. TEMP. 2)', and the third is 'THERMISTOR (COMP SHELL 1)'. Each thermistor is connected to a pair of pins (1-2, 3-4, 5-6) which are labeled 'BLACK'.</p> </div>	
Compressor temperature sensor 1 (CN141:5-6)	
<b>► If the voltage does not appear, replace Main PCB and set up original address.</b> <b>( Refer to 06-03 page Main PCB removal.)</b>	

<b>Trouble shooting 29</b> <b>OUTDOOR UNIT Error Method:</b> <b>Compressor Temp Sensor 2 Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 72. 2</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 72</b>
--	---

<b>Detective Actuators:</b>  Compressor temperature thermistor 2	<b>Detective details:</b> <ul style="list-style-type: none"> <li>Compressor temperature thermistor 2 short detected</li> <li>Compressor thermistor 2 open detected after compressor 2 operated continuously for 5 minutes or more</li> </ul>
--	--



<b>Forecast of Cause :</b> <ol style="list-style-type: none"> <li>Connector connection defective, open</li> <li>Thermistor defective</li> <li>Main PCB defective</li> </ol>
---

Check Point 1 : Check the connector connection and cable open
<input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check



Check Point 2 : Check the thermistor
<input type="checkbox"/> Thermistor characteristics check (Disconnect the thermistor from the PCB and check.) * For the thermistor characteristics, refer to the Service Parts Information 22.



Check Point 3 : Check voltage of Main PCB (DC5.0V)	<div style="border: 1px solid black; padding: 5px; text-align: center;"> <b>DC</b>   </div>
<input type="checkbox"/> Main PCB (CN145:1-3) voltage value = 5V <u>Remove the thermistor from Main PCB, check the voltage.</u>	
<div style="border: 1px solid black; padding: 10px; text-align: center;">  </div>	
Compressor temperature sensor 2 (CN145:1-3)	
<b>► If the voltage does not appear, replace Main PCB and set up original address.</b> <b>(Refer to 06-03 page Main PCB removal.)</b>	

<b>Trouble shooting 30</b> <b>OUTDOOR UNIT Error Method:</b> <b>Outdoor Unit Heat Ex. Liquid Temp. Sensor Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 73. 3</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 73</b>
---	---

<b>Detective Actuators:</b>  Heat exchanger liquid temperature thermistor	<b>Detective details:</b>  • Heat exchanger liquid temperature thermistor short or open detected
---	--



<b>Forecast of Cause :</b>	1. Connector connection defective, open 2. Thermistor defective 3. Main PCB defective
----------------------------	---

Check Point 1 : Check the connector connection and cable open  <input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check
---



Check Point 2 : Check the thermistor  <input type="checkbox"/> Thermistor characteristics check (Disconnect the thermistor from the PCB and check.) * For the thermistor characteristics, refer to the "Service Parts Information 22".
---



Check Point 3 : Check voltage of Main PCB (DC5.0V)  <input type="checkbox"/> Main PCB (CN143:3-4) voltage value = 5V <u>Remove the thermistor from Main PCB, check the voltage.</u>	<div style="border: 1px solid black; padding: 5px; text-align: center;"> <b>DC</b>   </div>
<div style="border: 1px solid black; padding: 10px; text-align: center;">  <p>CN143</p> </div> <p>Heat exchanger liquid temperature sensor (CN143:3-4)</p> <p>► <b><u>If the voltage does not appear, replace Main PCB and set up original address.</u></b>  <b><u>(Refer to 06-03 page Main PCB removal.)</u></b></p>	

<b>Trouble shooting 31</b> <b><u>OUTDOOR UNIT Error Method:</u></b> <b>Outdoor Temp Sensor Error</b>	<b><u>Indicate or Display:</u></b> <b>Outdoor Unit : E. 74. 1</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 74</b>
--	--

<b><u>Detective Actuators:</u></b>  Outdoor temperature thermistor	<b><u>Detective details:</u></b>  • Outdoor temperature thermistor short or open detected
--	---



<b><u>Forecast of Cause :</u></b>	1. Connector connection defective, open 2. Thermistor defective 3. Main PCB defective
-----------------------------------	---

Check Point 1 : Check the connector connection and cable open
<input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check



Check Point 2: Check the thermistor
<input type="checkbox"/> Thermistor characteristics check (Disconnect the thermistor from the PCB and check.) * For the thermistor characteristics, refer to the "Service Parts Information 22".



Check Point 3 : Check voltage of Main PCB (DC5.0V)	<div style="border: 1px solid black; padding: 5px; text-align: center;"> <b>DC</b>   </div>
<input type="checkbox"/> Main PCB (CN144:1-3) voltage value = 5V <u>Remove the thermistor from Main PCB, check the voltage.</u>	
<div style="border: 1px solid black; padding: 10px; text-align: center;">  <p>Outdoor temperature sensor (CN144:1-3)</p> <p>► <b><u>If the voltage does not appear, replace Main PCB and set up original address.</u></b>  <b><u>(Refer to 06-03 page Main PCB removal.)</u></b></p> </div>	

<b>Trouble shooting 32</b> <b>OUTDOOR UNIT Error Method:</b> <b>Suction Gas Temp Sensor Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 75. 1</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 75</b>
---	---

<b>Detective Actuators:</b>  Suction gas temperature thermistor	<b>Detective details:</b>  <ul style="list-style-type: none"> <li>Suction gas temperature thermistor short or open detected</li> </ul>
---	--

<b>Forecast of Cause :</b>	1. Connector connection defective, open 2. Thermistor defective 3. Main PCB defective
----------------------------	---

Check Point 1 : Check the connector connection and cable open
<input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check



Check Point 2 : Check the thermistor
<input type="checkbox"/> Thermistor characteristics check (Disconnect the thermistor from the PCB and check.) * For the thermistor characteristics, refer to the "Service Parts Information 22".



Check Point 3 : Check voltage of Main PCB (DC5.0V)	<div>DC</div>
<input type="checkbox"/> Main PCB (CN143:1-2) voltage value = 5V <u>Remove the thermistor from Main PCB, check the voltage.</u>	
<div> </div> <p>Suction gas temperature sensor (CN143:1-2)</p> <p>► <b><u>If the voltage does not appear, replace Main PCB and set up original address.</u></b>  <b><u>(Refer to 06-03 page Main PCB removal.)</u></b></p>	

<b>Trouble shooting 33</b> <b><u>OUTDOOR UNIT Error Method:</u></b> <b>Heat Sink Temp Sensor Error</b>	<b><u>Indicate or Display:</u></b> <b>Outdoor Unit : E. 77. 1</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 77</b>
--	--

<b><u>Detective Actuators:</u></b>  Heat sink temperature thermistor	<b><u>Detective details:</u></b>  • Heat sink temperature thermistor open/short detected
--	--



<b><u>Forecast of Cause :</u></b>	1. Connector connection defective, open 2. Thermistor defective 3. Inverter PCB defective
-----------------------------------	---

Check Point 1 : Check the connector connection and cable open
<input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check



Check Point 2 : Check the thermistor
<input type="checkbox"/> Thermistor characteristics check (Disconnect the thermistor from the PCB and check.) * For the thermistor characteristics, refer to the "Service Parts Information 22".



Check Point 3 : Check voltage of Inverter PCB (DC5.0V)	<div style="border: 1px solid black; padding: 5px; text-align: center;"> <b>DC</b>   </div>
<input type="checkbox"/> Inverter PCB (CN800:1-2) voltage value = 5V <u>Remove the thermistor from Inverter PCB, check the voltage.</u>	
<div style="border: 1px solid black; padding: 10px; text-align: center;">  <p>Heat sink temperature thermistor (CN800:1-2)</p> <p>► <b><u>If the voltage does not appear, replace Inverter PCB and set up original address.</u></b></p> </div>	

<b>Trouble shooting 34</b> <b>OUTDOOR UNIT Error Method:</b> <b>Sub-cool Heat EX. Gas Inlet</b> <b>Temp Sensor Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 82. 1</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash,</b> <b>Filter LED Continuous Flash.</b> <b>Error Code : 82</b>
---	---

<b>Detective Actuators:</b>  Sub-cooling heat exchanger gas inlet temperature thermistor	<b>Detective details:</b>  • Sub-cooling heat exchanger gas inlet temperature thermistor short or open detected
--	---

<b>Forecast of Cause :</b> 1. Connector connection defective, open 2. Thermistor defective 3. Main PCB defective
--

Check Point 1 : Check the connector connection and cable open  <input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check
---



Check Point 2 : Check the thermistor  <input type="checkbox"/> Thermistor characteristics check (Disconnect the thermistor from the PCB and check.) * For the thermistor characteristics, refer to the "Service Parts Information 22".
---



Check Point 3 : Check voltage of Main PCB (DC5.0V)  <input type="checkbox"/> Main PCB (CN142:5-6) voltage value = 5V <u>Remove the thermistor from Main PCB, check the voltage.</u>	<div>DC</div>
<div> <div> THERMISTOR (SC.INT.LIQ)  THERMISTOR (SC.EXT.LIQ)  THERMISTOR (SC.INT.GAS)  THERMISTOR (SC.EXT.GAS) </div> <div> BLACK BLACK BLACK BLACK BLACK BLACK BLACK BLACK </div> <div> 1 2 3 4 5 6 7 8  1 2 3 4 5 6 7 8 </div> <div>CN142</div> </div> <div>Sub-cooling heat exchanger gas inlet temperature sensor (CN142:5-6)</div> <div> <b>► If the voltage does not appear, replace Main PCB and set up original address.</b>  <b>(Refer to Refer to 06-03 page Main PCB removal.)</b> </div>	



<b>Trouble shooting 35</b> <b>OUTDOOR UNIT Error Method:</b> <b>Sub-cool Heat EX. Gas outlet</b> <b>Temp Sensor Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 82. 2</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash,</b> <b>Filter LED Continuous Flash.</b> <b>Error Code : 82</b>
--	---

<b>Detective Actuators:</b>  Sub-cooling heat exchanger gas outlet temperature thermistor	<b>Detective details:</b>  • Sub-cooling heat exchanger gas outlet temperature thermistor short or open detected
---	--

<b>Forecast of Cause :</b> 1. Connector connection defective, open 2. Thermistor defective 3. Main PCB defective
--

Check Point 1 : Check the connector connection and cable open  <input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check
---



Check Point 2 : Check the thermistor  <input type="checkbox"/> Thermistor characteristics check (Disconnect the thermistor from the PCB and check.) * For the thermistor characteristics, refer to the "Service Parts Information 22".
---



Check Point 3 : Check voltage of Main PCB (DC5.0V)  <input type="checkbox"/> Main PCB (CN142:7-8) voltage value = 5V <u>Remove the thermistor from Main PCB, check the voltage.</u>	<div>DC</div>
<div> <div> THERMISTOR (SC.INT.LIQ)  THERMISTOR (SC.EXT.LIQ)  THERMISTOR (SC.INT.GAS)  THERMISTOR (SC.EXT.GAS) </div> <div> BLACK BLACK BLACK BLACK BLACK BLACK BLACK BLACK </div> <div> 1 2 3 4 5 6 7 8  1 2 3 4 5 6 7 8 </div> <div>CN142</div> </div> <div> Sub-cooling heat exchanger gas outlet temperature sensor (CN142:7-8)  ► <b>If the voltage does not appear, replace Main PCB and set up original address.</b>  <b>(Refer to 06-03 page Main PCB removal.)</b> </div>	

<b>Trouble shooting 36</b> <b>OUTDOOR UNIT Error Method:</b> <b>Liquid Pipe Temp. Sensor 1 Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 83. 1</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 83</b>
--	---

<b>Detective Actuators:</b>  Liquid pipe temperature thermistor 1	<b>Detective details:</b>  <ul style="list-style-type: none"> <li>• Liquid pipe temperature thermistor 1 short or open detected</li> </ul>
---	--

<b>Forecast of Cause :</b>	1. Connector connection defective, open 2. Thermistor defective 3. Main PCB defective
----------------------------	---

Check Point 1 : Check the connector connection and cable open
<input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check



Check Point 2 : Check the thermistor
<input type="checkbox"/> Thermistor characteristics check (Disconnect the thermistor from the PCB and check.) * For the thermistor characteristics, refer to the "Service Parts Information 22".



Check Point 3 : Check voltage of Main PCB (DC5.0V)	<div>DC</div>
<input type="checkbox"/> Main PCB (CN142:1-2) voltage value = 5V Remove the thermistor from Main PCB, check the voltage.	
<div> </div>	
Liquid pipe temperature sensor 1 (CN142:1-2)	
<b>► If the voltage does not appear, replace Main PCB and set up original address.</b> <b>(Refer to 06-03 page Main PCB removal.)</b>	

<b>Trouble shooting 37</b> <b>OUTDOOR UNIT Error Method:</b> <b>Liquid Pipe Temp Sensor 2 Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 83. 2</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 83</b>
---	---

<b>Detective Actuators:</b>  Liquid pipe temperature thermistor 2	<b>Detective details:</b>  <ul style="list-style-type: none"> <li>• Liquid pipe temperature thermistor 2 short or open detected</li> </ul>
---	--

<b>Forecast of Cause :</b> 1. Connector connection defective, open 2. Thermistor defective 3. Main PCB defective
--

Check Point 1 : Check the connector connection and cable open  <input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check
---



Check Point 2 : Check the thermistor  <input type="checkbox"/> Thermistor characteristics check (Disconnect the thermistor from the PCB and check.) * For the thermistor characteristics, refer to the "Service Parts Information 22".
---



### Check Point 3 : Check voltage of Main PCB (DC5.0V)

**DC**

❑ Main PCB (CN142:3-4) voltage value = 5V

Remove the thermistor from Main PCB, check the voltage.

THERMISTOR (SC.INT.LIQ)

THERMISTOR (SC.EXT.LIQ)

THERMISTOR (SC.INT.GAS)

THERMISTOR (SC.EXT.GAS)

BLACK

BLACK

BLACK

BLACK

BLACK

BLACK

BLACK

BLACK

1 2 3 4 5 6 7 8

1 2 3 4 5 6 7 8

CN142

Liquid pipe temperature sensor 2 (CN142:3-4)


► **If the voltage does not appear, replace Main PCB and set up original address.**  
**(Refer to 06-03 page Main PCB removal.)**

Liquid pipe temperature sensor 2 (CN142:3-4)  
**► If the voltage does not appear, replace Main PCB and set up original address.**  
**(Refer to 06-03 page Main PCB removal.)**

<b>Trouble shooting 38</b> <b>OUTDOOR UNIT Error Method:</b> <b>Current Sensor 1 Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 84. 1</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 84</b>
--	---

<b>Detective Actuators:</b> Judgment from value sensed by current sensor 1 (current sensor for inverter) * Current sensor 1 is mounted on Filter PCB (INV)	<b>Detective details:</b> <ul style="list-style-type: none"> <li>• "Protection stop by "inverter speed <math>\geq 50</math> rps and sensor value 0A continued for 1 min"" was generated 2 times</li> <li>• Sensor value while inverter stopped = maximum was detected</li> </ul>
--	--

<b>Forecast of Cause :</b> <ol style="list-style-type: none"> <li>1. Filter PCB (INV) to Inverter PCB CT system wiring connector disconnection, open</li> <li>2. Power supply to Filter PCB (INV) to Inverter PC wiring disconnection, open</li> <li>3. Filter PCB(INV) defective (Power supply section, current sensor section)</li> <li>4. Inverter PCB defective</li> </ol>
--



<b>Trouble shooting 39</b> <b>OUTDOOR UNIT Error Method:</b> <b>Discharge Pressure Sensor Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 86. 1</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 86</b>
---	---

<b>Detective Actuators:</b> Discharge pressure sensor	<b>Detective details:</b> <ul style="list-style-type: none"> <li>When any of the following conditions is satisfied, a discharge pressure sensor error is generated.             <ol style="list-style-type: none"> <li>30 seconds or more have elapsed since the outdoor unit power was turned on and pressure sensor detected value &lt; 0.3V continued for 30 seconds or more</li> <li>30 seconds or more have elapsed since the outdoor unit power was turned on and pressure sensor detected value <math>\geq</math> 5.0V was detected.</li> </ol> </li> </ul>
--	--



<b>Forecast of Cause :</b> <ol style="list-style-type: none"> <li>Discharge pressure sensor connector disconnection, open</li> <li>Discharge pressure sensor defective</li> <li>Main PCB defective</li> </ol>
---

<b>Check Point 1 : Check the discharge pressure sensor connection state</b>
<input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check



<b>Check Point 2 : Check the discharge pressure sensor</b>
<input type="checkbox"/> Sensor characteristics check * For the characteristics of the discharge pressure sensor, refer to the "Service Parts Information 20".



<b>Check Point 3 : Check voltage of Main PCB (DC5.0V)</b>	<div style="border: 1px solid black; padding: 5px; text-align: center;"> <b>DC</b>   </div>
<input type="checkbox"/> Main PCB (CN118:1-3) voltage value = 5V <u>Remove the thermistor from Main PCB, check the voltage.</u>	
<div style="border: 1px solid black; padding: 10px; text-align: center;">  <p>Discharge pressure sensor (CN118:1-3)</p> </div>	
<p>► <b>If the voltage does not appear, replace Main PCB and set up original address.</b>  <b>(Refer to 06-03 page Main PCB removal.)</b></p>	

<b>Trouble shooting 40</b> <b>OUTDOOR UNIT Error Method:</b> <b>Suction Pressure Sensor Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 86. 3</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 86</b>
---	---

<b>Detective Actuators:</b> Suction pressure sensor	<b>Detective details:</b> <ul style="list-style-type: none"> <li>When any of the following conditions is satisfied, a suction pressure sensor error is generated. <ol style="list-style-type: none"> <li>30 seconds or more have elapsed since the outdoor unit power was turned on and pressure sensor detected value &lt; 0.06V continued for 30 seconds or more.</li> <li>30 seconds or more have elapsed since the outdoor unit power was turned on and pressure sensor detected value <math>\geq</math> 5.0V was detected.</li> </ol> </li> </ul>
--	--

<b>Forecast of Cause :</b> <ol style="list-style-type: none"> <li>Suction pressure sensor connector disconnection, open</li> <li>Suction pressure sensor defective</li> <li>Main PCB defective</li> </ol>
---

Check Point 1 : Check the suction pressure sensor connection state

☐ Connector connection state check  
☐ Cable open check



Check Point 2 : Check the suction pressure sensor


☐ Sensor characteristics check  
\* For the characteristics of the suction pressure sensor, refer to the "Service Parts Information 20".



Check Point 3 : Check voltage of Main PCB (DC5.0V)

☐ Main PCB (CN119:1-3) voltage value = 5V  
Remove the thermistor from Main PCB, check the voltage.

DC

PRESSURE  
SENSOR  
(LOW)

PS

RED

WHITE

BLACK

1

2

3

1

2

3

CN119


Suction pressure sensor (CN119:1-3)

► **If the voltage does not appear, replace Main PCB and set up original address.**  
**(Refer to 06-03 page Main PCB removal.)**

<b>Trouble shooting 41</b> <b>OUTDOOR UNIT Error Method:</b> <b>High Pressure Switch 1 Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 86. 4</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 86</b>
--	---

<b><u>Detective Actuators:</u></b> High pressure switch 1	<b><u>Detective details:</u></b> • When the power was turned on, "high pressure switch 1: open" was detected.
--	--


<b><u>Forecast of Cause :</u></b>	1. High pressure switch 1 connector disconnection, open 2. High pressure switch 1 characteristics defective 3. Main PCB defective
-----------------------------------	---



<b>Trouble shooting 42</b> <b>OUTDOOR UNIT Error Method:</b> <b>High Pressure Switch 2 Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 86. 5</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 86</b>
--	---

<b><u>Detective Actuators:</u></b>  High pressure switch 2	<b><u>Detective details:</u></b>  • When the power was turned on, "high pressure switch 2: open" was detected.
--	--

<b><u>Forecast of Cause :</u></b>	1. High pressure switch 2 connector disconnection, open 2. High pressure switch 2 characteristics defective 3. Main PCB defective
-----------------------------------	---





<b>Trouble shooting 43</b> <b>OUTDOOR UNIT Error Method:</b> <b>Compressor 2 Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 92. 1</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 92</b>
--	---

<b>Detective Actuators:</b> Current sensor 2 (for constant speed compressor)	<b>Detective details:</b> ▪ "Protection stop by "current sensor value $\leq 0.1A$ continued for within 5 hours during compressor ON command"" generated 2 times
---	--

<b>Forecast of Cause :</b>	1. Main PCB to magnetic relay (for constant speed compressor) wiring disconnection, open 2. Compressor power supply system wiring disconnection, open (terminal to magnetic Relay for constant speed compressor) to constant speed compressor) 3. Magnetic Relay (for constant speed compressor) defective 4. Current sensor 2 (current sensor for constant speed compressor) to Main PCB wiring disconnection, open 5. Current sensor 2 (current sensor for constant speed compressor) defective 6. Main PCB defective 7. Compressor 2 defective (winding open, protector operated)
----------------------------	--

<b>Check Point 1 : Check the wiring connection state (main PCB to magnetic Relay (for constant speed compressor))</b>
<input type="checkbox"/> Connector and wiring connection state check <input type="checkbox"/> Cable open check



<b>Check Point 2 : Compressor Power supply system (terminal to magnetic Relay (for constant speed compressor) to constant speed compressor) wiring connection state</b>
<input type="checkbox"/> Wiring connection state check <input type="checkbox"/> Cable open check



<b>Check Point 3 : Check Magnetic Relay (for constant speed compressor)</b>
<input type="checkbox"/> Magnetic relay (for constant speed compressor) operation check (Refer to "Sarvise Parts Information 13")



<b>Check Point 4 : Check the wiring connection state (current sensor 2 (current sensor for constant speed compressor) to Main PCB</b>
<input type="checkbox"/> Connector and wiring connection state check <input type="checkbox"/> Cable open check



<b>Check Point 5 : Check the current sensor 2 (current sensor for constant speed compressor)</b>
<input type="checkbox"/> Current sensor 2 (current sensor for constant speed compressor) check (Refer to "Service Parts Information 7")



<b>Check Point 6 : Main PCB check</b>
<input type="checkbox"/> Chack Main PCB. (Refer to "Sarvise Parts Information 4") <b>&gt;&gt;If replace Main PCB, Refer to 06-03 page Main PCB removal.</b>




<b>Check Point 7 : Replace compressor 2</b>
<input type="checkbox"/> Compressor 2 replacement

<b>Trouble shooting 44</b> <b>OUTDOOR UNIT Error Method:</b> <b>Compressor 2 Current Value Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 92. 2</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 92</b>
--	---

<b>Detective Actuators:</b> Current sensor 2 (for constant speed compressor)	<b>Detective details:</b> ▪ "Protection stop by "current sensor value $\geq 19.5A$ continued for 2 seconds"" generated 2 times within 60 minutes
---	---


<b>Forecast of Cause :</b>	1. Compressor power supply system wiring disconnection, open (terminal to magnetic contactor (for constant speed compressor) to constant speed compressor) 2. Current sensor 2 (current sensor for constant speed compressor) defective 3. Compressor 2 defective (lock, winding short)
----------------------------	---



<b>Trouble shooting 45</b> <b>OUTDOOR UNIT Error Method:</b> <b>Inverter Compressor Start UP Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 93. 1</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 93</b>
--	---

<b>Detective Actuators:</b> Inverter PCB	<b>Detective details:</b> <ul style="list-style-type: none"> <li>▪ "Protection stop by "overcurrent generation at inverter compressor starting" ⇒ restart" generated consecutively 60 times x 2 sets (total 120 times)</li> <li>* The shortest time up to error generation is about 100 minutes</li> <li>* Restart is not performed if an indoor unit in the same refrigerant system is not turned ON by thermostat.</li> <li>* After the end of the 1st set, the 2nd set is not started if all the compressors in the same refrigerant system are not temporarily stopped.</li> </ul>
---	--


<b>Forecast of Cause :</b> <ol style="list-style-type: none"> <li>1. Inverter PCB to inverter compressor wiring disconnection, open</li> <li>2. Inverter PCB defective</li> <li>3. Inverter compressor defective (lock, winding short)</li> </ol>
---



<b>Trouble shooting 46</b> <b><u>OUTDOOR UNIT Error Method:</u></b> <b>Trip Detection</b>	<b><u>Indicate or Display:</u></b> <b>Outdoor Unit : E. 94. 1</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 94</b>
---	--

<b><u>Detective Actuators:</u></b> Inverter PCB	<b><u>Detective details:</u></b> <ul style="list-style-type: none"> <li>▪ "Protection stop by "overcurrent generation after inverter compressor start processing completed"" generated consecutively 5 times.</li> <li>* The number of generations is reset if protection stop is not generated again within 40 seconds after restarting.</li> </ul>
--	---

<b><u>Forecast of Cause :</u></b>	1. Outdoor unit fan operation defective, foreign matter on hear exchanger, excessive rise of ambient temperature 2. Inverter PCB defective 3. Inverter compressor defective (lock, winding short)
-----------------------------------	---



<b>Trouble shooting 47</b> <b><u>OUTDOOR UNIT Error Method:</u></b> <b>Compressor Motor Loss of Synchronization</b>	<b><u>Indicate or Display:</u></b> <b>Outdoor Unit : E. 95. 5</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 95</b>
---	--

<b><u>Detective Actuators:</u></b> Inverter PCB	<b><u>Detective details:</u></b> <ul style="list-style-type: none"> <li>▪ "Protection stop by "loss of synchronization detection"" generated consecutively 5 times</li> <li>* The number of generations is reset if protection stop is not generated again within 40 seconds after restarting.</li> </ul>
--	--

<b><u>Forecast of Cause :</u></b>	1. Inverter PCB defective 2. Inverter compressor defective (lock)
-----------------------------------	--

Check Point 1 : Check the Inverter PCB
<input type="checkbox"/> Inverter PCB check (Refer to Service Parts Information 5)




Check Point 2 : Replace the Inverter compressor
<input type="checkbox"/> Inverter compressor replacement

<b>Trouble shooting 48</b> <b><u>OUTDOOR UNIT Error Method:</u></b> <b>Outdoor Unit Fan Motor Lock Error</b>	<b><u>Indicate or Display:</u></b> <b>Outdoor Unit : E. 97. 1</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 97</b>
--	--

<b><u>Detective Actuators:</u></b> Outdoor unit fan	<b><u>Detective details:</u></b> <ul style="list-style-type: none"> <li>▪ "Protection stop by "fan speed <math>\leq</math> 100rpm" 20 seconds after fan operation command issued" was generated consecutively 5 times</li> <li>* The compressor is protection stopped every time fan protection stop has been generated 3 times.</li> </ul>
--	--


<b><u>Forecast of Cause :</u></b>	1. Rotation obstruction by foreign matter 2. Motor wiring, connector disconnection, open 3. Fan motor defective (winding open, lock) 4. Main PCB defective (drive circuit, speed detection circuit)
-----------------------------------	--



<b>Trouble shooting 49</b> <b><u>OUTDOOR UNIT Error Method:</u></b> <b>Outdoor Unit Fan Motor Undervoltage</b>	<b><u>Indicate or Display:</u></b> <b>Outdoor Unit : E. 97. 4</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 97</b>
--	--

<b><u>Detective Actuators:</u></b>  Outdoor unit main	<b><u>Detective details:</u></b>  ▪ Low DC power supply (DC voltage 180V or less) detected
---	--


<b><u>Forecast of Cause :</u></b> <ol style="list-style-type: none"> <li>1. Power OFF, voltage drop, momentary open</li> <li>2. Power supply wiring connection defective, open</li> <li>3. Main PCB defective (electrolytic capacitor, DC voltage detection circuit)</li> </ol>
---



<b>Trouble shooting 50</b> <b>OUTDOOR UNIT Error Method:</b> <b>Outdoor Unit Fan Motor Temperature Abnormal</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 97. 5</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 97</b>
---	---

<b><u>Detective Actuators:</u></b>  Outdoor unit fan	<b><u>Detective details:</u></b>  • Protection stop by speed $\leq 270\text{rpm}$ after 60 seconds have elapsed after fan operation command issued generated 3 times within 3 hours.
--	--

<b><u>Forecast of Cause :</u></b>	1. Rotation obstructed by foreign matter 2. Ventilation obstructed by heat exchange foreign matter 3. Excessive ambient temperature rise 4. Static pressure setting incorrect, specified static pressure value exceeded 5. Fan motor defective (internal PCB defective)
-----------------------------------	---





<b>Trouble shooting 51</b> <b><u>OUTDOOR UNIT Error Method:</u></b> <b>Slave Unit Error</b>	<b><u>Indicate or Display:</u></b> <b>Outdoor Unit : E. 9U. 2</b> <b>Indoor Unit : No display</b> <b>Error Code : 9U</b>
---	---

<b><u>Detective Actuators:</u></b>  Slave Unit	<b><u>Detective details:</u></b>  <ul style="list-style-type: none"> <li>▪ Error signal received from slave unit of same refrigerant system</li> </ul>
--	--

Check Point 1 : Check the slave unit
<input type="checkbox"/> Slave unit 7 seg display check ⇒ Check by troubleshooting based on displayed error code.

<b>Trouble shooting 52</b> <b>OUTDOOR UNIT Error Method:</b> <b>Discharge Temperture 1 Abnormal</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. A1. 1</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : A1</b>
---	---

<b>Detective Actuators:</b>  Discharge temperature thermistor 1	<b>Detective details:</b>  <ul style="list-style-type: none"> <li>▪ "Protection stop by "discharge temperature1 <math>\geq</math> 110°C during compressor 1 operation"" generated 2 times within 40 minutes</li> </ul>
---	--

<b>Forecast of Cause :</b>	1. 3-way valve not opened 2. EEV defective, strainer clogged 3. Outdoor unit operation defective, foreign matter on heat exchanger 4. Discharge temperature thermistor 1 defective 5. Insufficient refrigerant
----------------------------	--

#### <Cooling operation>

Check Point 1 : Check if 3-way valve(gas side) is open.
<input type="checkbox"/> If the 3-way valve(gas side) was closed, open the 3-way valve(gas side) and check operation.



Check Point 2 : Check the EEV, strainer
<input type="checkbox"/> EEV (EEV2, indoor unit EEV) open? <input type="checkbox"/> Strainer clogging check (before and after EEV, ACM oil return) Refer to "Service Parts Information 14, 16".



Check Point 3 : Check the outdoor unit fan,heat exchanger
<input type="checkbox"/> Check for foreign matter at heat exchanger <input type="checkbox"/> Check if fan can be rotated by hand. <input type="checkbox"/> Motor check



Check Point 4 : Check the discharge thermistor 1
<input type="checkbox"/> Discharger thermistor 1 characteristics check (Check by disconnecting thermistor from PCB.) * For the characteristics of the thermistor, refer to the "Service Parts Information 22".




Check Point 5 : Check the refrigerant amount
<input type="checkbox"/> Leak check

#### <Heating operation>

Check Point 1 : Check if 3-way valve(liquid side) is open.
<input type="checkbox"/> If the 3-way valve(liquid side) was closed, open the 3-way valve(liquid side) and check operation.




Check Point 2 : Check the EEV, strainer
<input type="checkbox"/> EEV (EEV1, EEV2) open? <input type="checkbox"/> Strainer clogging check (before and after EEV, ACM oil return) Refer to "Service Parts Information 15, 16".



<b>Trouble shooting 53</b> <b>OUTDOOR UNIT Error Method:</b> <b>Discharge Temperture 2 Abnormal</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. A2. 1</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : A2</b>
---	---

<b>Detective Actuators:</b>  Discharge temperature thermistor 2	<b>Detective details:</b>  ▪ "Protection stop by "discharge temperature 2 $\geq$ 115°C during compressor 2 operation"" generated 2 times within 40 minutes
---	--

<b>Forecast of Cause :</b>	1. 3-way valve not opened 2. EEV defective, strainer clogged 3. Outdoor unit operation defective, foreign matter on heat exchanger 4. Discharge temperature thermistor 2 defective 5. Insufficient refrigerant
----------------------------	--



<b>Trouble shooting 54</b> <b>OUTDOOR UNIT Error Method:</b> <b>Compressor 1 Temperture Abnormal</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. A3. 1</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : A3</b>
--	---

<b>Detective Actuators:</b>  Compressor temperature thermistor 1	<b>Detective details:</b>  • "Protection stop by "compressor 1 temperture" $\geq 112^{\circ}\text{C}$ during compressor 1 operation" generated 2 times within 40 minutes
--	--

<b>Forecast of Cause :</b>	1. 3-way valve not opened 2. EEV defective, strainer clogged 3. Outdoor unit operation defective, foreign matter on heat exchanger 4. Compressor 1 temperature thermistor defective 5. Insufficient refrigerant
----------------------------	---

#### <Cooling operation>

Check Point 1 : Check if 3-way valve(gas side) is open.
<input type="checkbox"/> If the 3-way valve(gas side) was closed, open the 3-way valve(gas side) and check operation.



Check Point 2 : Check the EEV, strainer
<input type="checkbox"/> EEV (EEV2, indoor unit EEV) open? <input type="checkbox"/> Strainer clogging check (before and after EEV, ACM oil return) Refer to "Service Parts Information 14, 16".



Check Point 3 : Outdoor unit fan, heat exchanger chek
<input type="checkbox"/> Check for foreign matter at heat exchanger <input type="checkbox"/> Check if fan can be rotated by hand. <input type="checkbox"/> Motor check



Check Point 4 : Check the compressor 1 temperature thermistor
<input type="checkbox"/> Compressor 1 temperature thermistor characteristics check (Check by disconnecting thermistor from PCB) * For the characteristics of the thermistor, refer to the "Service Parts Information 22.



Check Point 5 : Check the refrigerant amount
<input type="checkbox"/> Leak check

#### <Heating operation>

Check Point 1 : Check if 3-way valve(liquid side) is open.
<input type="checkbox"/> If the 3-way valve(liquid side) was closed, open the 3-way valve(liquid side) and check operation.



Check Point 2 : Check the EEV, strainer
<input type="checkbox"/> EEV (EEV1, EEV2) open? <input type="checkbox"/> Strainer clogging check (before and after EEV, ACM oil return) Refer to "Service Parts Information 15, 16".



<b>Trouble shooting 55</b> <b>OUTDOOR UNIT Error Method :</b> <b>Compressor 2 Temperture Abnormal</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. A3. 2</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : A3</b>
---	---

<b><u>Detective Actuators:</u></b>  Compressor temperature thermistor 2	<b><u>Detective details:</u></b>  •"Protection stop by "compressor 2 temperture" $\geq 120^{\circ}\text{C}$ during compressor 2 operation" generated 2 times within 40 minutes
---	--

<b><u>Forecast of Cause :</u></b>	1. 3-way valve not opened 2. EEV defective, strainer clogged 3. Outdoor unit operation defective, foreign matter on heat exchanger 4. Compressor temperature thermistor 2 defective 5. Insufficient refrigerant
-----------------------------------	---

#### <Cooling operation>

Check Point 1 : Check if 3-way valve(gas side) is open.
<input type="checkbox"/> If the 3-way valve(gas side) was closed, open the 3-way valve(gas side) and check operation.



Check Point 2 : Check the EEV, strainer
<input type="checkbox"/> EEV (EEV2, indoor unit EEV) open? <input type="checkbox"/> Strainer clogging check (before and after EEV, ACM oil return) Refer to "Service Parts Information 14, 16".



Check Point 3 : Check the outdoor unit fan, heat exchanger
<input type="checkbox"/> Check for foreign matter at heat exchanger <input type="checkbox"/> Check if fan can be rotated by hand. <input type="checkbox"/> Motor check



Check Point 4 : Check the compressor 2 temperature thermistor
<input type="checkbox"/> Compressor 2 temperature thermistor characteristics check (Check by disconnecting thermistor from PCB) * For the characteristics of the thermistor, refer to the "Service Parts Information 22".




Check Point 5 : Check the refrigerant amount
<input type="checkbox"/> Leak check

#### <Heating operation>

Check Point 1 : Check if 3-way valve(liquid side) is open.
<input type="checkbox"/> If the 3-way valve(liquid side) was closed, open the 3-way valve(liquid side) and check operation.



Check Point 2 : Check the EEV, strainer
<input type="checkbox"/> EEV (EEV1, EEV2) open? <input type="checkbox"/> Strainer clogging check (before and after EEV, ACM oil return) Refer to "Service Parts Information 15, 16".



<b>Trouble shooting 56</b> <b>OUTDOOR UNIT Error Method:</b> <b>High Pressure Abnormal</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. A4. 1</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : A4</b>
--	---

<b>Detective Actuators:</b>  Judgment from value sensed by discharge pressure sensor	<b>Detective details:</b>  ▪ "Protection stop by "discharge pressure $\geq$ 4.00MPa during operation of any compressor"" generated 3 times within 60 minutes
--	--

<b>Forecast of Cause :</b>	1. 3-way valve not opened 2. Outdoor unit fan operation defective, foreign matter at heat exchanger, excessive ambient temperature rise 3. Check valve clogged 4. EEV defective, strainer clogged 5. Solenoid valve defective 6. Discharge pressure sensor defective 7. Refrigerant overcharged
----------------------------	---

#### <Cooling operation>

Check Point 1 : Check if 3-way valve(liquid side) is open.
<input type="checkbox"/> If the 3-way valve(liquid side) was closed, open the 3-way valve(liquid side) and check operation.



Check Point 2 : Check the outdoor unit fan operation, heat exchanger, ambient temperature
<input type="checkbox"/> No foreign matter in air passage? <input type="checkbox"/> Heat exchange fins clogged <input type="checkbox"/> Outdoor unit fan motor check <input type="checkbox"/> Ambient temperature not raised by effect of other heat sources? <input type="checkbox"/> Discharged air not sucked in?



Check Point 3 : Check the check valve
<input type="checkbox"/> Check if check valve (parallel with EEV1) not clogged.



Check Point 5 : Check the solenoid valve (SV1, SV2)
<input type="checkbox"/> Solenoid valve operation check Refer to "Service Parts Information 17".



Check Point 6 : Check the discharge pressure sensor
<input type="checkbox"/> Discharge pressure sensor characteristics check * For the characteristics of the discharge pressure sensor, refer to "Service Parts Information 20".




Check Point 7 : Check the refrigerant amount
<input type="checkbox"/> Refrigerant charged amount check

#### <Heating operation>

Check Point 1 : Check if 3-way valve(gas side) is open.
<input type="checkbox"/> If the 3-way valve(gas side) was closed, open the 3-way valve(gas side) and check operation.



Check Point 4 : Check the EEV, strainer (indoor unit)
<input type="checkbox"/> EEV operation check <input type="checkbox"/> Check of strainers before and after EEV Refer to "Service Parts Information 14, 15, 16".



<b>Trouble shooting 57</b> <b><u>OUTDOOR UNIT Error Method:</u></b> <b>High Pressure Protection 1</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. A4. 2</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : A4</b>
---	---

<b><u>Detective Actuators:</u></b>  High pressure switch 1	<b><u>Detective details:</u></b>  ▪ "Protection stop by "high pressure switch 1 operated during compressor 1 operation"" generated 3 times within 60 minutes
--	--

<b><u>Forecast of Cause :</u></b>	1. 3-way valve not opened 2. Outdoor unit fan operation defective, foreign matter at heat exchanger, excessive ambient temperature rise 3. Check valve clogged 4. EEV defective, strainer clogged 5. Solenoid valve defective 6. High pressure switch 1 defective 7. Refrigerant overcharged
-----------------------------------	--

<Cooling operation>

Check Point 1 : Check if 3-way valve(liquid side) is open.  <input type="checkbox"/> If the 3-way valve(liquid side) was closed, open the 3-way valve(liquid side) and check operation.
---



Check Point 2 : Check the outdoor unit fan operation, heat exchanger, ambient temperature  <input type="checkbox"/> No foreign matter in air passage? <input type="checkbox"/> Heat exchange fins clogged <input type="checkbox"/> Outdoor unit fan motor check <input type="checkbox"/> Ambient temperature not raised by effect of other heat sources? <input type="checkbox"/> Discharged air not sucked in?
---



Check Point 3-1 : Check the check valve  <input type="checkbox"/> Check if check valve (parallel with EEV1) not clogged.
--



Check Point 3-2 : Check the check valve  <input type="checkbox"/> Check if check valve (oilseparator (out) of compressor 1) is not clogged.
---



Check Point 5 : Check the solenoid valve (SV1, SV2)  <input type="checkbox"/> Solenoid valve operation check Refer to "Service Parts Information 17".
--



Check Point 6 : Check high pressure switch 1  <input type="checkbox"/> High pressure switch 1 characteristics check * For the characteristics of the high pressure switch 1, refer to "Service Parts Information 21".
--




Check Point 7 : Check the refrigerant amount  <input type="checkbox"/> Refrigerant charged amount check
---

<Heating operation>

Check Point 1 : Check if 3-way valve(gas side) is open.  <input type="checkbox"/> If the 3-way valve(gas side) was closed, open the 3-way valve(gas side) and check operation.
--



Check Point 4 : Check the EEV, strainer (indoor unit)  <input type="checkbox"/> EEV operation check <input type="checkbox"/> Check of strainers before and after EEV Refer to "Service Parts Information 14, 15, 16".
---



<b>Trouble shooting 58</b> <b>OUTDOOR UNIT Error Method:</b> <b>High Pressure Protection 2</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. A4. 3</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : A4</b>
--	---

<b>Detective Actuators:</b>  High pressure switch 2	<b>Detective details:</b>  ▪ "Protection stop by "high pressure switch 2 operated during compressor 2 operation"" generated 3 times within 60 minutes
---	---

<b>Forecast of Cause :</b>	1. 3-way valve not opened 2. Outdoor unit fan operation defective, foreign matter at heat exchanger, excessive ambient temperature rise 3. Check valve clogged 4. EEV defective, strainer clogged 5. Solenoid valve defective 6. High pressure switch 2 defective 7. Refrigerant overcharged
----------------------------	--

#### <Cooling operation>

Check Point 1 : Check if 3-way valve(liquid side) is open.
<input type="checkbox"/> If the 3-way valve(liquid side) was closed, open the 3-way valve(liquid side) and check operation.



Check Point 2 : Check the outdoor unit fan operation, heat exchanger, ambient temperature
<input type="checkbox"/> No foreign matter in air passage? <input type="checkbox"/> Heat exchange fins clogged <input type="checkbox"/> Outdoor unit fan motor check <input type="checkbox"/> Ambient temperature not raised by effect of other heat sources? <input type="checkbox"/> Discharged air not sucked in?



Check Point 3-1 : Check valve check
<input type="checkbox"/> Check if check valve (parallel with EEV1) not clogged.



Check Point 3-2 : Check valve check
<input type="checkbox"/> Check if check valve (oilseparator (out) of compressor 2) is not clogged.



Check Point 5 : Solenoid valve (SV1, SV2) check
<input type="checkbox"/> Solenoid valve operation check Refer to "Service Parts Information 17".



Check Point 6 : High pressure switch 2 check
<input type="checkbox"/> High pressure switch 2 characteristics check * For the characteristics of the high pressure switch 2, refer to the "Service Parts Information 21".




Check Point 7 : Refrigerant amount check
<input type="checkbox"/> Refrigerant charged amount check

#### <Heating operation>

Check Point 1 : Check if 3-way valve(gas side) is open.
<input type="checkbox"/> If the 3-way valve(gas side) was closed, open the 3-way valve(gas side) and check operation.



Check Point 4 : Check the EEV, strainer (indoorunit)
<input type="checkbox"/> EEV operation check <input type="checkbox"/> Check of strainers before and after EEV Refer to "Service Parts Information 14, 15, 16".





<b>Trouble shooting 59</b> <b>OUTDOOR UNIT Error Method:</b> <b>Low Pressure Abnormal</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. A5. 1</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : A5</b>
---	---

<b>Detective Actuators:</b> Suction pressure sensor	<b>Detective details:</b> <ul style="list-style-type: none"> <li>"Protection stop by "suction pressure <math>\leq 0.10\text{MPa}</math> continued for 10 minutes" or "suction pressure <math>\leq 0.05\text{MPa}</math>" during operation of any compressor"" was generated 5 times within 3 hours</li> </ul>
--	---

<b>Forecast of Cause :</b>	1. 3-way valve not opened 2. Outdoor unit ambient temperature too low 3. Outdoor unit fan operation defective, foreign matter at heat exchanger 4. EEV defective, strainer clogged 5. Solenoid valve defective 6. Low pressure sensor characteristics defective 7. Insufficient refrigerant
----------------------------	--

#### <Cooling operation>

Check Point 1 : Check if 3-way valve(gas side) is open.
<input type="checkbox"/> If the 3-way valve(gas side) was closed, open the 3-way valve(gas side) and check operation.



Check Point 4 : Check the indoor unit EEV, strainer clogging
<input type="checkbox"/> Indoor unit EEV operation check <input type="checkbox"/> Strainer not clogged?



Check Point 5 : Check the solenoid valve (SV1)
<input type="checkbox"/> Solenoid valve operation check Refer to "Service Parts Information 17".



Check Point 6 : Check the suction pressure sensor
<input type="checkbox"/> Suction pressure sensor characteristics check * For the characteristics of the suction pressure sensor, refer to "Service Parts Information 20".



Check Point 7 : Check the refrigerant amount
<input type="checkbox"/> Leak check

#### <Heating operation>

Check Point 1 : Check if 3-way valve(liquid side) is open.
<input type="checkbox"/> If the 3-way valve(liquid side) was closed, open the 3-way valve(liquid side) and check operation.



Check Point 2 : Check the outdoor unit ambient temperature
<input type="checkbox"/> Outdoor ambient temperature lower than operating range?



Check Point 3 : Check the outdoor unit fan operation, heat exchanger
<input type="checkbox"/> No foreign matter in air passage? <input type="checkbox"/> Heat exchange fins clogged <input type="checkbox"/> Fan rotates? <input type="checkbox"/> Outdoor unit fan motor check



Check Point 4 : Check the outdoor unit EEV, strainer clogging
<input type="checkbox"/> Outdoor unit EEV1 operation check <input type="checkbox"/> Strainer not clogged? Refer to "Service Parts Information 15".



<b>Trouble shooting 60</b> <b>OUTDOOR UNIT Error Method:</b> <b>Heat Sink Temperature Abnormal</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. AC. 4</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : AC</b>
--	---

<b>Detective Actuators:</b>  Heat sink thermistor	<b>Detective details:</b>  <ul style="list-style-type: none"> <li>"Protection stop by "heat sink temperature <math>\geq 88^{\circ}\text{C}</math>" generated 3 times within 60 minutes</li> </ul>
---	---

<b>Forecast of Cause :</b>	1. Foreign matter on heat sink, heat sink dirty 2. Foreign matter on heat exchanger, excessive ambient temperature rise 3. Heat sink thermistor defective
----------------------------	---

Check Point 1 : Check the heat sink state
<input type="checkbox"/> Heat sink foreign matter, soiling check



Check Point 2 : Check the foreign matter and ambient temperature of heat exchanger
<input type="checkbox"/> Heat exchange foreign matter check <input type="checkbox"/> Ambient temperature not raised by effect of other heat sources? <input type="checkbox"/> Discharged air not sucked in?



Check Point 3 : Check the heat sink thermistor
<input type="checkbox"/> Heat sink thermistor characteristics check (Check by disconnecting thermistor from PCB.) * For the characteristics of the thermistor, refer to "Service Parts Information 22".

<b>Trouble shooting 61</b> <b>UTDOOR UNIT Error Method:</b> <b>Auto Address Setting Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 28. 1</b> <b>Indoor Unit : No Display</b> <b>Error Code : 28</b>
---	--

<b>Detective Actuators:</b> Outdoor unit Main PCB	<b>Detective details:</b> • When none of the connected indoor units answers during auto address And when abnormal answer signal is input.
--	---

<b>Forecast of Cause :</b>	1. Indoor unit power supply defective 2 Indoor unit overconnected 3.Communication line incorrect connection 4. Noise, momentary open
----------------------------	---

Check Point 1 : Check the indoor unit power supply
<input type="checkbox"/> Check the indoor unit power supply
↓ <b>OK</b>
Check Point 2 : Check the indoor unit number connection
<input type="checkbox"/> Check if more than 64 indoor units are connected in a refrigerant circuit
↓ <b>OK</b>
Check Point 3 : Check the communication line connection
Check if communication line is correctly connected
<input type="checkbox"/> Is it uncoupled or cut halfway ?
<input type="checkbox"/> Connecting terminal position is correct as the installation manual shows ?
↓ <b>OK</b>
Check Point 4 : Check noise, momentary open, voltage drop
<input type="checkbox"/> Check if power supply temporarily stops by outages or if strong noise is generated from surrounding environment during auto address

<b>Trouble shooting 62</b> <b>UTDOOR UNIT Error Method:</b> <b>Signal Amplifier Auto Address Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 28. 4</b> <b>Indoor Unit : No Display</b> <b>Error Code : 28</b>
--	--

<b>Detective Actuators:</b> Outdoor unit Main PCB	<b>Detective details:</b> • When abnormal answer signal is input during signal amplifier auto address
--	--

<b>Forecast of Cause :</b>	1. Signal amplifier power supply defective 2. Signal amplifier overconnected 3. Signal amplifier auto address wrong setting 4. Noise, momentary open.
----------------------------	--

Check Point 1 : Check signal amplifier unit power supply
<input type="checkbox"/> Check signal amplifier unit power supply
↓ <b>OK</b>
Check Point 2 : Check the signal amplifier number connection
<input type="checkbox"/> Check if more than 8 signal amplifiers are connected in a network
↓ <b>OK</b>
Check Point 3 : Check the operation of signal amplifier auto address setting
<input type="checkbox"/> Check if signal amplifier auto address is set at the same time from multiple outdoor units (master unit)
↓ <b>OK</b>
Check Point 4 : Check noise, momentary open, voltage drop
<input type="checkbox"/> Check if power supply temporarily stops by outages or if strong noise is generated from surrounding environment during signal amplifier auto address


## TROUBLE SHOOTING WITH NO ERROR CODE

### Trouble shooting 63

#### Indoor Unit - No Power

#### Forecast of Cause :

1. Power Supply failure 2. Outside cause 3. Electrical Component defective



## Trouble shooting 64

### Outdoor Unit - No Power

#### Forecast of Cause :

1. Power Supply failure 2. Outside cause 3. Electrical Components defective

#### Check Point 1 : Check Installation Condition

- ☐ Isn't the breaker down?
- ☐ Check loose or removed connection cable.
- >>If abnormal condition is found, correct it by referring to Installation Manual or Data & Technical Manual.**

OK

#### Check Point 2 : Check Outside Cause such as Voltage drop or Noise

- Instant drop ----- Check if there is a large load electric apparatus in the same circuit.
  - Momentary power failure ----- Check if there is a defective contact or leak current in the power supply circuit.
  - Noise ----- Check if there is any equipment causing harmonic wave near electric line (Neon bulb or electric equipment that may cause harmonic wave).
- Check the complete insulation of grounding.

OK

#### Check Point 3 : Check Electrical Components



- ☐ Check the voltage of power supply.
- >> Check if AC380V appears at Outdoor Unit Terminal R-S, S-T, T-R, and AC220V at R-N, S-N, T-N.**

NO

OK

- ☐ Check the fuse on the Filter PCB(Main).

OK

NG

- ☐ Replace the fuse.
  - ☐ Recheck if the power supply terminals section is shorted.
- (Note) Always check in the power off state.

OK

NG

- ☐ Disconnect connecting cable of the Filter PCB(Main) and Main PCB and recheck.
- if the power supply terminals section is not shorted.
- (Note) Always check in the power off state.

OK

NG

- ☐ Replace the Main PCB.
- (Refer to 06-03 page Main PCB removal.)

NG

- ☐ Replace the Filter PCB(Main).

NG

- ☐ If the symptom does not change, Check voltage of "CN125 pins 1-3" on the Main PCB. (DC 5V)

OK

NG

- ☐ For 8HP and 10HP models, advance to [OK] without checking.
  - ☐ For 12HP, 14HP and 16HP models, disconnect connecting cable of the PWB Unit(CT) and Main PCB and recheck.
- Recheck voltage of "CN125 pins 1-3" on the Main PCB. (DC 5V)

OK

NG

- ☐ Replace the Pressure sensor

OK

- ☐ Replace the PWB Unit (CT)

NG

- If the symptom does not change by above Check 3, replace Main PCB or Filter PCB (Main).**
- >>If replace Main PCB, Refer to 06-03 page Main PCB removal.**

## Trouble shooting 65

### No Operation (Power is ON)

#### Forecast of Cause :

1. Setting/Connection failure
2. Outside cause
3. Electrical Component defective

#### Check Point 1 : Check indoor and outdoor installation condition

- ❑ Indoor Unit - Check incorrect wiring between Indoor Unit- Remote Control, or terminals between Indoor Units.  
Or, check if there is an open cable connection.
  - ❑ Check address setting (Are all the address of Indoor and Outdoor correct?)
  - ❑ Are these Indoor Unit, Outdoor Unit, and Remote Control suitable model numbers to connect?
- >> If there is some abnormal condition, correct it by referring to Installation manual and Data & Technical Manual.**



OK

Turn off Power and check/correct followings.

- ❑ Isn't Communication PCB of Indoor Unit removed?
- ❑ Is there loose or removed communication line of Indoor Unit and Outdoor Unit?
- ❑ Check Terminator (DIP-SW SET 5) is installed on Outdoor Main PCB.
- ❑ Check loose or removed communication line between each Outdoor Unit.
- ❑ Check loose Communication PCB of each Outdoor Unit.



OK

#### Check Point 2 : Check outside cause at Indoor and Outdoor (Voltage drop or Noise)

- Instant drop -----Check if there is a large load electric apparatus in the same circuit.
- Momentary power failure ----- Check if there is a defective contact or leak current in the power supply circuit.
- Noise ----- Check if there is any equipment causing harmonic wave near electric line (Neon bulb or electric equipment that may cause harmonic wave).  
Check the complete insulation of grounding.



OK

#### Check Point 3 : Check Electrical Components at Indoor and Outdoor



- ❑ Indoor Unit - Check the voltage between pins 1-3 of the connector (on the control PCB) for connection with the remote controller.  
**>> If it is DC12V, Remote Control is defective (Controller PCB is normal) >> Replace Remote Control**  
**>> If it is DC 0V, Controller PCB is defective (Check Remote Control once again) >> Replace Controller PCB**
- ❑ If some of Indoor unit does not operate, replace the Communication PCB of the non-operative Indoor Unit.  
**>> If the symptom does not change, replace Controller PCB of Indoor Unit.**
- ❑ If all of Indoor Units do not operate, check the connection between Main PCB and Communication PCB of Outdoor Unit (Main Unit).  
**>> If the symptom does not change, replace Communication PCB of Outdoor Unit (Main Unit).**  
**(If it did not work, replace Main PCB.)**

## Trouble shooting 66

### No Cooling

#### Forecast of Cause :

1. Indoor Unit error
2. Outdoor Unit error
3. Effect by Surrounding environment
4. Connection Pipe / Connection Wire failure
5. Refrigeration cycle failure

#### Check Point 1 : Check Indoor Unit

- ☐ Does Indoor Unit FAN run on HIGH FAN?
- ☐ Is Air Filter dirty?
- ☐ Is Heat Exchanger clogged?



#### Check Point 2 : Check Outdoor Unit Operation

- ☐ Check if Outdoor Unit is operating
- ☐ Check any objects that obstruct the air flow route.
- ☐ Check clogged Heat Exchanger.
- ☐ Is the pipe length setting (Push Switch "MODE/EXIT", "SELECT", "ENTER") suitable?
- ☐ Is the Valve open?



#### Check Point 3 : Check Site Condition

- ☐ Is capacity of Indoor Unit fitted to Room size?
- ☐ Any windows open? Or direct sunlight ?




#### Check Point 4 : Check Indoor/Outdoor Installation Condition

- ☐ Check connection pipe (specified pipe length & Pipe diameter?)
  - ☐ Check any loose or removed communication line.
- >> If there is an abnormal condition, correct it by referring to Installation Manual or Data & Technical Manual.**





#### Check Point 5 : Check Refrigeration Cycle

- ☐ Check if Strainer is clogged (Refer to the figure at right).
  - ☐ Measure Gas Pressure and if there is a leakage, correct it.
- >> When recharging the refrigerant, make sure to perform vacuuming, and recharge the specified amount.**
- ▶ Check EEV (Service Parts Information 15, 16)
  - ▶ Check Solenoid Valve (Service Parts Information 17)
  - ▶ Check Compressor (Service Parts Information 2,3)



#### Attention!!

Strainer normally does not have temperature difference between inlet and outlet as shown in (1), but if there is a difference like shown in (2), there is a possibility of inside clogged. In this case, replace Strainer.



## Trouble shooting 67

### Abnormal Noise

#### Forecast of Cause :

1. Abnormal installation (Indoor/Outdoor) 2. Fan failure(Indoor/Outdoor)
3. EEV failure (Indoor) 4. Compressor failure (Outdoor)

#### Diagnosis method when Abnormal Noise is occurred

Abnormal noise is coming from Indoor Unit  
(Check and correct followings)

- ☐ Is Main Unit installed in stable condition?
- ☐ Is the installation of Air suction grille and front panel normal?
- ☐ In case of Duct type : Is Static Pressure range normal?  
(Refer to Data & Technical Manual)

OK

- ☐ Is Fan broken or deformed?
- ☐ Is the screw of Fan loose?
- ☐ Is there any object which obstruct the Fan rotation?

#### Attention!!

If Refrigerant Noise is occurring, Check if the Indoor and Outdoor Thermistor is wrongly installed. Check and correct the thermistor.

Abnormal noise is coming from Outdoor Unit  
(Check and correct followings)

- ☐ Is Main Unit installed in stable condition?
- ☐ Is Bell Mouth installed normally?

OK

- ☐ Is Fan broken or deformed?
- ☐ Is the screw of Fan loose?
- ☐ Is there any object which obstruct the Fan rotation?

OK

- ☐ Check if vibration noise by loose bolt or contact noise of piping is happening.

OK

- ☐ Is Compressor locked?  
>> Check Compressor (Service Parts Information 2,3)

## Trouble shooting 68

### Water Leaking

#### Forecast of Cause :

1. Erroneous installation 2. Drain hose failure 3. Float Switch failure

#### Diagnosis method when water leak occurs

- ☐ Is Main Unit installed in stable condition?
- ☐ Is Main Unit broken or deformed at the time of transportation or maintenance?

OK

- ☐ Is Drain Hose connection loose?
- ☐ Is there a trap in Drain Hose?
- ☐ Is Drain Hose clogged?

OK

- ☐ Is Fan rotating?  
>> Check Fan Motor (Service Parts Information 19)

OK


- ☐ Is Float Switch defective?  
>> Check Float Switch (Refer to Trouble Shooting 7)

#### Diagnosis method when water is spitting out

- ☐ Is the filter clogged?

OK

- ☐ Check Gas Pressure and correct it if there was a gas leak.



#### Attention!!

If water is leaking from the Indoor Unit that is not in operation, there is a possibility of Indoor EEV is not closed.

=> Check EEV (Service Parts Information 14)



### 4-3-3 Trouble Shooting for Optional Parts

#### 1. External Switch Controller (UTY-TEKX)

##### Trouble shooting 69

**Error Contents :**  
**Power Supply Error**

**Symptom :**  
**No operation & LED does not light up.**

**Condition :**

1. No power supply.  
Voltage error between red and black terminals of External Switch Controller. (Normal voltage: 12V plus minus 10%)
2. Electric circuit error.  
Voltage is normal between red and black terminals of External Switch Controller (Normal voltage: 12V plus minus 10%)

Cause 1 : Indoor unit defective

- ❑ Refer to Indoor unit trouble shooting.



Cause 2 : Connection cable is defective or open.

- ❑ Check installation of connection cable.
- ❑ Check if connection cable is open.

OK

Cause 3 : Defective insertion or open connection of the cable between External Switch Controller terminal and PCB.

- ❑ Check connector insertion.
- ❑ Check if connection cable is open.



Cause 4 : Ext. Switch Controller is defective.

► **Replace External Switch Controller.**

##### Trouble shooting 70

**Error Contents :**  
**The abnormality in connection of remote controller cable**

**Symptom :**  
**LED repeats flashing 0.5sec ON & 0.5sec OFF.**

**Condition :**

Communication with Indoor unit has been cut off for longer than 1 minute.

Cause 1 :  
Communication cable is defective or open.

- ❑ Check installation of connection cable.
- ❑ Check if connection cable is open.



Cause 2 : Defective insertion or open connection of the cable between External Switch Controller terminal and PCB.

- ❑ Check connector insertion.
- ❑ Check if connection cable is open.



Cause 3 : DIP switch setting defective

- ❑ Check setting of DIP-SW1-4, 1-5, 1-6.

OK

Cause 4 : External noise

- ❑ Remove or shut out external noise source.



Cause 5 : Ext. Switch Controller is defective.

► **Replace External Switch Controller.**

## Trouble shooting 71

**Error Contents :**  
Transmission Error

**Symptom :**  
LED repeats flashing 0.5sec ON & 1.0sec OFF.

**Condition :**

Normal communication with Indoor unit has been suspended for longer than 1 minute.

Cause 1 : DIP switch setting defective

- Check setting of DIP-SW1-4, 1-5, 1-6.



Cause 2 : External noise

- Remove or shut out external noise source.

OK

Cause 3 : Ext. Switch Controller is defective.

- ▶ **Replace External Switch Controller.**

## Trouble shooting 72

**Error Contents :**  
Switch Operation Error

**Symptom :**  
LED is lighting but Switch (SW1 or SW2) does not operate.

**Condition :**

Switch input can not be detected.

Cause 1 : Connection cable is defective or open.

- Check installation of connection cable.
- Check if connection cable is open.



Cause 2 : Defective insertion or open connection of the cable between External Switch Controller terminal and PCB.

- Check connector insertion.
- Check if connection cable is open.



Cause 3 : DIP switch setting defective

- Check DIP Switch setting.

OK

Cause 4 : External Switch is defective

- Check any short or switch operation failure.
- Check resistance value between the terminals, at the time of input.
- ▶ **OPEN** : More than 50 kΩ
- ▶ **SHORT** : Less than 1 kΩ



Cause 5 : Ext. Switch Controller is defective.

- ▶ **Replace External Switch Controller.**

## 2. Signal Amplifier (UTY-VSGX)

### Trouble shooting 73

**Error Contents :**  
**Power Supply Error**

**Symptom :**  
**No display**

**Details :**

Condition of occurrence : Normal power is not supplied. 7 segment indicator is defective.


Release condition : Normal power is supplied. 7 segment indicator is normal.

**Cause 1 :**

Power supply cable installation is defective or open.

- ❑ Check following installation and reset the power supply.
- (1) Installation of power cable on power supply terminal.
- (2) Connection between Power PCB and Terminal.
- (3) Connector condition between power PCB and Main PCB.

OK



**Cause 2 : Signal Amplifier is defective.**

If normal voltage (220V) is applied to power supply terminal of Signal Amplifier, there is a possibility of defective PCB. Proceed as follows.

► **Replace Signal Amplifier.**

### Trouble shooting 74

**Error Contents :**  
**Communication Error**

**Symptom :**  
**Error code does not appear [ \_ ]**  
**Communication error occurs at connected equipment side.**

**Details :**

Condition of occurrence : Network cable defective. External noise is applied.

Overlapping of Signal Amplifier address setting. System design mistake.

Release condition : Network cable is connected. External noise is removed.

Overlapping of Signal Amplifier has been corrected. System design is normal.

**Cause 1 :**

Network cable installation is defective or open.

- ❑ Check Network cable installation.

OK

**Cause 2 : External noise**

- ❑ Remove external noise around Signal Amplifier or Network cable. (Keep enough distance)

OK

**Cause 3 :**

Overlapped address of Signal Amplifier.

- ❑ Set up address again which does not overlap on system. After set up again, reset the power supply.

OK

**Cause 4 : System Design mistake**

- ❑ Check following items.(Refer to Installation Manual)
- (1) Installation location of Terminal Resistor.  
(Only 1 location on NS\*)
- (2) Cable length. (Within 500m maximum on NS\*)
- (3) Number of units connected  
(Up to 64 units maximum on NS\*)
- (4) Communication cable specification.  
(Use specified type.)
- (5) Number of Signal Amplifier installed.  
(Up to 8 units max. on system)
- (6) Network cable shall not be connected in loop.

\*NS : Network Segment

## Trouble shooting 75

**Error Contents :**  
**Address Setting Error**

**Symptom :**  
**Error display [ 2 6 ]**  
**No operation.**

### Details :

Condition of occurrence : Address is not set at Signal Amplifier.

Release condition : Address setting mode is started up, and desired address has been set up.

#### Cause 1 : External noise

□ Upon pressing RESET button (SW7) or turning on power, proceed as follows.

- (1) If error did not appear, it is not a defect of PCB.  
Remove the surrounding noise source.
- (2) If error occurs again, check followings other than removing surrounding noise source.

OK

#### Cause 2 : Address is not set at Signal Amplifier.

□ Set up address again.  
After set up again, reset the power supply.

OK

#### Cause 3 : Signal Amplifier is defective.

► Replace Signal Amplifier.

## Trouble shooting 76

**Error Contents :**  
**Parallel Communication**

**Symptom :**  
**Error display [ C 1 ]**  
**No operation.**

### Details :

Condition of occurrence : Communication error between CPU and Network Driver IC

Release condition : Communication is normal between CPU and Network Driver IC

#### Cause 1 : External noise

□ Upon pressing RESET button (SW7) or turning on power, proceed as follows.

- (1) If error did not appear, it is not a defect of PCB. Remove the surrounding noise source.
- (2) If error occurs again, check followings other than removing surrounding noise source.

OK

#### Cause 2 : Signal Amplifier is defective.

► Replace Signal Amplifier.

### Trouble shooting 77

**Error Contents :**  
**Communication Error B**

**Symptom :**  
**Error display [ D9 (Flashing or Lighting) ]**  
**No operation.**

**Details :**

Condition of occurrence : Communication error between CPU and Network Driver IC (CH\_B side).

Network Driver IC is defective.

Release condition : Communication is normal between CPU and Network Driver IC (CH\_B side).

Network Driver IC operation is normal.

**Cause 1 : External noise**

- Upon pressing RESET button (SW7) or turning on power, proceed as follows.
- (1) If error did not appear, it is not a defect of PCB. Remove the surrounding noise source.
- (2) If error occurs again, check followings other than removing surrounding noise source.

**OK**

**Cause 2 :Signal Amplifier is defective.**

► **Replace Signal Amplifier.**

### Trouble shooting 78

**Error Contents :**  
**Communication Error A**

**Symptom :**  
**Error display [ D14 (Flashing or Lighting) ]**  
**No operation.**

**Details :**

Condition of occurrence : Communication error between CPU and Network Driver IC (CH\_A side).

Network Driver IC is defective.

Release condition : Communication is normal between CPU and Network Driver IC (CH\_A side).

Network Driver IC operation is normal.

**Cause 1 : External noise**

- Upon pressing RESET button (SW7) or turning on power, proceed as follows.
- (1) If error did not appear, it is not a defect of PCB. Remove the surrounding noise source.
- (2) If error occurs again, check followings other than removing surrounding noise source.

**OK**

**Cause 2 : Signal Amplifier is defective.**

► **Replace Signal Amplifier.**

### 3. Network Convertor (UTY-VGGX)

#### 1. When connecting a group remote controller to a network convertor

##### Trouble shooting 79

**Error Contents :**  
**Power Supply Error**

**Symptom :**  
**No display**


**Details :**

Condition of occurrence : Normal power is not supplied. 7 segment indicator is defective.  
Release condition : Normal power is supplied. 7 segment indicator is normal.

**Cause 1 :**  
Power supply cable installation is defective or open.

- Check following installation and reset the power supply.
- (1) Installation of power cable on power supply terminal.
- (2) Connection between Power PCB and Terminal.
- (3) Connector condition between power PCB and Main PCB.

OK



**Cause 2 : Network Convertor is defective.**

If normal voltage (220V) is applied to power supply terminal of Network Convertor, there is a possibility of defective PCB. Proceed as follows.

► **Replace Network Convertor.**

##### Trouble shooting 80

**Error Contents :**  
**PCB Error 1**

**Symptom :**  
**Error Code display [ C 1 ]**  
**All the control items do not operate.**

**Details :**

Condition of occurrence : Synchronization of Network Device was not normally done.  
Release condition : When the synchronization of the device is normally done.

**Cause 1 : External noise**

- After pressing SW104 of Network Convertor PCB for 5 seconds or turning on power.  
Does error code display reappear?

YES

- Remove the surrounding noise source.

NO

- It is not a defect of PCB. Remove the surrounding noise source.

OK

**Cause 2 : Network Convertor is defective.**

► **Replace Network Convertor.**

## Trouble shooting 81

### Error Contents :

**Communication Error  
with Group Remote Controller**

### Symptom :

**Error Code display [ 1 2 ] Control/Display from Group Remote is  
not available.**

### Details :

Condition of occurrence : The communication between Group Remote and Network Convertor was not normally performed.  
Release condition : When the communication between Group Remote and Network Convertor resumes normal operation.

#### Cause 1 : External noise

- ☐ After pressing SW104 of Network Convertor PCB for 5 seconds or turning on power.  
Does error code display reappear?

**YES**

- Remove the surrounding noise source.

**OK**

**NO**

- It is not a defect of PCB. Remove the surrounding noise source.

#### Cause 2 :

**Defective or open connection of cable wire between Network Convertor and Connected Remote Controller.**

After the following are checked, the power supply is reset.

- ☐ Check connection cable wire between Network Convertor and Connected Remote Controller.
- ☐ Check connection between Control PCB and Terminal.

**OK**

#### Cause 3 : Incorrect setting of Network Convertor's DIP-SW103[1 to 4] (For Convertor setting of Group Remote Controller)

- ☐ Check Network Convertor PCB DIP-SW103[1 to 4] ON.

**OK**

#### Cause 4 : Defective Remote Controller or Network Convertor.

- **Replace Remote Controller or Network Convertor.**

## Trouble shooting 82

### Error Contents : Software Error

**Symptom :**  
**Error Code display [ C A ]**  
**All the control items do not operate.**  
**Other Controls are left they are.**

### Details :

Condition of occurrence : Micon program performed an abnormal control.  
Error of inside information of EEPROM.  
initial setting of Network Converter PCB was not normally performed.

Release condition : Micon has been reset, and the control of Network Converter became normal.  
When error disappeared and Network Converter becomes available to control.

### Cause 1 : External noise

- ☐ Check continuation of error.  
(1) If error is released automatically, it is not a defect of PCB. Remove the surrounding noise source around Network Converter.  
(2) If error is not released automatically, check followings.

↓ OK

- ☐ After pressing SW104 of Network Converter PCB for 5 seconds or turning on power.  
Does error code display reappear?

↓ YES

- Remove the surrounding noise source.

↓ OK

↓ NO

- It is not a defect of PCB. Remove the surrounding noise source.

### Cause 2 : Network Converter is defective.

► **Replace Network Converter.**

## Trouble shooting 83

### Error Contents : Refrigerant circuit address setting error

**Symptom :**  
**Error Code display [ 2 6 ]**

### Details :

Condition of occurrence : Indoor unit registration is 3 refrigerant circuits or more.  
Release condition : Indoor unit registration is 2 refrigerant circuits or more.

### Cause 1 : Check of number of indoor unit registration refrigerant circuits

- ☐ Check indoor unit registration.  
(1) Number of refrigerant circuits of indoor unit registered at Replace Group Remote Controller is 3 refrigerant circuits or more even though connected to one converter.

↓ YES

- ☐ Make 2 refrigerant circuits or less  
and wait 2 minutes

↓ NO

- ☐ Replace Network Converter  
Replace Group Remote Controller



### 3. Network Convertor (UTY-VGGX)

#### 2. When connecting a single split type indoor unit to a network convertor

##### Trouble shooting 84

**Error Contents :**  
**Power Supply Error**

**Symptom :**  
**No display**

**Details :**

Condition of occurrence : Normal power is not supplied. 7 segment indicator is defective.  
Release condition : Normal power is supplied. 7 segment indicator is normal.


**Cause 1 :**  
Power supply cable installation is defective or open.

- Check following installation and reset the power supply.
- (1) Installation of power cable on power supply terminal.
- (2) Connection between Power PCB and Terminal.
- (3) Connector condition between power PCB and Main PCB.

OK

**Cause 2 : Network Convertor is defective.**

If normal voltage (220V) is applied to power supply terminal of Network Convertor, there is a possibility of defective PCB. Proceed as follows.  
► **Replace Network Convertor.**



##### Trouble shooting 85

**Error Contents :**  
**PCB Error 1**

**Symptom :**  
**Error Code display [ C 1 ]**  
**All the control items do not operate.**

**Details :**

Condition of occurrence : Synchronization of Network Device was not normally done.  
Release condition : When the synchronization of the device is normally done.

**Cause 1 : External noise**

- After pressing SW104 of Network Convertor PCB for 5 seconds or turning on power.  
Does error code display reappear?

YES

- Remove the surrounding noise source.

NO

- It is not a defect of PCB. Remove the surrounding noise source.

OK

**Cause 2 : Network Convertor is defective.**

► **Replace Network Convertor.**

## Trouble shooting 86

### Error Contents :

**Communication Error  
with Standard Remote Controller**

### Symptom :

**Error Code display [ 1 2 ] Control/Display from Standard Remote s  
not available. Other controls are left as they are.**

### Details :

Condition of occurrence : The communication between Standard Remote Controller and Network Converter was not normally performed.

Release condition : When the communication between Standard Remote Controller and Network Converter resumes normal operation.

#### Cause 1 : External noise

- ☐ After pressing SW104 of Network Converter PCB for 5 seconds or turning on power.  
Does error code display reappear?

↓ YES

- Remove the surrounding noise source.

↓ OK

↓ NO

- It is not a defect of PCB. Remove the surrounding noise source.

#### Cause 2 :

**Defective or open connection of cable wire between Network Converter and Connected Remote Controller.**

After the following are checked, the power supply is reset.

- ☐ Check connection cable wire between Network Converter and Connected Remote Controller.
- ☐ Check connection between Control PCB and Terminal.

↓ OK

#### Cause 3 : Incorrect setting of Network Converter's DIP-SW107[2] (Wired RC Validity setting)

- ☐ Check Network Converter PCB DIP-SW107[2].

↓ OK

#### Cause 4 : Incorrect selection of Remote Controller

- ☐ Check connection Remote Controller. (Is it specified with the Installation Manual of Network Converter?)

↓ OK

#### Cause 5 :

**Incorrect setting of Remote Controller's DIP-SW (Number of connected remote controllers)**

- ☐ Check DIP-SW of Remote Controller.

↓ OK

#### Cause 6 : Defective Remote Controller or Network Converter.

- ▶ **Replace Remote Controller or Network Converter.**

## Trouble shooting 87

### Error Contents : Communication Error with Indoor Unit

Symptom :  
Error Code display [ 1 6 ]  
All the control items do not operate.

#### Details :

Condition of occurrence : The communication between Indoor unit and Network Converter was not performed normally.

Release condition : When the communication with Indoor unit is resumed normally.

#### Cause 1 : External noise

- ☐ After pressing SW104 of Network Converter PCB for 5 seconds or turning on power.  
Does error code display reappear?

YES

- Remove the surrounding noise source.

OK

NO

- It is not a defect of PCB. Remove the surrounding noise source.

#### Cause 2 :

Defective or open connection of Remote Control cable between Network Converter and Indoor Unit.

After the following are checked, the power supply is reset.

- ☐ Check connection cable wire between Network Converter and Indoor unit.
- ☐ Check connection between Control PCB and Terminal.

OK

#### Cause 3 : Power to Indoor unit is shut down.

- ☐ Check the power to Indoor unit.

OK

#### Cause 4 : Incorrect setting of main unit address of Indoor unit.

- ☐ Check main unit address setting of Indoor unit.

OK

#### Cause 5 : Incorrect setting of DIP-SW of Network Converter. Mis-read of Indoor unit type and RC type.

- ☐ Check DIP-SW103[1 to 8] of Network Converter (Indoor unit type, RC type, number of Indoor units connected.)
- ☐ Check Indoor unit type and RC type of all Indoor units connected to Network Converter.

OK

#### Cause 6 : Defective PCB of Indoor unit or Network Converter.

- ▶ **Replace PCB of Controller PCB or Network Converter.**  
>>If replace Controller PCB, Refer to 06-03 page Main PCB removal.

## Trouble shooting 88

### Error Contents : Communication Error with Indoor Unit

Symptom :  
Error Code display [ 2 6 ]  
All the control items do not operate.

#### Details :

Condition of occurrence : The communication between Indoor unit and Network Converter was not performed normally.  
Release condition : When the communication with Indoor unit is resumed normally.

#### Cause 1 : External noise

- ☐ After pressing SW104 of Network Converter PCB for 5 seconds or turning on power.  
Does error code display reappear?

↓ YES

- Remove the surrounding noise source.

↓ OK

↓ NO

- It is not a defect of PCB. Remove the surrounding noise source.

#### Cause 2 : Defective or open connection of Remote Control cable between Network Converter and Indoor Unit.

- After the following are checked, the power supply is reset.
- ☐ Check connection cable wire between Network Converter and Indoor unit.
  - ☐ Check connection between Control PCB and Terminal.

↓ OK

#### Cause 3 : Power to Indoor unit is shut down.

- ☐ Check the power to Indoor unit.

↓ OK

#### Cause 4 : Incorrect setting of main unit address of Indoor unit.

- ☐ Check main unit address setting of Indoor unit.

↓ OK

#### Cause 5 : Incorrect setting of DIP-SW of Network Converter. Mis-read of Indoor unit type and RC type.

- ☐ Check DIP-SW103[1 to 8] of Network Converter (Indoor unit type, RC type, number of Indoor units connected.)
- ☐ Check Indoor unit type and RC type of all Indoor units connected to Network Converter.

↓ OK

#### Cause 6 : Defective PCB of Indoor unit or Network Converter.

- ▶ **Replace PCB of Controller PCB or Network Converter.**  
>>If replace Controller PCB, Refer to 06-03 page Main PCB removal.

## Trouble shooting 89

**Error Contents :**  
**Software Error**

**Symptom :**  
**Error Code display [ C A ]**  
**All the control items do not operate.**  
**Other Controls are left they are.**

### Details :

Condition of occurrence : Micon program performed an abnormal control.  
Error of inside information of EEPROM.  
initial setting of Network Converter PCB was not normally performed.

Release condition : Micon has been reset, and the control of Network Converter became normal.  
When error disappeared and Network Converter becomes available to control.

### Cause 1 : External noise

- Check continuation of error.  
(1) If error is released automatically, it is not a defect of PCB. Remove the surrounding noise source around Network Converter.  
(2) If error is not released automatically, check followings.

↓  
**OK**

- After pressing SW104 of Network Converter PCB for 5 seconds or turning on power.  
Does error code display reappear?

↓  
**YES**

- Remove the surrounding noise source.

↓  
**OK**

↓  
**NO**

- It is not a defect of PCB. Remove the surrounding noise source.

### Cause 2 : Network Converter is defective.

- **Replace Network Converter.**

## Trouble shooting 90

**Error Contents :**  
**Indoor / Outdoor Unit Error**

**Symptom :**  
**Error Code display [ 5 U ]**  
**Other controls are left as they are.**

### Details :

Condition of occurrence : When error occurred on Indoor/Outdoor unit that is connected to Network Converter.  
Release condition : When the error of Indoor/Outdoor unit that is connected to Network Converter is released.

### Cause 1 : Error occurred in Indoor unit

- **Refer to Indoor Unit trouble shooting.**  
(Removal of error of indoor unit connected to network converter)

↓  
**OK**

### Cause 2 : Error occurred in Outdoor unit

- **Refer to Outdoor Unit trouble shooting.**  
(Removal of error of outdoor unit connected to network converter)

#### 4. Group Remote Controller (UTY-CGGY / CGGG)

##### Trouble shooting 91

##### Error Contents : PCB Error

Symptom :  
Error Code display [ C 4 ]  
OPERATION LED is flashing.

##### Details :

Condition of occurrence : When EEPROM can not be written, or the control port does not operate.  
Release condition : Power is reset.

Cause 1 : Remote Controller is defective.

► Replace Group Remote Controller.

## Trouble shooting 92

### **Error Contents :** **Connection Error**

**Symptom :**  
**Error Code display [ 1 2 ]**  
**OPERATION LED is flashing.**

#### **Details :**

Condition of occurrence :

The valid signal has not been received from the convertor more than 90 seconds after the communication line became valid.

Release condition : Valid signal is received from Convertor.

#### **Cause 1 : Connection failure**

- ☐ Check power to the convertor.
- ☐ Check connection of remote control line between controller and convertor.



#### **Cause 2 : Check outside cause (Voltage drop or noise, etc.)**

- Instant drop ----- Check if there is a large load electric apparatus in the same circuit.
- Momentary power failure ----- Check if there is a defective contact or leak current in the power supply circuit.
- Noise ----- Check if there is any equipment causing harmonic wave near electric line (Neon bulb or electric equipment that may cause harmonic wave).



#### **Cause 3 : Remote Controller is defective.**

- ▶ **Replace Group Remote Controller.**

## Trouble shooting 93

### **Error Contents :** **Address Setting Error**

**Symptom :**  
**Error Code display [ 2 8 ]**  
**OPERATION LED is flashing.**

#### **Details :**

Condition of occurrence :

1. No Indoor unit is registered.

Release condition :

1. The key to enter the function selection process is pressed.  
TIME< key and TIME> key are simultaneously kept pressed.
2. It automatically initializes by itself. After that, it is released by pressing the key to enter the function selection process.

#### **Cause 1 : Setting failure**

- ☐ Register Indoor units again by entering to the function selection mode.  
(Keep pressing TIME< key and TIME> key.  
**(Refer to the installation manual for the remote controller.)**

## Trouble shooting 94

### Error Contents : System Error

### Symptom :

Error Code display [ 1 5 ]  
OPERATION LED is flashing.

### Details :

Condition of occurrence :

1. Registration started within 4 minutes after power ON
2. Indoor unit refrigerant system registered at controller connected to converter reached 3 or more ([26] error generated at converter)
3. Only the slave unit is registered. (Main unit is not registered.)
4. Indoor unit which is not existing was registered.
5. Outdoor unit is not set in the same refrigerant circuit as the indoor unit.

Release condition : Registered contents have been changed by SELECT key, DAY key, Timer Mode key (DELETE key).

#### Cause 1 : Conditions check

- ☐ Check if 4 minutes or more after starting
- ☐ Clear when [26] error generated at converter.
- ☐ Check if refrigerant systems do not become 3 or more by this indoor unit registration.



#### Cause 2 : Setting failure

- ☐ Recheck the registered contents.(Register the main unit.)
- ☐ Check Indoor unit DIP-SW, R-SW
- ☐ Check outdoor unit R-SW.



#### Cause 3 : Connection failure

- ☐ Check transmission cable
- ☐ Check if Indoor or Outdoor unit power line is disconnected.
- ☐ Check if the convertor power line is disconnected.
- ☐ Check connection between controller and the convertor.



#### Cause 4 : Check outside cause (Voltage drop or noise, etc.)

- Instant drop ----- Check if there is a large load electric apparatus in the same circuit.
- Momentary power failure ----- Check if there is a defective contact or leak current in the power supply circuit.
- Noise ----- Check if there is any equipment causing harmonic wave near electric line (Neon bulb or electric equipment that may cause harmonic wave).



#### Cause 5 : Remote Controller is defective.

- ▶ **Replace Group Remote Controller.**



## Trouble shooting 95

### **Error Contents :** **Transmission Error**

**Symptom :**  
**Error Code display [ 1 4 ]**  
**OPERATION LED is flashing.**

#### **Details :**

Condition of occurrence :

When the signal is cut off for more than 10 minutes from the registered Indoor unit (not including Slave unit).

Release condition : 1. The signal has been received from the Indoor units that was creating the error.

2. MPU has been booted up. (Release from the reset operation, the power failure stand-by operation.)

#### Cause 1 : Connection failure

- ☐ Check transmission cable
- ☐ Check disconnected power line for Indoor unit.
- ☐ Check if convertor power line is disconnected.



#### Cause 2 : Check outside cause (Voltage drop or noise, etc.)

- Instant drop ----- Check if there is a large load electric apparatus in the same circuit.
- Momentary power failure ----- Check if there is a defective contact or leak current in the power supply circuit.
- Noise ----- Check if there is any equipment causing harmonic wave near electric line (Neon bulb or electric equipment that may cause harmonic wave).



#### Cause 3 : Remote Controller is defective.

- ▶ **Replace Group Remote Controller.**

## 5. Wired Remote Controller (UTY-RNK\* )

## Trouble shooting 96

### **Error Contents :** **Thermo Sensor Error**

**Symptom :**  
**Thermostat Sensor display is flashing.**

#### **Details :**

Condition of occurrence : Thermistor in remote controller is open or shorted.

Release condition : Thermistor in remote controller is not open or shorted.

#### Cause 1 : Remote controller internal thermistor trouble

- ☐ Replace remote controller.

## 6. Wired(UTY-RNK\*) and Simple Remote Controller (UTY-RSK\*,RHK\*)

### Trouble shooting 97

**Error Contents :**  
**Indoor Unit ↔ Remote Controller**  
**Communication Error**

**Symptom :**  
**Error Code display [ 1 2 ]**

**Details :**

Condition of occurrence : When signal from indoor unit does not enter  
Release condition : When signal from indoor unit entered

Cause 1 : Check connection

- ☐ Check cable
- ☐ Check indoor unit power supply



Cause 2 : Check indoor unit remote controller address.

- ☐ Check if the indoor unit remote controller addresses are sequentially set from 0.



Cause 3 : Noise

- ☐ Remove the surrounding noise.



Cause 4 : Remote controller trouble

- ☐ Replace remote controller.



Cause 5 : Indoor unit PCB trouble

- ☐ Change Controller PCB and set up the original address.  
(Refer to 06-03 page Main PCB removal.)

## Trouble shooting 98

**Error Contents :**  
**Incompatible Indoor Unit is Connected**

**Symptom :**  
**Error Code display [ 1 5 ]**

### Details :

Condition of occurrence : When information was not obtained from indoor unit

Release condition : When information was obtained from indoor unit

Cause 1 : Check remote controller master/slave setting.

- ☐ For the check and modification methods, refer to the remote controller (including external SW) installation manual.
- ☐ When there is 1 remote controller, check whether or not it is set as the master remote controller.
- ☐ When there are 2 remote controllers, check if one side is the master remote controller and the other side is the slave remote controller.
- ☐ When there are 1 remote controller and 1 external switch controller, check if the remote controller is master controller and the external switch controller is slave controller.



Cause 2 : Check connection

- ☐ Check cable
- ☐ Check indoor unit power supply



Cause 3 : Noise

- ☐ Source around cable



Cause 4 : Remote controller trouble

- ☐ Replace remote controller.



Cause 5 : Indoor unit PCB trouble

- ☐ Change Controller PCB and set up the original address.  
(Refer to 06-03 page Main PCB removal.)

7. System Controller (UTY-APGX) / Service Tool (UTY-ASGX) / Web Monitoring Tool (UTY-AMGX)  
(Referred to as "Service Tool" hereafter)

**Trouble shooting 99**

**Error Contents :**  
**Unit Not Detected**

**Symptom :**

**1 or more units (but not all) are not detected after Scan.**  
**1 or more units (but not all) are not listed in the system list after Scan.**

**Details :**

Condition of occurrence:

- Unit address is not set correctly.
- Network cable is not connected correctly.
- System design is mistaken.
- Unit transmission board is defective.

Recovery condition:

- Unit address is set correctly.
- Network cable is connected as designed.
- System design and work is corrected.
- Unit transmission board is normal.

Cause 1 : Unit address is not set correctly.

- ☐ Check the unit address setting of the undetected unit and correct it if mistaken.



Cause 2 : Network cable is not connected as designed.

- ☐ Check that the network cables are connected according to the site design drawing.  
Check specifically the network segment where the undetected unit exists.
- ☐ Check and fix the loose cable connection to the terminal of the undetected unit.
- ☐ Using Service Tool, perform scan changing the network segment where the Service Tool is connected and localize the mistaken network segment. Start from the network segment where the undetected unit exists.  
Specify priority scan when possible.



Cause 3 : System design work is mistaken.

- ☐ Check the following items and fix appropriately if mistaken.
  - (1) 1 (and only 1) Terminal Resistor is connected for each network segment.
  - (2) Cable length is within 500m for each network segment.
  - (3) Number of units connected within a network segment does not exceed 64.  
(1 connected port of Signal Amplifier is counted as 1).
  - (4) Network cable specification is as specified in the Design & Technical Document.
  - (5) Total number of Signal Amplifiers does not exceed 8 per system.
  - (6) Network cable is not connected in loop.
  - (7) Both ends of the network cable are grounded.
  - (8) Network cables are not bundled together with power cables to prevent noise induction.



Cause 4 : Unit transmission board is defective.

- ☐ Replace transmission board of the undetected unit if none of the above cause applies.

**Note :**

A Network Segment is a portion of the network connected directly by network cables and is separated by Signal Amplifiers. If no Signal Amplifier exists, there is only 1 network segment.

## 4-4 SERVICE INFORMATION

### SERVICE INFORMATION

#### Backup Operation

##### Details :

- Backup operation is the operating method of replacing compressor while the system is running. Compressor can be replaced without stopping the system.
- In backup operation, cooling and heating capacity is decreased by the capacity of the separated outdoor unit.
- The work procedure is as follows.


### 4-4-1 Backup operation

#### 1. Method of backup operation

##### 1-1. Backup operation when compressor of the master unit is defective.

##### [Procedure]


(Example: Three outdoor units are connected.)



## 1-2. Backup operation when compressor of the slave unit #1 is broken.

### [Procedure]

(Example: Three outdoor units are connected. the slave unit #1 is broken.)



## 4-4-2 Work procedure after the backup operation

### 1. Refrigerant shortage at the backup operation

When excessive refrigerant accumulates in the defective outdoor unit during the backup operation, it becomes capacity shortage by refrigerant shortage.

The meaning of the sign

- LPS : Low pressure sensor detection value
- EEV1 : Expansion valve #1
- TH3 : Outdoor thermistor detection value
- TH4 : Suction thermistor detection value
- TH5 : Outdoor heat EX. temperature sensor detection value

<How to judge, when refrigerant is deficient>

Refrigerant shortage is judged by the information from "Service tool" during backup operation.

#### 1. On Cooling operation


- ① It often creates "Low pressure protection stop" at start up or after oil recovery operation.  
>>> When  $LPS < 0.1\text{MPa}$  at start up, the compressor stops.
- ② Running indoor unit's EEV is fully open condition.  
>>> It displays corresponding indoor unit's EEV on the chart at the bottom of the monitor.  
If there is no sign of closing the EEV from fully opened condition.

#### 2. On Heating operation

- ① It often creates "Low pressure protection stop" at start up or after oil recovery operation.  
>>> When  $LPS < 0.1\text{MPa}$  at start up, the compressor stops.
- ② EEV1 of outdoor unit is open at 500 pulse. (full admission).
- ③ Suction superheat is too high.  
>>> When both  $TH5 < TH4$  and  $TH4 \cong TH3$ .

<How to respond, when refrigerant is deficient>

- ① Reuse the refrigerant of the broken master unit.



Connect the high pressure service port of the broken master unit and the low pressure service port of the substitutional master unit by charging hose, placing the valve on the way.

>>> Refrigerant release from the heat exchanger of the broken master unit.

(Refrigerant is removed until refrigerant shortage is resolved)

- ② Not available to reuse.  
>>> New refrigerant is encapsulated.  
\* substitutional master unit, and encapsulating amount is recorded.

#### 2. Refrigerant charging after the compressor replacement.

When the refrigerant leaks at the time of replacing the defective compressor, charge the refrigerant as follows depending on the situation.


- ① If the amount of recovered refrigerant is available that was pulled out of outdoor unit which compressor was replaced.  
(When the refrigerant is recovered by refrigerant recovery machine, and its weight is measured.)  
>>> Perform vacuuming of repaired outdoor unit thoroughly ,  
and add the refrigerant with the recovered amount.
- ② If the amount of recovered refrigerant from outdoor unit that compressor was replaced is not sure.  
>>> Once recover all units' refrigerant, and then recharge the calculated amount of refrigerant again after vacuuming.

## 4-5 SERVICE PARTS INFORMATION

### SERVICE PARTS INFORMATION 1

#### Compressor

Diagnosis method of Compressor (If Outdoor Unit 7 segment LED displays Error, refer to Trouble shooting )






## SERVICE PARTS INFORMATION 2


### Constant Speed Compressor

#### Check Point 1 : Check Connection

❑ Check terminal connection of Compressor (loose or incorrect wiring)




❑ Check connection of magnet relay (Loose or incorrect wiring)



#### Check Point 2 : Check Winding Resistance


❑ Check winding resistance of each terminal

▶ **If the resistance value is 0Ω or infinite, replace Compressor.**  
(Check again after several minutes because the protector may be operated.)



#### Attention!!

The constant speed compressor is equipped with a protector. It detects the inside temperature and the current value, and if it detects an over current or too high temperature, the protector is operated to stop operation of Compressor. (Protector operates within the range in the following graph, and it is released when the temperature becomes lower than approx. 80°C.



#### Check Point 3 : Check Cause of Protector Operation

- ❑ Due to unstable power supply, Compressor is causing an abnormally high temperature.  
 >> **Check Power Voltage once again.**
- ❑ Due to missing phase, Compressor is causing an abnormally high temperature.  
 >> **Check loose or open connection cable once again.**
- ❑ Due to less refrigerant, the cooling effect inside Compressor is decreased.  
 >> **Check if there is a gas leak or less refrigerant.**



## SERVICE PARTS INFORMATION 3

### Inverter Compressor

#### Check Point 1 : Check Connection

❑ Check terminal connection of Compressor (loose or incorrect wiring)


❑ Check connection of magnet relay (Loose or incorrect wiring)



#### Check Point 2 : Check Winding Resistance

❑ Check winding resistance of each terminal

► **If the resistance value is 0Ω or infinite, replace Compressor.**



#### Attention!!

If Check 1, 2 are normal, make sure the following points.

(1) Check AC voltage among each terminals from filter PCB(INV) to Diode Bridge.  
(AC380V - 415V, voltage among L1, L2 and L3).

► **If it does not appear, check the power supply terminal.**

(2) Check Voltage from Main PCB to Inverter PCB.  
(DC15.0 - 18.0V between terminals of CN126 (1-2) connector of Main PCB).

► **If it does not appear, replace Main PCB.**

◆ **If both of above voltages appear, it is considered to be Inverter PCB circuit failure.  
Replace Inverter PCB and check operation.**




#### **SERVICE PARTS INFORMATION 4**

##### **Main PCB**


##### **Filter PCB (Main)**

##### **PWB UNIT (CT)**



## SERVICE PARTS INFORMATION 5

### Inverter PCB Filter PCB (INV)



## SERVICE PARTS INFORMATION 6

### IPM

(Mounted on Inverter PCB)

#### Check Point 1

- ① Disconnect the connection wires between the Inverter PCB - electrolytic capacitor and Inverter PCB - Inverter Compressor.


- ② Set the tester to the "Resistance" mode, and measure the resistance between the following terminals.

Red wire (P) - screw terminals U/V/W

White wire (N) - screw terminals U/V/W

- ③ Judge the result of ② as follows:

All 6 points several MΩ or greater	: Normal
1 or more points several kΩ to short	: Defective



#### Check Point 2

- ④ Set the tester to the "Diode" mode, and measure the voltage value between the following terminals.

Tester +side (red)	Tester - side (black)	Tester display [V]
Terminal U	Red wire (P)	
Terminal V		
Terminal W		
White wire (N)	Terminal U	
	Terminal V	
	Terminal W	

- ⑤ Judge the result of ④ as follows:

All 6 points several 0.3V to 0.7V	: Normal
1 or more points under 0.1V or over load	: Defective




## SERVICE PARTS INFORMATION 7


### CT PCB

#### Check Point 1

- Measure the AC current flowing from TM302 and the DC voltage between connector pins 1-3 at that time.



#### ● AC current - DC voltage characteristic



## SERVICE PARTS INFORMATION 8

### 3-Phase Diode Bridge

#### Check Point 1 : Appearance check


- ☐ No fissures, breaks, damage, etc. at body and terminal section?
- ☐ Is the rear of the body coated with silicone grease?
- ☐ Are there no abnormalities at threaded parts (stripped threads, deformation, damage, etc.) ?

#### Check Point 2 : Electric check




- ① In the 3-phase diode bridge single part state, set the tester to the "Resistance" mode, and check for open/short between the following terminals.

Tester + side (red)	Tester - side (black)
Pin 1	Pin 4
Pin 2	
Pin 3	
Pin 5	Pin 1
	Pin 2
	Pin 3



- ② Judge the result of ① as follows:

All 6 points shorted	: Normal
1 or more points open	: Defective



- ③ Set the tester to the "Resistance" mode, and check for open/short between the following terminals.

Tester + side (red)	Tester - side (black)
Pin 4	Pin 1
	Pin 2
	Pin 3
Pin 1	Pin 5
Pin 2	
Pin 3	

- ④ Judge the result of ③ as follows:

All 6 points open	: Normal
1 or more points shorted	: Defective


## SERVICE PARTS INFORMATION 9

Reactor (INV)  
Reactor (DC Fan)

### Check Point 1 : Appearance check

- No fissures, breaks, damage, etc. at the body and winding section, terminals section?

### Check Point 2 : Electric check



- ① Set the tester to the "Resistance" mode, and check for open/short between both ends of the reactor wire (or connector).
- ② Judge the result of ① as follows:

Short	: Normal
Open	: Abnormal (open)



## SERVICE PARTS INFORMATION 10

### Resistor, Cement

#### Check Point 1 : Appearance check

- ☐ No fissures, breaks, damage, etc. at the body and terminals section?

#### Check Point 2 : Electric check

##### 1. Surge prevention resistor (connected to magnetic contactor)

- ① Set the tester to the "Resistance" mode, and measure the resistance value between the terminals. (No polarity)

- ② Judge the result of ① as follows:


5.32Ω to 5.88 Ω	: Normal
Other than the above	: Deteriorated, defective

##### 2. Balance resistor (connected to electrolytic capacitor)

- ① Set the tester to the "Resistance" mode, and measure the resistance value between the terminals. (No polarity)

- ② Judge the result of ① as follows:

31.35Ω to 34.65Ω	: Normal
Other than the above	: Deteriorated, defective



## SERVICE PARTS INFORMATION 11

### Capacitor

#### Check Point 1 : Appearance check

- ☐ Explosion-proof not operated?
- ☐ Electrolyte not leaking?
- ☐ No abnormalities at threaded parts? (Stripped threads, deformation, damage, etc.)

#### Check Point 2 : Electric check

- ☐ No short between terminals?

## **SERVICE PARTS INFORMATION 12**

### **Terminal**

#### Check Point 1 : Appearance check

- ☐ No fissures, breaks, damage, etc. at the body and terminals section?
- ☐ Not clogged with foreign matter?
- ☐ Are there no abnormalities at threaded parts (Stripped threads, deformation, damage, etc.) ?

#### Check Point 2 : Electric check

- ☐ No short between adjacent terminals?
- ☐ Conducts before and after same terminal?



## **SERVICE PARTS INFORMATION 13**

### **Magnetic Relay**

#### Check Point 1 : Appearance check

- ☐ No fissures, breaks, damage, etc. at the body and terminals section?
- ☐ Are there no abnormalities at threaded parts (Stripped threads, deformation, damage, etc.) ?


#### Check Point 2 : Electric check

① Set the tester to the "Resistance" mode, and check for open/short between the following terminals. (No polarity)

- Between R to U
- Between S to V
- Between T to W

② Judge the result of ① as follows:

Open	: Normal
Short	: Abnormal (contacts fused)




## SERVICE PARTS INFORMATION 14

### Indoor Unit Electronic Expansion Valve (EEV)


#### Check Point 1 : Check Connections

❑ Check Connectors (Loose connector or open cable.)


##### Duct




##### Small Wall mount




##### Floor/ Ceiling, Ceiling



##### Cassette



##### Wall mount



#### Check Point 2 : Check Coil of EEV

❑ Remove connector, check each winding resistance of Coil.

Read wire	Resistance value (20°C)
White - Red	<b>200 ± 10% Ω</b>
Yellow - Brown	
Orange - Red	
Blue - Brown	

► **If Resistance value is abnormal, replace EEV.**



#### Check Point 3 : Check Voltage from Controller PCB

❑ Remove Connector and check Voltage (DC12V).

>> **If it does not appear, replace Controller PCB.**




#### Check Point 4 : Check Noise at start up

Turn on Power and check operation noise.


>> **If an abnormal noise does not show, replace Controller PCB.**

### Check Point 5 : Check Opening and Closing Operation of Valve

When Valve is closed,  
it has a temp. difference between Inlet and Outlet.





If it is open, it has no temp. difference between Inlet and Outlet.



### Check Point 6 : Check Strainer

Strainer normally does not have temperature difference between inlet and outlet as shown in (1), but if there is a difference as shown in (2), there is a possibility of inside clogged. In this case, replace Strainer.




## SERVICE PARTS INFORMATION 15

### Outdoor Unit Electronic Expansion Valve (EEV1)

#### Check Point 1 : Check Connections

- Check connection of connector (CN116)  
(Loose connector or open cable)



#### Check Point 2 : Check Coil of EEV1

- Remove connector, check each winding resistance of Coil.

Read wire	Resistance value (20°C)
White - Red	$46 \pm 4 \% \Omega$
Yellow - Brown	
Orange - Red	
Blue - Brown	

► If Resistance value is abnormal, replace EEV.

#### Check Point 3 : Check Voltage from Controller PCB

- Remove Connector and check Voltage (DC12V).  
 >> If it does not appear, replace Controller PCB.



#### Check Point 4 : Check Noise at start up

- Turn on Power and check operation noise.  
 >> If an abnormal noise does not show, replace Controller PCB.


#### Check Point 5 : Check Opening and Closing Operation of Valve

When Valve is closed,  
it has a temp. difference between Inlet and Outlet.

##### CLOSE

Example : Hot GAS

Pipe (In)  
Hi TEMP.




If it is open, it has no temp. difference between Inlet and Outlet.

##### OPEN



Example : Hot GAS

Pipe (In)  
Hi TEMP.



#### Check Point 6 : Check Strainer

Strainer normally does not have temperature difference between inlet and outlet as shown in (1), but if there is a difference as shown in (2), there is a possibility of inside clogged. In this case, replace Strainer.




## SERVICE PARTS INFORMATION 16

### Outdoor Unit Electronic Expansion Valve (EEV2)

#### Check Point 1 : Check Connections

- Check connection of connector (CN117)  
(Loose connector or open cable)



#### Check Point 2 : Check Coil of EEV1

- Remove connector, check each winding resistance of Coil.

Read wire	Resistance value (20°C)
White - Red	$46 \pm 4 \% \Omega$
Yellow - Brown	
Orange - RED	
Blue - Brown	

► If Resistance value is abnormal, replace EEV.

#### Check Point 3 : Check Voltage from Controller PCB

- Remove Connector and check Voltage (DC12V).  
 >> If it does not appear, replace Controller PCB.



#### Check Point 4 : Check Noise at start up

- Turn on Power and check operation noise.  
 >> If an abnormal noise does not show, replace Controller PCB.


#### Check Point 5 : Check Opening and Closing Operation of Valve

When Valve is closed,  
it has a temp. difference between Inlet and Outlet.

##### CLOSE

Example : Hot GAS

Pipe (In)  
Hi TEMP.




If it is open, it has no temp. difference between Inlet and Outlet.

##### OPEN



Example : Hot GAS

Pipe (In)  
Hi TEMP.



#### Check Point 6 : Check Strainer

Strainer normally does not have temperature difference between inlet and outlet as shown in (1), but if there is a difference as shown in (2), there is a possibility of inside clogged. In this case, replace Strainer.




## SERVICE PARTS INFORMATION 17

### Outdoor Unit Solenoid Valve (SV1,SV2,SV3,SV5,SV6)

#### Check Point 1 : Check connections

- ❑ Check connection of connector.  
(Loose connector or open cable)


- AJ\*A72,90LALH  
    >> C106,C107,C108
- AJ\*A108LALH  
    >> C106,C107,C108,CN111
- AJ\*A126,144LALH  
    >> C106,C107,C108,CN110



#### Check Point 2 : Check Solenoid Coil

- ❑ Remove connector and check if coil is open.  
(Normal resistance value of each coil:  $1495 \pm 7\% \Omega$ )

>> **If Resistance value is abnormal, replace Solenoid Coil.**



#### Check Point 3 : Check Voltage from Controller PCB

- ❑ Remove connector and check the voltage (AC220V).



>> **If the voltage does not appear, replace Controller PCB.**




#### Check Point 4 : Check opening & closing operation of Valve

- ❑ Depending on either during operation or protection control, check if Valve is operating normally.  
(When Valve opens, there is no temperature difference between Inlet and Outlet.)

**Normal Operation**  
Pipe (In) TEMP. Hi,  
Pipe (Out) TEMP.Normal





**Protection Function**  
Pipe (In) TEMP. = Pipe (Out) TEMP.



- ❑ If the valve closes by removing the connector of the valve which does not close, it is considered to be Controller PCB failure. Replace Controller PCB.

- ❑ If it does not close by removing connector, there is a possibility of (1) clogging by dirt, or (2) deformation by the heat at the time of Solenoid Valve installation.  
In this case, replace Solenoid Valve.




## SERVICE PARTS INFORMATION 18

### 4-WAY VALVE

#### Check Point 1 : Check Circuit connection

- Check the connection of connector CN 105




#### Check Point 2 : Check Solenoid Coil

- Remove CN6 from PCB and check the resistance value of coil




- ☆ If it is Open or abnormal resistance value, replace Solenoid Coil



#### Check Point 3: Check Operation of 4 Way Valve

- Check each piping temperature, and confirm the location of the valve by the temperature difference.



- ☆ If the valve location is not proper, replace 4 way valve.

#### Check Point 4: Check Voltage of Solenoid Coil

- If CN6 of Control PCB dose not Show 220V ± 20 V during Heating operation (Compressor is in operation), replace Control PCB.




## SERVICE PARTS INFORMATION 19

### Indoor Unit Fan Motor

Check Point : ARXB24LATH (Low Static pressure Duct Type)

□ Check each winding resistance of the motor

► If Resistance value is abnormal, replace motor.




Lead wire	Resistance value
White – Red	<b>44.8 <math>\Omega \pm 8\%</math></b>
Red – Black	<b>37.3 <math>\Omega \pm 8\%</math></b>
Red – Pink	<b>21.3 <math>\Omega \pm 8\%</math></b>
Pink – Violet	<b>12.9 <math>\Omega \pm 8\%</math></b>
Violet – Blue	<b>12.9 <math>\Omega \pm 8\%</math></b>

at 20°C

Check Point : ARXB30/ 36LATH (Low Static pressure Duct Type)

□ Check each winding resistance of the motor

► If Resistance value is abnormal, replace motor.




Lead wire	Resistance value
White – Red	<b>47.1 <math>\Omega \pm 8\%</math></b>
Red – Black	<b>27.4 <math>\Omega \pm 8\%</math></b>
Red – Pink	<b>8.00 <math>\Omega \pm 8\%</math></b>
Pink – Violet	<b>8.00 <math>\Omega \pm 8\%</math></b>
Violet – Blue	<b>8.00 <math>\Omega \pm 8\%</math></b>

at 20°C

Check Point : ARXB45LATH (Low Static pressure Duct Type)

□ Check each winding resistance of the motor

► If Resistance value is abnormal, replace motor.




Lead wire	Resistance value
White – Red	<b>20.1 <math>\Omega \pm 8\%</math></b>
Red – Black	<b>13.8 <math>\Omega \pm 8\%</math></b>
Red – Pink	<b>6.50 <math>\Omega \pm 8\%</math></b>
Pink – Violet	<b>6.50 <math>\Omega \pm 8\%</math></b>
Violet – Blue	<b>6.50 <math>\Omega \pm 8\%</math></b>

at 20°C

Check Point : ARXA24/ 30LATH (Duct Type)

- Check each winding resistance of the motor  
 ► **If Resistance value is abnormal, replace motor.**




Lead wire	Resistance value
White – Red	<b>47.1 <math>\Omega \pm 8\%</math></b>
Red – Black	<b>27.4 <math>\Omega \pm 8\%</math></b>
Red – Pink	<b>8.00 <math>\Omega \pm 8\%</math></b>
Pink – Violet	<b>8.00 <math>\Omega \pm 8\%</math></b>
Violet – Blue	<b>8.00 <math>\Omega \pm 8\%</math></b>

at 20°C

Check Point : ARXA36/ 45LATH (Duct Type)

- Check each winding resistance of the motor  
 ► **If Resistance value is abnormal, replace motor.**




Lead wire	Resistance value
White – Red	<b>20.1 <math>\Omega \pm 8\%</math></b>
Red – Black	<b>13.8 <math>\Omega \pm 8\%</math></b>
Red – Pink	<b>6.50 <math>\Omega \pm 8\%</math></b>
Pink – Violet	<b>6.50 <math>\Omega \pm 8\%</math></b>
Violet – Blue	<b>6.50 <math>\Omega \pm 8\%</math></b>

at 20°C

### Check Point : ARXB07LALH (Compact Duct Type)

- Check each winding resistance of the motor  
 ► **If Resistance value is abnormal, replace motor.**




Lead wire	Resistance value
White – Red	<b>579 <math>\Omega \pm 8\%</math></b>
Red – Black	<b>255 <math>\Omega \pm 8\%</math></b>
Red – Pink	<b>162 <math>\Omega \pm 8\%</math></b>
Pink – Violet	<b>66 <math>\Omega \pm 8\%</math></b>
Violet – Blue	<b>93 <math>\Omega \pm 8\%</math></b>

at 20°C

### Check Point : ARXB09LALH (Compact Duct Type)

- Check each winding resistance of the motor  
 ► **If Resistance value is abnormal, replace motor.**




Lead wire	Resistance value
White – Red	<b>322.8 <math>\Omega \pm 8\%</math></b>
Red – Black	<b>255 <math>\Omega \pm 8\%</math></b>
Red – Pink	<b>103 <math>\Omega \pm 8\%</math></b>
Pink – Violet	<b>53 <math>\Omega \pm 8\%</math></b>
Violet – Blue	<b>100.7 <math>\Omega \pm 8\%</math></b>

at 20°C

### Check Point : ARXB12LALH (Compact Duct Type)

- Check each winding resistance of the motor  
 ► **If Resistance value is abnormal, replace motor.**



Lead wire	Resistance value
White – Red	<b>336 <math>\Omega \pm 8\%</math></b>
Red – Black	<b>261 <math>\Omega \pm 8\%</math></b>
Red – Pink	<b>107 <math>\Omega \pm 8\%</math></b>
Pink – Violet	<b>55 <math>\Omega \pm 8\%</math></b>
Violet – Blue	<b>103 <math>\Omega \pm 8\%</math></b>


at 20°C

Check Point : ARXB14LALH (Compact Duct Type)

Ω

□ Check each winding resistance of the motor

► If Resistance value is abnormal, replace motor.



Lead wire	Resistance value
White – Red	<b>136.5 Ω ± 8%</b>
Red – Black	<b>125.6 Ω ± 8%</b>
Red – Pink	<b>23.7 Ω ± 8%</b>
Pink – Violet	<b>23.7 Ω ± 8%</b>
Violet – Blue	<b>49.4 Ω ± 8%</b>


at 20°C

Check Point : ARXB18LALH (Compact Duct Type)

Ω

□ Check each winding resistance of the motor

► If Resistance value is abnormal, replace motor.




Lead wire	Resistance value
White – Red	<b>89.7 Ω ± 8%</b>
Red – Black	<b>150 Ω ± 8%</b>
Red – Pink	<b>37.4 Ω ± 8%</b>
Pink – Violet	<b>37.4 Ω ± 8%</b>
Violet – Blue	<b>197 Ω ± 8%</b>

at 20°C

Check Point : AB\*A12/ 14LATH (Floor/ Ceiling Type)

- Check each winding resistance of the motor  
 ► If Resistance value is abnormal, replace motor.




Lead wire	Resistance value
White – Red	<b>252 <math>\Omega \pm 8\%</math></b>
Red – Black	<b>337 <math>\Omega \pm 8\%</math></b>
Red – Violet	<b>59.5 <math>\Omega \pm 8\%</math></b>
Violet – Blue	<b>59.5 <math>\Omega \pm 8\%</math></b>

at 20°C

Check Point : AB\*A18LATH (Floor/ Ceiling Type)

- Check each winding resistance of the motor  
 ► If Resistance value is abnormal, replace motor.




Lead wire	Resistance value
White – Red	<b>134 <math>\Omega \pm 8\%</math></b>
Red – Black	<b>243 <math>\Omega \pm 8\%</math></b>
Red – Violet	<b>63.1 <math>\Omega \pm 8\%</math></b>
Violet – Blue	<b>63.1 <math>\Omega \pm 8\%</math></b>

at 20°C

Check Point : AB\*A24LATH (Floor/ Ceiling Type)

- Check each winding resistance of the motor  
 ► If Resistance value is abnormal, replace motor.




Lead wire	Resistance value
White – Red	<b>110 <math>\Omega \pm 8\%</math></b>
Red – Black	<b>181 <math>\Omega \pm 8\%</math></b>
Red – Violet	<b>64.9 <math>\Omega \pm 8\%</math></b>
Violet – Blue	<b>64.9 <math>\Omega \pm 8\%</math></b>

at 20°C

Check Point : AB\*A30/ 36/ 45/ 54LATH (Ceiling Type)

- Check each winding resistance of the motor  
 ► If Resistance value is abnormal, replace motor.




Lead wire	Resistance value
1 (WHITE) – 3 (RED)	<b>22.8 <math>\Omega \pm 10\%</math></b>
2 (BLACK) – 3 (RED)	<b>31.9 <math>\Omega \pm 10\%</math></b>

at 20°C

Check Point : ARXC36LATH (High Static Pressure Duct Type)

- Check each winding resistance of the motor  
 ► **If Resistance value is abnormal, replace motor.**




Lead wire	Resistance value
White – Red	<b>13.4 <math>\Omega \pm 8\%</math></b>
Red – Black	<b>16.9 <math>\Omega \pm 8\%</math></b>
Red – Violet	<b>11.5 <math>\Omega \pm 8\%</math></b>
Violet – Blue	<b>13.3 <math>\Omega \pm 8\%</math></b>

at 20°C

Check Point : ARXC45/ 60LATH (High Static Pressure Duct Type)

- Check each winding resistance of the motor  
 ► **If Resistance value is abnormal, replace motor.**




Lead wire	Resistance value
White – Red	<b>6.84 <math>\Omega \pm 7\%</math></b>
Red – Black	<b>9.78 <math>\Omega \pm 7\%</math></b>
Red – Violet	<b>6.1 <math>\Omega \pm 7\%</math></b>
Violet – Blue	<b>6.1 <math>\Omega \pm 7\%</math></b>

at 20°C

Check Point : ARXC72LATH (High Static Pressure Duct Type)

- Check each winding resistance of the motor  
 ► **If Resistance value is abnormal, replace motor.**




Lead wire	Resistance value
White – Red	<b>5.25 <math>\Omega \pm 7\%</math></b>
Red – Black	<b>5.02 <math>\Omega \pm 7\%</math></b>
Red – Pink	<b>1.86 <math>\Omega \pm 7\%</math></b>
Pink – Violet	<b>0.94 <math>\Omega \pm 7\%</math></b>
Violet – Blue	<b>0.94 <math>\Omega \pm 7\%</math></b>

at 20°C

Check Point : ARXC90LATH (High Static Pressure Duct Type)

- Check each winding resistance of the motor  
 ► **If Resistance value is abnormal, replace motor.**




Lead wire	Resistance value
White – Red	<b>4.24 <math>\Omega \pm 7\%</math></b>
Red – Black	<b>4.16 <math>\Omega \pm 7\%</math></b>
Red – Pink	<b>0.46 <math>\Omega \pm 7\%</math></b>
Pink – Violet	<b>0.91 <math>\Omega \pm 7\%</math></b>
Violet – Blue	<b>0.46 <math>\Omega \pm 7\%</math></b>

at 20°C

Check Point : AS \* A18 / 24 / 30 LATH(Wall Mounted Type)


□ Check each winding resistance of the motor

► If Resistance value is abnormal, replace motor.



Lead wire	Resistance value
White – Red	<b>134 <math>\Omega \pm 8\%</math></b>
Blue – Black	<b>25.5 <math>\Omega \pm 8\%</math></b>
Blue – Red	<b>306 <math>\Omega \pm 8\%</math></b>

at 20°C




## SERVICE PARTS INFORMATION 20

### Discharge Pressure Sensor Suction Pressure Sensor


#### 1. Discharge Pressure Sensor

Check Point : Check Voltage from Main PCB

- With the connector connected to the PCB, measure the voltage between CN118:2-3 of the Main PCB.




- Characteristics of pressure sensor




#### 2. Suction Pressure Sensor

Check Point : Check Voltage from Main PCB

- With the connector connected to the PCB, measure the voltage between CN119:2-3 of the Main PCB.



- Characteristics of pressure sensor






## **SERVICE PARTS INFORMATION 21**

### **Pressure switch 1,2**

#### • Type of contact



#### • Characteristics of pressure switch

	Pressure switch 1 (For Inverter comp.)	Pressure switch 2 (For Constant speed comp.)
Contact : Short ⇒ Open	4.2±0.1MPa	4.2±0.1MPa
Contact : Open ⇒ Short	3.2±0.15MPa	3.2±0.15MPa


## SERVICE PARTS INFORMATION 22

### Thermistor

#### Check Point : Check Thermistor resistance value

- ❑ Remove connector and check Thermistor resistance value.

Temperature [°C]	Resistance Value [ kΩ ]			
	Thermistor A	Thermistor B	Thermistor C	Thermistor D
- 20	---	---	105.4	---
- 10	---	27.8	58.2	27.4
- 5	---	21.0	44.0	20.7
0	168.6	16.1	33.6	15.8
5	129.8	12.4	25.9	12.2
10	100.9	9.6	20.2	9.5
15	79.1	7.6	15.8	7.5
20	62.6	6.0	12.5	5.9
25	49.8	4.8	10.0	4.7
30	40.0	3.8	8.0	3.8
40	26.3	2.5	5.3	2.5
50	17.8	1.7	3.6	1.7
60	12.3	1.2	---	1.2
70	8.7	---	---	0.8
80	6.3	---	---	0.6
90	4.6	---	---	0.4
100	3.4	---	---	0.3
110	2.6	---	---	---
120	2.0	---	---	---
Applicable Thermistors	Discharge temp. TH1 Discharge temp. TH2 Comp.1 temp. TH Comp.2 temp. TH	Heat exchanger. TH Suction temp. TH Sub-cool heat exchanger (inlet) TH Sub-cool heat exchanger (outlet) TH Liquid temp. TH1 Liquid temp. TH2	Outdoor temp. TH	Heat sink temp. TH



# **AIRSTAGE™ V-II**


*Variable Refrigerant Flow System*

## **5. APPENDING DATA (UNIT)**




## 5-1 REFRIGERANT CIRCUIT


MODELS : AJ\*A72LALH, AJ\*A90LALH



# MODEL : AJ \*108LALH



# MODELS : AJ\*126LALH, AJ\*144LALH



## SYMBOL DESCRIPTION

### Outdoor unit

MARK	DESCRIPTION
CMP 1	Compressor 1 (Inverter type)
CMP 2	Compressor 2 (Constant speed type)
HEX	Heat exchanger
FAN 1	Fan 1
ACM	Accumulator
OS	Oil separator
SCHEX	Sub-cool heat exchanger
HPS	High pressure sensor
LPS	Low pressure sensor
HPSW1	High pressure sensor switch 1
4WV	4-way valve
EEV 1	Electric expansion valve 1
EEV 2	Electric expansion valve 2
SV 1	Solenoid valve 1
SV 2	Solenoid valve 2
SV 3	Solenoid valve 3
SV 4	Solenoid valve 4
SV 5	Solenoid valve 5
SV 6	Solenoid valve 6
TH 1	Discharge temperature thermistor 1
TH 2	Discharge temperature thermistor 2
TH 3	Outdoor temperature thermistor
TH 4	Suction temperature thermistor
TH 5	Heat exchanger (outlet) thermistor
TH 6	Liquid temperature thermistor 1
TH 7	Liquid temperature thermistor 2
TH 8	Sub-cool heat exchanger (inlet) thermistor
TH 9	Sub-cool heat exchanger (outlet) thermistor
TH 10	Compressor 1 temperature thermistor
TH 11	Compressor 2 temperature thermistor

### Indoor unit


MARK	DESCRIPTION
HEX 21	Heat exchanger
FAN 21	Fan
EEV 21	Electric expansion valve
TH 21	Room temperature thermistor
TH 22	Heat exchanger (inlet) thermistor
TH 23	Heat exchanger (outlet) thermistor




## 5-2 WIRING DIAGRAM

### 5-2-1 Indoor Unit


MODELS : AUXB07, AUXB09, AUXB12, AUXB14, AUXB18, AUXB24




# MODELS : AUXD18, AUXD24, AUXA30, AUXA36, AUXA45, AUXA54




# MODELS : ARXB07, ARXB09, ARXB12, ARXB14, ARXB18




## MODEL : ARXB24




## MODELS : ARXB30, ARXB36




MODEL : ARXB45




## MODEL : ARXA24




## MODELS : ARXA30, ARXA36, ARXA45




## MODELS : ARXC36, ARXC45, ARXC60



## MODELS : ARXC72, ARXC90




# MODELS : AB\*A12, AB\*A14, AB\*A18, AB\*A24







# MODELS : AB\*A30, AB\*A36, AB\*A45, AB\*A54




# **MODELS : AS\*A07, AS\*A09, AS\*A12, AS\*A14**



# MODELS : AS\*E07, AS\*E09, AS\*E12, AS\*E14




# MODELS : AS\*A18, AS\*A24, AS\*A30



## 5-2-2 Outdoor Unit

**MODELS : AJ\*A72LALH, AJ\*A90LALH**




**Note : \*1**

**X1, X2 : To be connected to indoor units**

**Z1, Z2 : To be connected to other master outdoor unit**

**H1, H2 : To be connected to outdoor unit within same refrigerant system**

**MODEL : AJ \* 108LALH**




**Note : \*1**

**X1, X2 : To be connected to indoor units**

**Z1, Z2 : To be connected to other master outdoor unit**

**H1, H2 : To be connected to outdoor unit within same refrigerant system**

# MODELS : AJ\*126LALH, AJ\*144LALH



## Note : \*1

X1, X2 : To be connected to indoor units


Z1, Z2 : To be connected to other master outdoor unit

H1, H2 : To be connected to outdoor unit within same refrigerant system


## 5-3 CHARACTERISTICS OF SENSORS

### 5-3-1 Pressure sensor

#### 1. Discharge Pressure Sensor




With the connector connected to the PCB, measure the voltage between CN118 : 2-3 of the Main PCB.




Pressure (MPa)	0.00	0.10	0.20	0.30	0.40	0.50	0.70	0.80	0.90	1.00	1.20	1.40	1.60	1.80	2.00
Output (V)	0.50	0.58	0.66	0.74	0.82	0.90	1.06	1.14	1.22	1.30	1.46	1.62	1.78	1.94	2.10

Pressure (MPa)	2.20	2.40	2.60	2.80	3.00	3.20	3.40	3.60	3.80	4.00	4.20	4.40	4.60	4.80	5.00
Output (V)	2.26	2.42	2.58	2.74	2.90	3.06	3.22	3.38	3.54	3.70	3.86	4.02	4.18	4.34	4.50

#### 2. Suction Pressure Sensor



With the connector connected to the PCB, measure the voltage between CN119 : 2-3 of the Main PCB.



Pressure (MPa)	0.00	0.10	0.20	0.30	0.40	0.50	0.70	0.80	0.90	1.00	1.10	1.20	1.30	1.40	1.50	1.60	1.70
Output (V)	0.50	0.68	0.85	1.03	1.21	1.38	1.74	1.91	2.09	2.27	2.44	2.62	2.79	2.97	3.15	3.32	3.50



## 5-3-2 Thermistor resistance

### Thermistor resistance value <Outdoor unit side>

Temperature [°C]	Resistance Value [kΩ]			
	Thermistor A	Thermistor B	Thermistor C	Thermistor D
- 20	---	---	105.4	---
- 10	---	27.8	58.2	27.4
- 5	---	21.0	44.0	20.7
0	168.6	16.1	33.6	15.8
5	129.8	12.4	25.9	12.2
10	100.9	9.6	20.2	9.5
15	79.1	7.6	15.8	7.5
20	62.6	6.0	12.5	5.9
25	49.8	4.8	10.0	4.7
30	40.0	3.8	8.0	3.8
40	26.3	2.5	5.3	2.5
50	17.8	1.7	3.6	1.7
60	12.3	1.2	---	1.2
70	8.7	---	---	0.8
80	6.3	---	---	0.6
90	4.6	---	---	0.4
100	3.4	---	---	0.3
110	2.6	---	---	---
120	2.0	---	---	---
Applicable Thermistors	Discharge temp. TH1 Discharge temp. TH2 Comp.1 temp. TH10 Comp.2 temp. TH11	Heat exchanger. TH5 Suction temp. TH4 Sub-cool heat exchanger (inlet) TH8 Sub-cool heat exchanger (outlet) TH9 Liquid temp.1 TH6 Liquid temp.2 TH7	Outdoor temp. TH3	Heat sink temp. TH (CN800)

### Thermistor resistance value <Indoor unit side>

#### Indoor Temperature Thermistor (TH21)

Temperature (°C)	0	5	10	15	20	25	30	35
Resistance Value (kΩ)	33.6	25.2	20.1	15.8	12.5	10.0	8.0	6.5

Temperature (°C)	40	45	50
Resistance Value (kΩ)	5.3	4.3	3.5

#### Heat Exchanger Thermistor (Inlet TH22 / Outlet TH23)

Temperature (°C)	0	5	10	15	20	25	30	35
Resistance Value (kΩ)	168.6	129.8	100.9	79.1	62.5	49.8	40.0	32.4

Temperature (°C)	40	45	50
Resistance Value (kΩ)	26.3	21.2	17.8

### 5-3-3 Saturation temperature and saturation pressure tables (R410A)


(Pressure: Gauge pressure)

Temp. (°C)	Saturation pressure (Mpa)	
	Saturated liquid	Saturated gas
-30	0.1722	0.1717
-29	0.1836	0.1830
-28	0.1953	0.1947
-27	0.2074	0.2067
-26	0.2199	0.2192
-25	0.2328	0.2320
-24	0.2460	0.2452
-23	0.2597	0.2588
-22	0.2737	0.2728
-21	0.2882	0.2872
-20	0.3031	0.3021
-19	0.3185	0.3174
-18	0.3343	0.3331
-17	0.3505	0.3493
-16	0.3672	0.3659
-15	0.3844	0.3830
-14	0.4021	0.4006
-13	0.4202	0.4187
-12	0.4389	0.4373
-11	0.4580	0.4563
-10	0.4776	0.4759
- 9	0.4978	0.4960
- 8	0.5185	0.5166
- 7	0.5398	0.5377
- 6	0.5616	0.5594
- 5	0.5839	0.5817
- 4	0.6069	0.6045
- 3	0.6304	0.6279
- 2	0.6545	0.6519
- 1	0.6791	0.6765
0	0.7044	0.7017
1	0.7303	0.7274
2	0.7569	0.7539
3	0.7840	0.7809
4	0.8119	0.8086
5	0.8403	0.8369
6	0.8695	0.8659
7	0.9000	0.8956
8	0.930	0.926
9	0.961	0.957
10	0.993	0.989
11	1.026	1.022
12	1.059	1.055
13	1.093	1.089
14	1.128	1.123
15	1.164	1.159
16	1.200	1.195
17	1.237	1.232

Temp. (°C)	Saturation pressure (Mpa)	
	Saturated liquid	Saturated gas
18	1.275	1.270
19	1.314	1.308
20	1.353	1.348
21	1.394	1.388
22	1.435	1.429
23	1.477	1.471
24	1.520	1.513
25	1.563	1.557
26	1.608	1.601
27	1.654	1.647
28	1.700	1.693
29	1.747	1.740
30	1.796	1.788
31	1.845	1.837
32	1.895	1.887
33	1.946	1.938
34	1.998	1.990
35	2.051	2.043
36	2.105	2.097
37	2.160	2.152
38	2.216	2.208
39	2.273	2.265
40	2.332	2.323
41	2.391	2.382
42	2.451	2.442
43	2.513	2.503
44	2.575	2.565
45	2.639	2.629
46	2.703	2.693
47	2.769	2.759
48	2.836	2.826
49	2.904	2.894
50	2.974	2.963
51	3.044	3.034
52	3.116	3.106
53	3.189	3.178
54	3.263	3.253
55	3.338	3.328
56	3.415	3.405
57	3.493	3.483
58	3.572	3.562
59	3.653	3.643
60	3.735	3.725
61	3.818	3.808
62	3.902	3.893
63	3.988	3.979
64	4.075	4.066
65	4.164	4.155

Saturation pressure (Mpa)	Saturation temperature (°C)	
	Saturated liquid	Saturated gas
0.0	-51.85	-51.83
0.1	-37.25	-37.21
0.2	-27.61	-27.55
0.3	-20.21	-20.14
0.4	-14.12	-14.04
0.5	- 8.89	- 8.80
0.6	- 4.30	- 4.20
0.7	- 0.17	- 0.06
0.8	3.58	3.69
0.9	7.02	7.15
1.0	10.22	10.35
1.1	13.21	13.34
1.2	16.01	16.15
1.3	18.66	18.80
1.4	21.17	21.31
1.5	23.55	23.70
1.6	25.83	25.98
1.7	28.01	28.16
1.8	30.10	30.25
1.9	32.11	32.26
2.0	34.04	34.20
2.1	35.91	36.06
2.2	37.72	37.87
2.3	39.46	39.62
2.4	41.16	41.31
2.5	42.80	42.95
2.6	44.40	44.55
2.7	45.95	46.10
2.8	47.47	47.62
2.9	48.94	49.09
3.0	50.38	50.53
3.1	51.78	51.93
3.2	53.16	53.30
3.3	54.50	54.63
3.4	55.81	55.94
3.5	57.09	57.22
3.6	58.35	58.48
3.7	59.58	59.70
3.8	60.79	60.91
3.9	61.98	62.09
4.0	63.14	63.25
4.1	63.99	64.38

5-3-4 Temperature and pressure of refrigerant (Graph)



# **AIRSTAGE™ V-II**

*Variable Refrigerant Flow System*

## **6. DISASSEMBLY PROCESS**



## 6. DISASSEMBLY PROCESS

### ⚠ WARNING

Before servicing the unit, turn the power supply switch OFF,  
Then, do not touch electric parts for 10 minutes due to the risk of electric shock.

### 1. Appearance




Model : AJYA72LALH

### 2. PANEL TOP removal



screws

Remove the 4 mounting screws.



Hook (3 places)



Remove the PANEL TOP  
by sliding toward.

### 3. CONTROL BOX COVER removal




screws

Remove the 4 mounting screws.




Remove the CONTROL BOX COVER  
by sliding downward.


4. Layout plan in CONTROL BOX



[REFERENCE DATA]  
Model : AJY126LALF  
(2 compressor model)



## 5. MAIN PCB removal



### ⚠ CAUTION

The model name is written in MAIN PCB of the outdoor unit and indoor unit, and when the factory of the product is shipped, it is written. However, the model name is not written in the MAIN PCB supplied for the repair. When the following function is made to work, the written model name is needed.

1. Display of system list display in service tool or system controller
2. Display of refrigerant circuit diagram in service tool.
3. When you use the electricity charge calculation function as system controller or touch panel controller.


If the model name is not written, the trouble such as the refrigerant circuit diagram is not displayed or the electricity charge calculation is not done accurately might occur.

Therefore, please register the model name to each controller who uses it when you exchange MAIN PCB by the repair.


1. Model name registration to service tool  
Please register the model name with the system list template file.  
(Please see the operation manual of the service tool for details)
2. Model name registration to system controller  
Please register the model name by the electricity charge calculation setting.  
(Please see the operation manual of system controller for details)



6. INVERTER PCB removal




INVERTER PCB




Screws  
(For inverter comp.)

Remove the 3 mounting screws  
and codes.  
Note the tightening torque at the installation.  
Tightening torque is  $2.5 \pm 0.2 \text{ N}\cdot\text{m}$




Screws  
(For capacitor)

Remove the 2 mounting screws  
and codes.  
Note the tightening torque at the installation.  
Tightening torque is  $2.5 \pm 0.2 \text{ N}\cdot\text{m}$




Screws  
(For IPM)

Remove the 2 mounting screws.  
Note the tightening torque at the installation.  
Tightening torque is  $3.0 \pm 0.2 \text{ N}\cdot\text{m}$




Screw  
(For magnetic relay)

Remove the mounting screw and codes.  
Note the tightening torque at the installation.  
Tightening torque is 1.5 to 1.8 N·m



Spacers  
(5 places)


Remove the connectors  
and spacers.



IPM


Spread the heat dissipation compound on the other side of IPM  
when you exchange INVERTER PCB by the repair.

7. PANEL BTM removal




Screws (7places)

Remove the 7 mounting screws.




Hook (3 places)

Remove the PANEL BTM by sliding toward.




8. CONDUIT PLATE removal




Screws (2places)

Remove the 2 mounting screws.




Hook (1 place)

Remove the CONDUIT PLATE by sliding upward.




9. CONTROL BOX open




Screws (2places)


Remove the 2 mounting screws.



Loose the binders.(3 places)




Remove the locking stopper  
of edging saddle.(3 places)



Remove the wires from edging saddle.  
(3 places)




Remove the WIRE PLATE  
by sliding leftward.



Screws (3places)

Remove the 3 mounting screws.



Handle

Open the CONTROL BOX with handle.




## 10. THERMISTORS removal



Cut the binder.



Remove the heat insulation.




## 11. SOLENOID COILS (4way valve and Solenoid valves) removal



Remove the mounting screw.



Remove the SOLENOID COIL.



## 12. EEV COILS removal



Remove the EEV coil by hand.  
There are two coils.

## 13. PRESSURE SENSORS removal




Remove the PRESSURE SENSOR  
with wrench.


There are two sensors.  
(High and Low pressure)

Note the tightening torque at the installation.  
Tightening torque is  $15 \pm 1.5 \text{ N}\cdot\text{m}$ .

## 14. FAN MOTOR removal



Remove the 4 mounting screws.




Remove the FAN GUARD.




Remove the nut.

Note the tightening torque at the installation.  
Tightening torque is from 15 to 20N·m.




Remove the PROPELLER FAN.

Note at the installation.  
Insert propeller Fan and Motor shaft reference  
D cutting position.




Cut the binder.




Remove the 4 mounting screws.  
Remove the FAN MOTOR.

## 15. COMP BOX COVER removal



Remove

Loose the 2 mounting screws.  
Remove the a mounting screw.



Remove the COMP BOX COVER  
by sliding leftward.






## 16. COMPRESSOR removal

### Precautions for exchange of Compressor.


Do not allow moisture or debris to get inside refrigerant pipes during work.

### Procedure for compressor removal.

- (1) Turn off power.
  - (2) Remove the PANEL TOP and PANEL BTM.
  - (3) Fully close the 3WAY VALVE(GAS) and 3WAY VALVE(LIQUID).
  - (4) Collect the refrigerant from the service port.
- Start the following work after completely collecting the refrigerant.  
Do not reuse the refrigerant that has been collected.



Remove the 2 mounting screws.  
Remove the wires.




Remove the 4 mounting screws.



Remove the COMP BOX TOP  
by sliding toward.



Remove the  
3 mounting screws.




Remove the COMP BOX L  
by sliding toward.




Remove the  
mounting screw.



Remove the COMP BOX R  
by sliding toward.



Remove the 2 mounting screws.




Remove the ROOF PLATE  
by sliding toward.




Remove the TERMINAL COVER.



Remove the 3 mounting screws  
of TERMINAL.  
[ U : RED, W : BLACK, V : WHITE ]




Remove the CRANK CASE HEATER.




Remove the Thermistor (comp.temp.)  
and Thermistor (Discharge).  
Remove the heat insulations.



Remove the COMP BOLTS.  
(3 places)



Cut the Discharge pipe in this range.





Cut the Suction pipe in this range.  
Remove the COMPRESSOR.

**Caution**

- Keep their shape better.
- There is a possibility of catching fire to oil when removing by the welding without cutting it.


# [REFERENCE DATA]

Model : AJY126LALF (2 compressor model)




Cut the Oil balance pipe in this range.

Caution —  
· Oil flows out when piping is cut when a lot of oil remains.  
So receive oil with the rag etc.



Cut the Discharge pipe in this range.



Cut the Suction pipe in this range.

Caution —  
· Keep their shape better.  
· There is a possibility of catching fire to oil when removing  
by the welding without cutting it.

## **Procedure for compressor installation.**

Reverse procedure to removing the compressor.

## **Precautions for installation of Compressor.**

- (1) When brazing, do not apply the flame to the terminal.
- (2) When brazing, be sure to replace the air in the pipe with nitrogen gas to prevent forming oxidization scale.



## 17. Precautions for exchange of refrigerant-cycle-parts

- (1) During exchange the following parts shall be protected by wet rag and not make the allowable temperature or more.
- (2) Remove the heat insulation when there is the heat insulation near the welding place.  
Move and cool it when its detaching is difficult.
- (3) Cool the parts when there are parts where heat might be transmitted besides the replacement part.
- (4) Interrupt the flame with the fire-retardant board when the flame seems to hit the following parts directly.
- (5) Do not allow moisture or debris to get inside refrigerant pipes during work.
- (6) When brazing, be sure to replace the air in the pipe with nitrogen gas to prevent forming oxidization scale.

Part name	Allowable temperature	Precautions in work	Applicable Outdoor unit (HP)				
			08	10	12	14	16
SOLENOID VALVE 1 /2 /3	200°C	Remove the coil before brazing. And install the coil after brazing.	○	○	○	○	○
SOLENOID VALVE 5			—	—	—	○	○
SOLENOID VALVE 6			—	—	○	—	—
EXPANSION VALVE 1 /2	120°C	Remove the coil before brazing. And install the coil after brazing.	○	○	○	○	○
4WAY VALVE	120°C	Remove the suction temp. sensor before brazing. And install the suction temp. sensor after brazing.	○	○	○	○	○
CHECK VALVE	120°C		○	○	○	○	○
3WAY VALVE (GAS)	100°C		○	○	○	○	○
3WAY VALVE (LIQUID)			○	○	○	○	○
RELIEF VALVE	120°C		○	○	○	○	○
UNION JOINT	100°C	Remove the pressure sensor before brazing. And install the pressure sensor after brazing.	○	○	○	○	○
HIGH PRESSURE SENSOR	100°C	Tighten the flare part gripping it. (Tightening torque :15±1.5N·m) Do the static electricity measures.	○	○	○	○	○
LOW PRESSURE SENSOR			○	○	○	○	○
PRESSURE SWITCH	100°C		○	○	○	○	○



## **FUJITSU GENERAL LIMITED**

**1116, Suenaga, Takatsu-ku, Kawasaki 213-8502, Japan**

Product specifications are subject to change without notice.

"**AIRSTAGE**" is a worldwide trademark of FUJITSU GENERAL LIMITED.

Copyright© 2004 Fujitsu General Limited. All rights reserved.