


ver service bulletin al final del documento



Domestic Air Conditioner

model 2005 - serial n°: AA5SK0E0C00

Edition:2004/09/15

No. in exploded view	Spare parts number	Spare parts description in english	Model	Qty	Failure rate	The proportion of the spare part stock	Remark
1	0010203843	Front grille					
2	001A2400060/ 001A2400061	Air filter					
3	001A1232074	Front panel assy					
4	001A1232077	Flap					
5	001A0900107	Drain pan assy					
6	0010702158	Heat exchanger					
7	001A0300005	Bearing					
8	0010202415	Fan					
9	001A0100206	Rear case assy					
10	0010101275	Mounting plate					
11	001A3000052	Motor					
12	001A3800002	Tansformer					
13	0010403282	PCB					
14	001A4000091	Terminal block					
15	0010402242	PCB(receiver)					
16	001A1434039	Drain tube					
17	001A3000008	Swing motor					
18	0010402638	Remote controller					
19	001A1434039	Drain tube					
20	001A3900059	Sensor					

1,The failer rate and the proportion of the spare-part stock are regarded as the reference of the stock for spare-parts;The first time should be stocked accroded with the proportion of the spare-parts,and it should be adjusted with the actual quantity 3 months later.

2,easy-damaged;The spare-part which is often damaged and the customer must stock in the spare-parts warehouse,and should be marked with""

3,possible damaged:The spare-part which is not often damaged like the easy damaged one and the customer may stock in the spare-part warehouse accord with the actual case,should be marked with " " .


4,not need provided :The spare-part which is seldom damaged or the maintenance man could not maitmains.The spare parts may be air freighted by the factory if they were damaged.The customer nees not stock in the spare-part warehouse,should be marked with " x " .

5,Above should be improved accord with the reply of the market half a year per time.

6.The spare parts price on net is FOB Qingdao term.

model 2007 - serial n°: AA5SK0E0C00


ver service bulletin al final del documento



No. in explode d view	Reference no.	Spare parts description	Qty
1	001A1232075	Front grille	1
2	001A2400060/1	Air filter	2
3	001A0100945	Front panel assy.	1
4	001A1232077	Flap	1
5	001A0900107	Drain pan assy.	1
6	001A0400055	Heat exchanger	1
7	0010849078	Bearing	1
8	0010202415	Cross flow fan	1
9	001A0100206	Rear case assy.	1
10	0010101275	Mounting plate	1
11	001A3000052	Fan motor	1
12	001A3800002	Tansformer	1
13	0010403282A	PCB	1
14	001A4000091	Terminal block	1
15	0010402241	PCB(receiver)	1
16	001A0900011	Drain tube	1
17	001A3000008	Swing motor	1
18	0010402638	Remote controller	1
19	001A3900059	Sensor	1

model 2005 - serial n°: AA5SK0E0C00

ver service bulletin al final del documento



Domestic Air Conditioner

model 2005 - serial n°: AA5SK0E0C00

Edition:2004/09/15

No. in explode d view	Spare parts number	Spare parts description in english	Model	Qty	Failure rate	The proportion of the spare part stock	Remark
1	0010100777	Front gril					
2	0010100775	Front panel					
3	0010202974	Fan					
4	0010402289	Motor					
5	0010100780	Motor support					
6	0010149003	Heat exchanger left plank					
7	0010706347	Heat exchanger					
8	0010100774	Tope panel					
9	0010100776	Right panel					
10	0010805678	Electric box					
11	0010705072	Suction pipe					
12	0010101027	Heat exchanger right plank					
13	001A2500004	4-way valve winding					
14	001A3600007A	Capacity for motor					
15	001A3600008	Capacity for compressor					
16	0010402287	Terminal block					
17	0010701742	Compressor					
18	001A1762576A	Sound insulating cushion					
19	0010402288	Wire bunch					
20	0010802047	Bottom panel					
21	0010101037	Bottom support					
22	0010100782	Side plank					

1,The failer rate and the proportion of the spare-part stock are regarded as the reference of the stock for spare-parts;The first time should be stocked accroded with the proportion of the spare-parts,and it should be adjusted with the actual quantity 3 months later.


2,easy-damaged;The spare-part which is often damaged and the customer must stock in the spare-parts warehouse,and should be marked with "***"

3,possible damaged:The spare-part which is not often damaged like the easy damaged one and the customer may stock in the spare-part warehouse accord with the actual case,should be marked with " " .

4,not need provided :The spare-part which is seldom damaged or the maintenance man could not maitmains.The spare parts may be air freighted by the factory if they were damaged.The customer nees not stock in the spare-part warehouse,should be marked with " x " .

5,Above should be improved accord with the reply of the market half a year per time.

6.The spare parts price on net is FOB Qingdao term.

model 2007 - serial n°: AA5SK0E0C00**ver service bulletin al final del documento**

No. in exploded view	Reference no.	Spare parts description
1	0010100777	Front gril
2	0010100775	Front panel
3	0010200212	Fan
4	0010402289	Motor
5	0010100780	Motor support
6	0010149003	Heat exchanger left plank
7	0010707491	Heat exchanger
8	0010100774	Tope panel
9	0010806365	Right panel
10	0010100779	Electric box
11	0010707443	Capillary assy
12	0010101393	Heat exchanger right plank
13	0010702789	4-way valve winding
14	001A3600007A	Capacity for motor
15	001A36000032	Capacity for compressor
16	0010402287	Terminal block
17	0010707446	Compressor
18	0010402288	Wire bunch
19	0010100778	Bottom panel
20	0010101287	Bottom support
21	0010100782	Side plank

SERVICE BULLETIN

Fecha: 08/06/07
Referencia: SB-DAITSU-001
PAG. 1/2

Producto: Split Pared On/Off DAITSU
Ref. fabricante: DS12HTA _ DOS12HTA
Código: 3NDA8020 – VL0
Marca: **DAITSU**



ASUNTO: Modelos distintos con misma referencia fabricante. Unidad interior DS12HTA y unidad exterior DOS12HTA.

Para el modelo 3NDA8020 VL0 tenemos dos modelos diferentes de máquina con la misma referencia DS-12HTA / DOS12HTA. Un modelo fabricado en el año 2005 y el otro en 2007.

La mayoría de los componentes principales son diferentes, por lo que cuando llame un cliente preguntado por un recambio será necesario preguntar por el número de serie de la unidad. Este aparece en la placa de características de la unidad interior y exterior

La identificación por el número de serie es la siguiente:

Número de Serie empieza por:

- modelo de 2005: AA5SK0E0C00
- modelo de 2007: AA6F31E0600

daitsu CE
MODEL : DS-12HTA
Split type room air conditioner indoor unit
Power supply 1PH, 220-230V~, 50Hz
Air volume 500m³/h
Anti-electric shock Class: I
Net weight 7.6kg
Manufacture date 0501
0010553539

Item	Mode	Item	Mode
Cooling capacity	3400W	Heating capacity	3700W
Working condition indoor	D.B./W.B. 17°C/19°C	Working condition indoor	D.B./W.B. 20°C/15°C
(cooling) outdoor	D.B./W.B. 35°C/34°C	(heating) outdoor	D.B./W.B. 7°C/6°C
Power input	1300W	Power input	1200W
Current	5.8A	Current	5.4A
Working condition indoor	D.B./W.B. 32°C/23°C	Working condition indoor	D.B./W.B. 17°C/17°C
(rated cooling) outdoor	D.B./W.B. 43°C/35°C	(rated heating) outdoor	D.B./W.B. 24°C/18°C
Rated power input	1650W	Rated power input	1500W
Rated current	6.8A	Rated current	6.1A

Una vez identificado, podéis acceder dentro del poppro al manual de servicio, despieces y exploded views de la máquina donde están identificados los dos modelos según el número de serie.

SERVICE BULLETIN

Fecha:	08/06/07	PAG. 2/2
Referencia:	SB-DAITSU-001	

Producto: Split Pared On/Off DAITSU
Ref. fabricante: DS12HTA _ DOS12HTA
Código: 3NDA8020 – VLO
Marca: **DAITSU**



Otras posibles maneras de identificar los dos modelos:

1. Las conexiones frigoríficas de la unidad interior y exterior son:
 - a. 1/4" y 1/2" para el modelo 2005 (AA5SK0E0C00)
 - b. 1/4 y 3/8" para el modelo 2007 (AA6F31E0600)
2. La unidad exterior fabricada en 2007 (AA6F31E0600) tiene tapa recoge gotas en las llaves de servicio. La fabricada en el 2005 (AA5SK0E0C00) no la lleva.



3. La potencia que aparece en las placas de características interior y exterior es diferente según el modelo:
 - a. Modelo 2005 (AA5SK0E0C00), frío 3400W / calor 3700W
 - b. Modelo 2007 (AA6F31E0600), frío 3200W / calor 3500W